

DEBRIS SHIELD FOR PROCHRONO MODELS - COMPETITION

ELECTRONICS DEBRIS SHIELD FOR PROCHRONO MODELS

Lexan Debris Shield to be used with ProChrono Models Clear lexan cover protects the display from debris. Covers the entire front and top of unit. Held in place with the guide wires Control buttons remain accessible Not intended to protect chronograph from projectiles

Lexan Debris Shield to be used with ProChrono Models Clear lexan cover protects the display from debris. Covers the entire front and top of unit. Held in place with the guide wires Control buttons remain accessible Not intended to protect chronograph from projectiles



Attributes

- Name: COMPETITION ELECTRONICS DEBRIS SHIELD FOR PROCHRONO MODELS
- Manufacturer: COMPETITION ELECTRONICS
- Product no.: 225000010
- Mfr. No.: CEI-2519
- Colour: Clear
- Style: Chronograph Accessory
- Delivery weight: 2.268kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 432mm
- UPC: 787735025194

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: DEBRIS SHIELD FOR PROCHRONO MODELS Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för DEBRIS SHIELD för ProChronomodeller](#)

DEBRIS SHIELD FOR PROCHRONO MODELS Safety Instruction Guide

Introduction

Thank you for choosing the Debris Shield for ProChrono Models by Competition Electronics. This guide provides essential safety instructions, usage guidelines, and installation procedures to ensure the safe and effective use of this product. Please read this document carefully before use.

General Safety Guidelines

- Ensure the Debris Shield is used only with ProChrono Models.
- Do not attempt to modify or alter the Debris Shield in any way.
- Keep the Debris Shield out of reach of children and vulnerable individuals.
- Regularly inspect the Debris Shield for any signs of damage or wear.
- If the Debris Shield shows signs of damage, discontinue use immediately and replace it.
- Be aware that the Debris Shield is not designed to protect the chronograph from projectiles.

Specific Safety Precautions for Use

- Always ensure that the Debris Shield is securely attached before operating the chronograph.
- Do not place any objects on top of the Debris Shield that may obstruct the display or control buttons.
- Ensure that the control buttons remain accessible at all times for safe operation.
- Avoid using the Debris Shield in extreme weather conditions that may affect its integrity.
- If using the chronograph outdoors, ensure that the area is free from debris that could interfere with its operation.

Instructions for Installation and Usage

1. Installation of the Debris Shield:

- Remove the Debris Shield from its packaging.
- Align the Debris Shield with the front and top of the ProChrono Model.
- Secure the Debris Shield in place using the guide wires provided.
- Ensure that the shield covers the entire front and top of the unit.

2. Usage of the Debris Shield:

- Once the Debris Shield is installed, check that all control buttons are easily accessible.
- Power on the chronograph and ensure that the display is visible through the lexan cover.
- Conduct your chronograph operations as per the manufacturer's instructions while ensuring the Debris Shield remains in place.

3. PostUse Care:

- After use, inspect the Debris Shield for any damage.
- Clean the Debris Shield with a soft, damp cloth to remove any debris or marks.
- Store the Debris Shield in a safe, dry place when not in use.

Disposal Instructions

- Dispose of the Debris Shield in accordance with local waste management regulations.
- If the Debris Shield is damaged beyond repair, ensure it is disposed of in an environmentally friendly

manner.

- Do not incinerate the Debris Shield as it may release harmful substances.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Debris Shield for ProChrono Models, please reach out to the appropriate EU-based contact point as specified by the manufacturer.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of the Debris Shield for ProChrono Models. Always prioritize safety and report any unsafe conditions or incidents to the relevant authorities. Thank you for your attention to these guidelines, and enjoy using your chronograph safely.

Säkerhetsinstruktioner för DEBRIS SHIELD för ProChronomodeller

Introduktion

Tack för att du valt DEBRIS SHIELD för ProChronomodeller. Denna produkt är utformad för att skydda din ProChronoenhet från skräp och förlänga dess livslängd. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa säker och korrekt användning av produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens anvisningar.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Förvara produkten på en säker plats, utom räckhåll för barn.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- DEBRIS SHIELD är avsett att skydda din ProChronoenhet från skräp, men är inte avsett att skydda mot projektiler.
- Kontrollknapparna förblir åtkomliga, men undvik att trycka på dem med överdrivet tryck.
- Använd inte produkten om den är skadad eller trasig.
- Följ alltid säkerhetsföreskrifter och riktlinjer för användning av kronografer.

Instruktioner för installation och användning

1. Installation av DEBRIS SHIELD:

- Ta bort eventuella skydd eller förpackningar från DEBRIS SHIELD.
- Placera DEBRIS SHIELD på framsidan och toppen av ProChronoenheten.
- Använd de vägledande kablarna för att fästa DEBRIS SHIELD på plats.
- Se till att DEBRIS SHIELD sitter ordentligt och att kontrollknapparna är lättåtkomliga.

2. Användning av ProChrono med DEBRIS SHIELD:

- Slå på ProChronoenheten som vanligt.
- Kontrollera att DEBRIS SHIELD inte blockerar någon del av displayen.
- Använd kontrollknapparna försiktigt för att undvika att skada DEBRIS SHIELD.

Avfallshanteringsinstruktioner

- När DEBRIS SHIELD inte längre behövs, kassera den enligt lokala avfallsbestämmelser.
- Återvinn materialet om möjligt, följ lokala riktlinjer för återvinning av plast.

Kontaktinformation för ytterligare support

För frågor eller mer information om DEBRIS SHIELD, vänligen kontakta tillverkaren eller den lokala återförsäljaren. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för snabbare hjälp.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att använda produkten på rätt sätt skyddar du både din ProChronoenhet och dig själv.