

ROTATING GUN RACK - WINCHESTER 12 GUN ROTATING RACK BLACK

"Lazy Susan Rack For Display & Easy Access To Each Gun

Sturdy "Lazy Susan" style rack of steel and $\frac{3}{4}$ " plywood laminate holds 12 long guns for convenient storage and display. Recessed polymer boot in the base cradles each gun's buttplate, while felt-lined notches with soft rubber fingers securely grasp the forearm, so your guns can't slip off the rack. Steel central support post with telescoping height adjustment. Attractive wood grain pattern on the laminate, with Winchester logo on the post. Smooth, silent-rotating base makes this rack great for use in the corner of a room, an eye-catching in-store display, or even inside a large gun safe.



Attributes

- Name: WINCHESTER 12 GUN ROTATING RACK BLACK
- Manufacturer: WINCHESTER
- Product no.: 430107222
- Mfr. No.: RASW003-MB
- Capacity: 12
- Colour: Black
- Height (Inches): 38.6"
- Length (Inches): 21.65"
- Material: Wood
- Style: Universal
- Width (Inches): 21.65"
- Delivery weight: 12.383kg
- Shipping height: 630mm
- Shipping width: 230mm
- Shipping length: 630mm
- UPC: 877697004440

Table of Contents

- [Startpage](#)
- [English: ROTATING GUN RACK DI ARMERIA EQUIPMENT Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för ROTATING GUN RACK WINCHESTER 12 GUN ROTATING RACK BLACK](#)

ROTATING GUN RACK DI ARMERIA EQUIPMENT

Safety Instruction Guide

Introduction

Thank you for choosing the ROTATING GUN RACK DI ARMERIA EQUIPMENT. This guide provides essential safety instructions to ensure the safe and effective use of your gun rack. By following these guidelines, you can help prevent accidents and ensure that your gun rack serves its purpose effectively.

General Safety Guidelines

- Always ensure that the gun rack is placed on a flat, stable surface to prevent tipping.
- Regularly check the integrity of the rack, including the stability of the base and the condition of the materials.
- Ensure that the gun rack is used only for its intended purpose – storing and displaying long guns.
- Keep the area around the gun rack clear of obstacles to prevent accidents.
- Always supervise children and vulnerable individuals around the gun rack.
- In case of any defects or damages, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Ensure that all firearms are unloaded before placing them on the rack.
- Avoid overloading the gun rack beyond its capacity of 12 long guns.
- When rotating the rack, do so slowly and carefully to prevent firearms from falling.
- Use the feltlined notches and polymer boot properly to secure firearms in place.
- Do not attempt to adjust the height of the rack while firearms are stored on it.
- Keep the rack away from heat sources and direct sunlight to prevent material degradation.

Instructions for Installation and Usage

1. Unpacking the Rack

- Carefully remove the gun rack from its packaging.
- Inspect all components for any signs of damage or missing parts.

2. Setting Up the Rack

- Place the rack on a level surface.
- Ensure that the base is sturdy and stable before placing firearms on it.

3. Adjusting the Height

- To adjust the height, loosen the central support post's locking mechanism.
- Adjust to the desired height and securely tighten the locking mechanism.

4. Storing Firearms

- Ensure all firearms are unloaded before placing them on the rack.
- Place the butt of each firearm into the recessed polymer boot at the base.
- Position the forearm of each firearm into the feltlined notches, ensuring they are securely held by the soft rubber fingers.

5. Using the Rotating Feature

- Gently rotate the rack to access different firearms.
- Avoid sudden movements to prevent firearms from dislodging.

6. Regular Maintenance

- Periodically check the rack for stability and wear.
- Clean the rack with a damp cloth to maintain its appearance.

Disposal Instructions

- When disposing of the gun rack, follow local regulations regarding waste disposal.
- If the rack is no longer usable, consider recycling the materials where possible.
- Ensure that any firearms or ammunition are stored securely and disposed of in accordance with local laws.

Contact Information for Further Support

For any inquiries or concerns regarding the ROTATING GUN RACK DI ARMERIA EQUIPMENT, please refer to the contact information provided by the manufacturer. Ensure to have the product details ready when seeking assistance.

By adhering to these safety guidelines, you can ensure a safe and enjoyable experience with your ROTATING GUN RACK DI ARMERIA EQUIPMENT. Thank you for your attention to safety.

Säkerhetsinstruktioner för ROTATING GUN RACK WINCHESTER 12 GUN ROTATING RACK BLACK

Introduktion

Tack för att du har valt ROTATING GUN RACK WINCHESTER 12 GUN ROTATING RACK BLACK. Denna produkt är utformad för att ge säker och bekväm förvaring av dina långvapen. För att säkerställa en trygg användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Produkten är avsedd för säker användning av långvapen och är inte en leksak. Håll alltid produkten utom räckhåll för barn.
- Kontrollera produkten regelbundet för tecken på slitage eller skador. Använd inte produkten om den är skadad.
- Följ alltid tillverkarens anvisningar för installation och användning.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Se till att alla vapen är korrekt placerade i stället och att de inte kan falla ut.
- Använd alltid produkten på en plan yta för att förhindra att den välter.
- Undvik att överbelasta stället med fler än 12 långvapen.
- Håll händerna borta från roterande delar när stället används för att undvika klämrisk.
- Använd inte produkten om den är fuktig eller blöt, eftersom detta kan påverka stabiliteten.

Instruktioner för installation och användning

1. Installation:

- Placera stället på en stabil, plan yta.
- Kontrollera att basen är helt i kontakt med ytan.
- Montera stålcentralen enligt tillverkarens anvisningar.
- Justera höjden på stödposten så att den är stabil.

2. Användning:

- Lasta inte mer än 12 långvapen i stället.
- Se till att varje vapen är ordentligt placerat i urtagen.
- Använd det teleskopiska höjjusteringssystemet för att justera stället efter behov.
- Roterar stället försiktigt för att visa vapen utan att riskera att de faller.

Avfallshantering

- När produkten inte längre är i bruk, se till att den kasseras på ett säkert sätt.
- Återvinn materialet när det är möjligt, och följ lokala riktlinjer för avfallshantering.
- Ta bort alla delar av produkten innan du kasserar den, för att säkerställa att den inte kan användas av barn eller andra obehöriga.

Kontaktinformation för vidare stöd

För frågor eller ytterligare information om produkten, vänligen kontakta tillverkaren eller din återförsäljare. Se till att ha produktens serienummer och inköpsinformation tillgänglig för att få bästa möjliga support.

Tack för att du följer dessa säkerhetsinstruktioner och för att du bidrar till en säker användning av ROTATING GUN RACK WINCHESTER 12 GUN ROTATING RACK BLACK.