

MAGAZINE LATCH, BLUE

FITS: 77/22® R, RS, .22 LR; 77/22® RH, RSH, .22 Hornet; 77/22® RM, RSM, .22 Mag



Attributes

- Name: MAGAZINE LATCH, BLUE
- Manufacturer: RUGER
- Product no.: 780000289
- Mfr. No.: J03400
- Make: Ruger
- Model: 77/22
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: MAGAZINE LATCH, BLUE Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för MAGAZINE LATCH, BLUE RUGER MAGAZINE LATCH, BLUE](#)

MAGAZINE LATCH, BLUE Safety Instruction Guide

Introduction

Thank you for purchasing the MAGAZINE LATCH, BLUE. This guide provides essential safety instructions and information to ensure the safe use of your product. Please read this guide carefully before installation and use.

General Safety Guidelines

- Ensure the MAGAZINE LATCH is compatible with your firearm model: Ruger 77/22® R, RS, .22 LR; 77/22® RH, RSH, .22 Hornet; 77/22® RM, RSM, .22 Mag.
- Always follow the manufacturer's instructions for your firearm when using the MAGAZINE LATCH.
- Keep the MAGAZINE LATCH out of reach of children and unauthorized users.
- Regularly inspect the MAGAZINE LATCH for any signs of wear or damage before use.
- If you notice any defects or malfunctions, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Always ensure the firearm is unloaded before installing or adjusting the MAGAZINE LATCH.
- Do not attempt to modify or alter the MAGAZINE LATCH. Unauthorized modifications may compromise safety.
- Use the MAGAZINE LATCH only for its intended purpose and with compatible firearms.
- Avoid exposing the MAGAZINE LATCH to extreme temperatures or harsh chemicals, as this may affect its performance.
- If using the MAGAZINE LATCH in adverse weather conditions, ensure it is properly maintained to prevent malfunctions.

Instructions for Installation and Usage

1. Installation

- Ensure the firearm is pointed in a safe direction and is unloaded.
- Remove any existing magazine latch if necessary.
- Align the MAGAZINE LATCH with the designated area on your Ruger firearm.
- Securely fasten the MAGAZINE LATCH according to the manufacturer's instructions.
- Confirm that the MAGAZINE LATCH is installed correctly and is functioning as intended.

2. Usage

- To release the magazine, press the MAGAZINE LATCH as instructed in your firearm's manual.
- Always check the firearm's chamber to ensure it is clear before proceeding with any operation.
- Store the firearm in a secure location when not in use, ensuring the MAGAZINE LATCH is in place.

Disposal Instructions

- Dispose of the MAGAZINE LATCH in accordance with local regulations regarding plastic and metal waste.
- Do not incinerate the MAGAZINE LATCH, as it may release harmful substances when burned.
- If you no longer need the MAGAZINE LATCH, consider returning it to the retailer or manufacturer for proper disposal.

Contact Information for Further Support

For any questions or concerns regarding the MAGAZINE LATCH, please refer to the manufacturer's website or

customer service for assistance. Always ensure you are following the latest safety guidelines and product updates.

Conclusion

The MAGAZINE LATCH, BLUE is designed to provide reliable performance when used correctly. By following the safety instructions outlined in this guide, you can ensure a safe and enjoyable experience with your product. Always prioritize safety and stay informed about best practices for firearm use.

Säkerhetsinstruktioner för MAGAZINE LATCH, BLUE RUGER MAGAZINE LATCH, BLUE

Introduktion

Tack för att du har valt MAGAZINE LATCH, BLUE RUGER MAGAZINE LATCH, BLUE. Denna produkt är designad för att användas med Ruger 77/22serien av gevär. För att säkerställa säker användning och långvarig prestanda är det viktigt att följa dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Inspektera produkten före varje användning för att säkerställa att den är i gott skick.
- Förvara produkten på en säker plats, utom räckhåll för barn och andra som inte är utbildade i säker vapenhantering.
- Rapportera eventuella skador eller fel på produkten till tillverkaren.
- Kontrollera regelbundet för eventuella återkallelser på EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd endast MAGAZINE LATCH, BLUE med kompatibla Rugermodeller: 77/22® R, RS, .22 LR; 77/22® RH, RSH, .22 Hornet; 77/22® RM, RSM, .22 Mag.
- Se till att vapnet är avstängt och tomt innan du installerar eller justerar magazine latch.
- Undvik att använda produkten om den är skadad eller om det finns tecken på slitage.
- Låt aldrig obehöriga personer hantera eller använda produkten.

Instruktioner för installation och användning

1. Installation av Magazine Latch:

- Ta bort det gamla magazine latch om det finns ett.
- Placera det nya magazine latch i den avsedda positionen på vapnet.
- Se till att latches sitter ordentligt på plats och inte är lös.

2. Användning av Magazine Latch:

- För att frigöra magasinet, tryck på magazine latches med ett jämnt tryck.
- Kontrollera att magasinet är säkert installerat innan du avfyrar vapnet.
- Efter användning, kontrollera att magasinet är tomt och avlägsna det från vapnet för säker förvaring.

Avfallshanteringsinstruktioner

- Kasta inte produkten i hushållssoporna.
- Följ lokala riktlinjer för avfallshantering av ickefarliga produkter.
- Kontakta din lokala avfallshanteringsmyndighet för information om korrekt bortskaffande av produkten.

Kontaktinformation för vidare support

För eventuella frågor eller säkerhetsinquiry, vänligen kontakta tillverkaren eller en auktoriserad återförsäljare.

Observera att dessa säkerhetsinstruktioner är utformade för att hjälpa dig att använda MAGAZINE LATCH, BLUE RUGER MAGAZINE LATCH, BLUE på ett säkert och effektivt sätt. Följ alltid dessa riktlinjer och håll produkten

borta från obehöriga personer för att säkerställa en säker och positiv användarupplevelse.