

RECOIL PLATE CROSS PIN

FITS: New Model Bearcat®, Serial # Above 93-00000, .22



Attributes

- Name: RECOIL PLATE CROSS PIN
- Manufacturer: RUGER
- Product no.: 780000947
- Mfr. No.: PR49
- Make: Ruger
- Model: Bearcat
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: RECOIL PLATE CROSS PIN Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för RECOIL PLATE CROSS PIN RUGER](#)

RECOIL PLATE CROSS PIN Safety Instructions

Introduction

Thank you for choosing the RECOIL PLATE CROSS PIN for your Ruger Bearcat® firearm. This product is designed to enhance the performance and reliability of your firearm. To ensure safe and effective use, please read this safety instruction guide carefully before installation and use.

General Safety Guidelines

- Always handle firearms with care and respect.
- Ensure that the firearm is unloaded before performing any maintenance or installation.
- Keep this product out of reach of children and unauthorized users.
- Follow all local laws and regulations regarding firearm ownership and use.
- Regularly inspect your firearm and its components for signs of wear or damage.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the RECOIL PLATE CROSS PIN is compatible with your Ruger Bearcat® model, specifically those with a serial number above 9300000.
- Always wear protective eyewear when working on or near firearms.
- Do not attempt to modify the RECOIL PLATE CROSS PIN or any other firearm components.
- If you are unsure about the installation or use of this product, seek assistance from a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation

- Make sure the firearm is completely unloaded.
- Gather the necessary tools for installation, including a punch tool and hammer.

2. Installation Steps

- Locate the recoil plate area of your Ruger Bearcat®.
- Align the RECOIL PLATE CROSS PIN with the designated hole in the recoil plate.
- Gently tap the pin into place using the punch tool and hammer, ensuring it is securely fitted.
- Doublecheck that the pin is flush with the recoil plate and does not protrude.

3. PostInstallation Check

- Inspect the installation to ensure there are no loose parts.
- Perform a function check of your Ruger Bearcat® to ensure proper operation.

4. Usage Guidelines

- Follow the manufacturer's instructions for operating your firearm.
- Regularly check the RECOIL PLATE CROSS PIN for any signs of wear or damage, particularly after extensive use.

Disposal Instructions

- Dispose of any damaged or unused parts in accordance with local regulations.
- Do not dispose of the RECOIL PLATE CROSS PIN in regular household waste.

- Contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any questions regarding the RECOIL PLATE CROSS PIN or safety concerns, please contact the manufacturer or a qualified firearms expert. Ensure that you have the product details and serial number available for reference.

Thank you for prioritizing safety and compliance when using the RECOIL PLATE CROSS PIN. Enjoy your shooting experience responsibly.

Säkerhetsinstruktioner för RECOIL PLATE CROSS PIN RUGER

Introduktion

Tack för att du valt RECOIL PLATE CROSS PIN RUGER. Denna produkt är designad för att förbättra säkerheten och funktionen hos din Ruger Bearcat®. För att säkerställa en säker och korrekt användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Säkerställ att produkten används enligt tillverkarens anvisningar.
- Kontrollera produkten regelbundet för skador eller slitage.
- Förvara produkten på en säker plats, utom räckhåll för barn.
- Rapportera eventuella osäkra produkter eller incidenter till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddsglasögon och handskar när du installerar eller hanterar produkten.
- Kontrollera att alla delar är korrekt installerade och säkrade innan användning.
- Använd endast produkten med Ruger Bearcat®-modeller med serienummer ovan 9300000.
- Undvik att använda produkten om du upptäcker några defekter.
- Följ alltid lokala lagar och föreskrifter om vapenhantering.

Instruktioner för installation och användning

1. Installation av Recoil Plate Cross Pin:

- Se till att vapnet är oladdat och säkert innan installation.
- Använd ett lämpligt verktyg för att ta bort den gamla recoil plate cross pin om sådan finns.
- Placera den nya recoil plate cross pin på rätt plats och se till att den sitter ordentligt.
- Kontrollera att alla delar är korrekt installerade innan du återmonterar vapnet.

2. Användning av produkten:

- Efter installation, använd vapnet enligt tillverkarens instruktioner.
- Utför regelbundna kontroller för att säkerställa att recoil plate cross pin är på plats och i gott skick.

Avfallshanteringsinstruktioner

- Kasta bort eventuella förpackningar och onödiga delar på ett miljövänligt sätt.
- Följ lokala riktlinjer för återvinning och avfallshantering för vapenrelaterade produkter.
- Om produkten är defekt eller oanvändbar, kontakta en auktoriserad återförsäljare för korrekt avfallshantering.

Kontaktinformation för vidare stöd

För säkerhetsfrågor eller ytterligare support, vänligen kontakta en lokal auktoriserad återförsäljare eller besök tillverkarens webbplats för mer information.