

SIGHT BLADE, FRONT, PLAIN, BLACK

FITS: Bisley™ Large Frame, .45; New Model Blackhawk®, .45



Attributes

- Name: SIGHT BLADE, FRONT, PLAIN, BLACK
- Manufacturer: RUGER
- Product no.: 780001230
- Mfr. No.:
- Color: Black
- Height: .440
- Make: Ruger
- Model: Blackhawk
- Outline: None
- Style: Serrated
- Width: .125
- Delivery weight: 0.005kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for SIGHT BLADE, FRONT, PLAIN, BLACK](#)
- [Svenska: Säkerhetsinstruktioner för SIGHT BLADE, FRONT, PLAIN, BLACK](#)

Safety Instruction Guide for SIGHT BLADE, FRONT, PLAIN, BLACK

Introduction

Thank you for choosing the SIGHT BLADE, FRONT, PLAIN, BLACK. This guide provides essential safety instructions and information to ensure the safe and effective use of the product. Please read this document carefully before installation and usage.

General Safety Guidelines

- Ensure that the product is compatible with your firearm model before use.
- Always handle firearms and accessories with care, treating them as if they are loaded.
- Store the product in a safe place, out of reach of children and unauthorized users.
- Regularly inspect the product for any signs of damage or wear.
- If you experience any issues or have concerns about the product, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Always wear appropriate eye protection when using firearms equipped with this sight blade.
- Do not modify the sight blade or any related components, as this may compromise safety and performance.
- Ensure that the firearm is unloaded before installing or adjusting the sight blade.
- Be cautious of the surrounding environment when using firearms to prevent accidents and injuries.
- Follow all local laws and regulations regarding the use of firearms and related accessories.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather the necessary tools for installation.

2. Installation Steps

- Remove the existing sight blade from the firearm using the appropriate tools.
- Align the SIGHT BLADE, FRONT, PLAIN, BLACK with the sight base on your firearm.
- Secure the sight blade in place, ensuring it is firmly attached.
- Check the alignment and make any necessary adjustments.

3. Usage

- Once installed, familiarize yourself with the sight alignment and how it affects your aim.
- Practice using the sight blade in a safe and controlled environment to enhance accuracy.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding firearm accessories.
- Do not dispose of the sight blade in regular household waste.
- If the product is damaged or no longer needed, consider recycling or returning it to the manufacturer.

Contact Information for Further Support

For any inquiries related to safety or product performance, please reach out to the appropriate EUbased contact point for assistance. Always ensure that you have the latest product information and safety updates.

By adhering to these safety guidelines and instructions, you help ensure a safe and enjoyable experience with your SIGHT BLADE, FRONT, PLAIN, BLACK. Thank you for your attention to safety.

Säkerhetsinstruktioner för SIGHT BLADE, FRONT, PLAIN, BLACK

Introduktion

Tack för att du valt SIGHT BLADE, FRONT, PLAIN, BLACK från Ruger. Denna produkt är designad för att förbättra din skjutprestanda och säkerhet. Det är viktigt att följa dessa säkerhetsinstruktioner noggrant för att säkerställa korrekt och säker användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Använd enbart originaldelar och tillbehör från Ruger för att säkerställa säkerhet och prestanda.
- Vid osäkerhet, kontakta en professionell för råd.

Specifika säkerhetsåtgärder för användning

- Kontrollera att siktbladet är korrekt installerat innan användning.
- Använd skyddsglasögon vid installation och användning för att skydda ögonen.
- Undvik att rikta vapnet mot dig själv eller andra när du installerar eller justerar siktbladet.
- Se till att vapnet är avsäkrat och ur funktion under installationen av siktbladet.
- Vid användning, följ alltid säkerhetsrutiner för skjutning och hantering av vapen.

Instruktioner för installation och användning

1. Förberedelse

- Se till att du har alla nödvändiga verktyg tillgängliga för installationen.
- Kontrollera att vapnet är avsäkrat och ur funktion.

2. Installation

- Ta bort det gamla siktbladet om det finns något installerat.
- Placera det nya siktbladet på rätt plats och se till att det är korrekt justerat.
- Fäst siktbladet med de medföljande skruvarna och dra åt dem försiktigt.
- Kontrollera att siktbladet sitter fast och är stabilt.

3. Användning

- När siktbladet är installerat, justera det vid behov för att passa dina skjutpreferenser.
- Utför en säkerhetstest innan du använder vapnet för skjutning.

Avfallshanteringsinstruktioner

- Kasta alltid bort förpackningsmaterial och gamla delar på ett miljövänligt sätt.
- Om produkten är skadad eller inte längre i bruk, följ lokala riktlinjer för avfallshantering.

Kontaktinformation för vidare stöd

- För frågor om säkerhet eller produktinformation, vänligen kontakta din lokala återförsäljare eller Rugers kundtjänst.

Genom att följa dessa säkerhetsinstruktioner kan du bidra till att säkerställa en trygg och effektiv användning av SIGHT BLADE, FRONT, PLAIN, BLACK. Tack för att du prioriterar säkerheten!