

GRIP FRAME SCREW, A-FRONT

FITS: Bisley™ - Common Parts; New Model Bearcat®, Serial # Above 93-00000, .22; New Model Blackhawk®; New Model Single-Six®; Old Army™, .45; Old Model Blackhawk®; Old Model Single-Six®, .22; Old Model Super Blackhawk®, .44 Mag; Super Blackhawk®, .44



Attributes

- Name: GRIP FRAME SCREW, A-FRONT
- Manufacturer: RUGER
- Product no.: 780012078
- Mfr. No.: XR01700
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.002kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: GRIP FRAME SCREW, AFRONT Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för GRIP FRAME SCREW, AFRONT RUGER GRIP FRAME SCREW, AFRONT](#)

GRIP FRAME SCREW, AFRONT Safety Instruction Guide

Introduction

Thank you for choosing the GRIP FRAME SCREW, AFRONT. This product is designed to fit various Ruger models, ensuring optimal performance and safety. It is essential to read and understand this safety instruction guide to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is compatible with your firearm model before installation.
- Always handle firearms and associated parts with care to prevent accidents.
- Store the GRIP FRAME SCREW in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Only use the GRIP FRAME SCREW with the following compatible models:
 - New Model Bearcat®, Serial # Above 9300000, .22
 - New Model Blackhawk®
 - New Model SingleSix®
 - Old Army™, .45
 - Old Model Blackhawk®
 - Old Model SingleSix®, .22
 - Old Model Super Blackhawk®, .44 Mag
 - Super Blackhawk®, .44
- Ensure that the firearm is unloaded before attempting to install or remove the screw.
- Avoid using excessive force during installation to prevent damaging the screw or firearm.
- If you are unsure about the installation process, consult a qualified gunsmith for assistance.
- Always wear appropriate safety gear, such as eye protection, when handling firearms.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is pointed in a safe direction and is unloaded.
- Gather necessary tools, including a screwdriver that fits the GRIP FRAME SCREW.

2. Installation

- Locate the grip frame on your compatible Ruger model.
- Align the GRIP FRAME SCREW with the designated hole on the grip frame.
- Insert the screw and gently turn it clockwise until it is snug. Do not overtighten.

3. PostInstallation Check

- After installation, check that the grip is securely attached.
- Ensure that there are no gaps between the grip and the frame.

4. Usage

- Regularly check the tightness of the GRIP FRAME SCREW during routine maintenance.
- If you notice any looseness or damage, remove the screw and inspect it for wear.

Disposal Instructions

- Dispose of the GRIP FRAME SCREW in accordance with local regulations for metal waste.
- Do not dispose of the product in regular household waste.
- Consider recycling options if available in your area.

Contact Information for Further Support

For any inquiries or concerns regarding the GRIP FRAME SCREW, please contact your local retailer or manufacturer representative. Ensure that you have the product details ready for efficient assistance.

Thank you for your attention to safety and compliance. Your responsible use of the GRIP FRAME SCREW contributes to a safer shooting experience.

Säkerhetsinstruktioner för GRIP FRAME SCREW, AFRONT RUGER GRIP FRAME SCREW, AFRONT

Introduktion

Tack för att du har valt GRIP FRAME SCREW, AFRONT. Denna produkt är utformad för att ge säker och effektiv användning med Rugervapen. För att säkerställa en säker och korrekt användning av produkten, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Förvara produkten på en säker plats, utom räckhåll för barn.
- Rapportera eventuella osäkra produkter eller olyckor till myndigheterna.
- Håll dig informerad om återkallelser genom EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder vid användning

- Använd endast produkten för avsett syfte, vilket är att fästa greppramen på Rugervapen.
- Kontrollera att skruven är korrekt installerad innan användning av vapnet.
- Undvik att använda produkten om den är skadad eller defekt.
- Använd skyddsutrustning, såsom skyddsglasögon, vid installation och hantering av produkten.
- Var medveten om att felaktig installation kan leda till allvarliga skador eller olyckor.

Instruktioner för installation och användning

1. Förberedelse:

- Se till att du har rätt verktyg för installationen.
- Rengör området där skruven ska installeras för att säkerställa en bra passform.

2. Installation:

- Placera skruven i det avsedda hålet på greppramen.
- Använd ett skruvmejsel för att försiktigt dra åt skruven. Se till att den inte är för hårt åtdragen för att undvika skador på materialet.

3. Användning:

- Kontrollera att skruven sitter ordentligt på plats innan du använder vapnet.
- Utför regelbundna kontroller av skruven för att säkerställa att den är i gott skick.

Avfallsanvisningar

- Kasta inte produkten i hushållsavfall.
- Följ lokala riktlinjer för avfallshantering för metallskrot.
- Om produkten är skadad eller inte längre behövs, se till att den hanteras på ett miljövänligt sätt.

Kontaktinformation för ytterligare stöd

För frågor eller mer information om säkerhet och användning av GRIP FRAME SCREW, AFRONT, vänligen kontakta tillverkaren eller återförsäljaren. Se till att ha produktens serienummer tillgängligt för att få bästa

möjliga support.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.