

GRIP FRAME SCREW, C-BOTTOM

FITS: Bisley™ - Common Parts; New Model Blackhawk®; New Model Single-Six®; Old Army†, .45; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®



Attributes

- Name: GRIP FRAME SCREW, C-BOTTOM
- Manufacturer: RUGER
- Product no.: 780012081
- Mfr. No.: XR01900
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: GRIP FRAME SCREW, CBOTTOM Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för GRIP FRAME SCREW, CBOTTOM RUGER](#)

GRIP FRAME SCREW, CBOTTOM Safety Instructions

Introduction

Thank you for choosing the GRIP FRAME SCREW, CBOTTOM. This product is designed for specific models of Ruger firearms, including Bisley™, New Model Blackhawk®, New Model SingleSix®, Old Army†, Super Blackhawk®, and Vaquero®. This guide provides essential safety instructions and guidelines to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always ensure that the firearm is unloaded before installing or handling the grip frame screw.
- Keep the product out of reach of children and unauthorized users.
- Inspect the product for any damage or defects before use.
- Follow all local laws and regulations regarding firearm accessories.
- Report any unsafe products or incidents to the appropriate authorities.
- Regularly check for product recalls on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Only use the GRIP FRAME SCREW, CBOTTOM with compatible Ruger models as listed.
- Do not attempt to modify or alter the product in any way.
- Ensure that all screws are tightened properly to avoid any malfunction during use.
- Use appropriate tools for installation to prevent injury or damage to the product.
- If you are unsure about the installation process, seek assistance from a qualified professional.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is completely unloaded.
- Gather the necessary tools, including a screwdriver that fits the screw head.

2. Installation Steps

- Remove the existing grip frame screw if applicable.
- Align the GRIP FRAME SCREW, CBOTTOM with the grip frame.
- Insert the screw into the designated hole.
- Using the screwdriver, tighten the screw securely but do not overtighten, as this may damage the grip frame.

3. Usage

- After installation, ensure that the grip is securely attached before handling the firearm.
- Regularly check the tightness of the screw, especially after extensive use or if the firearm is transported.

Disposal Instructions

- Dispose of any packaging materials and old screws in accordance with local waste disposal regulations.
- Do not dispose of the product in household waste. Instead, take it to a designated recycling center or follow local guidelines for hazardous materials if applicable.

Contact Information for Further Support

For any questions or concerns regarding the GRIP FRAME SCREW, CBOTTOM, please refer to the manufacturer's contact details provided with the product packaging or on the manufacturer's website.

By following these guidelines, you can ensure safe and effective use of the GRIP FRAME SCREW, CBOTTOM. Thank you for prioritizing safety and compliance.

Säkerhetsinstruktioner för GRIP FRAME SCREW, CBOTTOM RUGER

Introduktion

Tack för att du valt GRIP FRAME SCREW, CBOTTOM för din Rugerpistolsystem. Denna produkt är designad för att förbättra din skjutupplevelse och säkerhet. För att säkerställa en trygg och effektiv användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens anvisningar.
- Kontrollera produkten för synliga skador innan användning.
- Förvara produkten på en säker plats, oåtkomlig för barn.
- Rapportera eventuella skador eller brister i produkten till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddsglasögon och handskar vid installation och hantering av produkten.
- Undvik att använda produkten om du är trött eller under påverkan av alkohol eller droger.
- Se till att området där du arbetar är rent och fritt från hinder.
- Kontrollera att alla delar är korrekt monterade innan användning.
- Använd produkten endast med kompatibla Rugermodeller för att förhindra skador.

Instruktioner för installation och användning

1. Förberedelse

- Samla alla nödvändiga verktyg för installationen.
- Läs igenom alla instruktioner innan du påbörjar installationen.

2. Installation

- Ta bort den gamla skruven från greppramen.
- Rengör området där den nya skruven ska installeras.
- Placera den nya GRIP FRAME SCREW, CBOTTOM på plats.
- Använd ett lämpligt verktyg för att dra åt skruven, men undvik att överdriva åtdragningen.

3. Användning

- Kontrollera att skruven är ordentligt åtdragen innan du använder vapnet.
- Utför regelbundna inspektioner av skruven för att säkerställa att den förblir i gott skick.

Avfallshanteringsinstruktioner

- Kasta bort eventuella förpackningsmaterial på ett miljövänligt sätt.
- Om produkten är skadad eller inte längre används, följ lokala riktlinjer för avfallshantering.
- Undvik att slänga produkten i hushållsavfall för att förhindra miljöskador.

Kontaktinformation för vidare stöd

För frågor eller ytterligare information om säkerhet och användning av GRIP FRAME SCREW, CBOTTOM, vänligen kontakta en auktoriserad återförsäljare eller tillverkare. Se till att ha produktens serienummer tillgängligt för snabbare hjälp.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!