

EJECTOR ROD SPRING, BLUE

FITS: Bisley™ - Common Parts; New Model Blackhawk®; New Model Single-Six®; Super Blackhawk®, .44 Mag; Vaquero®



Attributes

- Name: EJECTOR ROD SPRING, BLUE
- Manufacturer: RUGER
- Product no.: 780012098
- Mfr. No.:
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.009kg
- Shipping height: 5mm
- Shipping width: 53mm
- Shipping length: 140mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Ejector Rod Spring Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för EJECTOR ROD SPRING, BLUE](#)

Ejector Rod Spring Safety Instructions

Introduction

Thank you for choosing the Ejector Rod Spring, Blue. This product is designed to fit various Ruger models, including the Bisley™, New Model Blackhawk®, New Model SingleSix®, Super Blackhawk®, .44 Mag, and Vaquero®. To ensure your safety and the proper functioning of your firearm, please read this safety instruction guide carefully.

General Safety Guidelines

- Always handle firearms with care and follow basic safety rules.
- Ensure that the Ejector Rod Spring is compatible with your firearm model before installation.
- Keep this product out of reach of children and unauthorized users.
- Regularly inspect the Ejector Rod Spring for wear or damage.
- In case of any malfunction, cease use immediately and consult a qualified gunsmith.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before installing or replacing the Ejector Rod Spring.
- Use appropriate tools and follow installation instructions carefully to avoid injury.
- Never attempt to modify the Ejector Rod Spring or any other firearm components.
- If you experience any issues during installation or usage, seek professional assistance.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a screwdriver and any other required equipment.

2. Installation Steps:

- Remove the existing Ejector Rod Spring from the firearm.
- Carefully install the new Ejector Rod Spring, ensuring it is seated correctly.
- Reassemble the firearm, following the manufacturer's guidelines.

3. Usage:

- Test the functionality of the Ejector Rod Spring by cycling the action of the firearm.
- Ensure that the ejector operates smoothly and without obstruction.

Disposal Instructions

- Dispose of any old or damaged Ejector Rod Springs in accordance with local regulations.
- Do not dispose of in regular household waste; consider recycling options if available.

Contact Information for Further Support

For any inquiries regarding the safety or performance of the Ejector Rod Spring, please consult your local dealer or a qualified gunsmith.

Säkerhetsinstruktioner för EJECTOR ROD SPRING, BLUE

Introduktion

Tack för att du valt EJECTOR ROD SPRING, BLUE. Denna produkt är designad för att förbättra prestanda och funktionalitet hos din Rugerrevolver. För att säkerställa säker användning och långvarig funktion, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Kontrollera alltid att produkten är i gott skick före användning.
- Använd produkten endast enligt tillverkarens anvisningar.
- Förvara produkten på en säker plats, utom räckhåll för barn och andra sårbara grupper.
- Rapportera alla osäkra produkter eller incidenter till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser genom EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddsglasögon och handskar vid installation och hantering av produkten.
- Kontrollera att fjädern är korrekt installerad innan användning för att undvika skador.
- Undvik att använda produkten om du upptäcker några skador eller defekter.
- Håll produkten borta från öppen eld eller extrem värme.
- Använd inte produkten i kombination med andra delar som inte är godkända av tillverkaren.

Instruktioner för installation och användning

1. Installation

- Ta bort den befintliga ejector rod spring från din Rugerrevolver.
- Kontrollera att området är rent och fritt från skräp.
- Installera den nya EJECTOR ROD SPRING, BLUE genom att följa tillverkarens specifikationer.
- Se till att fjädern är ordentligt på plats innan du återmonterar andra delar.

2. Användning

- Använd din Rugerrevolver enligt tillverkarens anvisningar.
- Utför regelbundet underhåll för att säkerställa att fjädern och andra delar fungerar korrekt.
- Vid tecken på slitage eller skada, byt ut fjädern omedelbart.

Avfallshanteringsinstruktioner

- Kasta inte produkten med hushållsavfall.
- Följ lokala bestämmelser för avfallshantering av metallprodukter.
- Om möjligt, återvinn produkten för att minska miljöpåverkan.

Kontaktinformation för ytterligare support

För frågor eller mer information om produkten, vänligen kontakta tillverkaren eller din återförsäljare. Se till att ha produktens modell och serienummer till hands för snabbare hjälp.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att använda produkten på rätt sätt bidrar du till din egen säkerhet och säkerheten för andra.