

Electric Fillet Knives - 110V Electric Corded Fillet Knife Set, 4 Blades

The 110V Bubba Electric Fillet Knife is designed by exceptional engineers to provide you with the best electric fillet knife for your success on the water. This Bubba Electric Fillet Knife is ergonomically crafted to fit your hands, and the iconic non-slip grip allows you to fillet fish with ease. Hours of testing and detailing have been put into creating an electric knife equipped with the most advanced technology. The uniquely designed ventilation is engineered for maximized motor and transmission output, providing you with the most efficient cut in the industry. Included are four different blade styles that reflect our renowned tapered flex and stiff fillet knives. The blade options are the following: 7" e-flex blade, 9" e-flex blade, 9' e-stiff blade and a 12" e-stiff blade. The perfect combination of two flexible blades and two stiff blades, allows you to fillet any size fish at any given time. All Bubba blades are constructed out of high carbon stainless-steel and finished with a titanium nitride coating. These premium materials make the blades extremely corrosion resistant and cause the meat to effortlessly fall off the knife. It features an 8' cord, a safety lock and trigger guard for ultimate usability. The electric fillet knife comes in our high-quality, all-weather carrying case, masterfully designed with removable internal components to simplify cleaning and storage. Ready to fillet any size fish with its variety of blades and advance technology, Bubba's engineers built your knife for life.

NO IMAGE
AVAILABLE

Attributes

- Name: 110V Electric Corded Fillet Knife Set, 4 Blades
- Manufacturer: BUBBA
- Product no.: EU1001356
- Mfr. No.: 1095704
- Color: Red
- Delivery weight: 1.814kg
- Shipping height: 94mm
- Shipping width: 159mm
- Shipping length: 432mm
- UPC: 661120416111

Table of Contents

- [Startpage](#)
- [English: BUBBA Electric Fillet Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv](#)

BUBBA Electric Fillet Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA Electric Fillet Knife. This product is designed to provide you with a safe and efficient way to fillet fish. Please read this safety instruction guide carefully to ensure safe use and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always ensure that the knife is used for its intended purpose.
- Keep the knife out of reach of children and vulnerable individuals.
- Regularly check for any damage to the knife or its components before use.
- If you notice any unusual sounds, smells, or performance issues, stop using the knife immediately and seek assistance.
- Always unplug the knife when not in use or when changing blades.
- Ensure that the knife is used in a dry environment to avoid electrical hazards.
- Follow all local regulations regarding the disposal of electrical appliances.

Specific Safety Precautions for Use

- **Blade Handling:**
 - Always handle blades with care. The blades are sharp and can cause injury.
 - Use the blade guard when the knife is not in use to protect the blades and yourself.
- **Electrical Safety:**
 - Ensure the knife is plugged into a properly grounded outlet.
 - Do not use the knife with an extension cord unless necessary. If so, ensure the cord is rated for the knife's power requirements.
- **Operational Safety:**
 - Use the knife on a stable surface to prevent accidents.
 - Keep your hands and other body parts away from the blade during operation.
 - Do not attempt to fillet fish while the knife is still plugged in if you are not ready to use it.
- **Cleaning and Maintenance:**
 - Always unplug the knife before cleaning.
 - Clean the blades and handle with a damp cloth; do not immerse the knife in water.
 - Store the knife in a safe place when not in use, preferably in its carrying case.

Instructions for Installation and Usage

1. Setup:

- Unpack the knife and all included accessories from the carrying case.
- Inspect the knife and blades for any signs of damage or defects.
- Choose the appropriate blade for the type of fish you will be filleting.

2. Blade Installation:

- Ensure the knife is unplugged.
- Press the blade release button to remove the existing blade.
- Align the new blade with the blade holder and push until it clicks into place.
- Ensure the blade is securely attached before plugging in the knife.

3. Filleting Fish:

- Plug the knife into a grounded outlet.
- Hold the knife firmly by the handle, ensuring a nonslip grip.
- Position the fish on a stable cutting surface.
- Begin filleting by gently guiding the blade along the fish's spine, applying light pressure.
- Use smooth, even strokes to achieve clean cuts.

4. PostUse:

- Unplug the knife immediately after use.
- Remove the blade using the blade release button and clean as instructed.
- Store the knife and blades in the carrying case.

Disposal Instructions

- When disposing of the BUBBA Electric Fillet Knife, follow local regulations for electrical waste.
- Remove the blades and dispose of them separately as they are sharp and can cause injury.
- Ensure the knife is rendered unusable before disposal to prevent accidents.

Contact Information for Further Support

For any questions or concerns regarding the BUBBA Electric Fillet Knife, please refer to the manufacturer's contact information provided on the product packaging or website.

By following these safety instructions, you can ensure a safe and enjoyable experience using the BUBBA Electric Fillet Knife. Thank you for your attention to safety!

Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv

Introduktion

Tack för att du har valt BUBBA Elektrisk Filékniv. Denna produkt är utformad för att ge dig en säker och effektiv upplevelse när du filéar fisk. För att säkerställa din säkerhet och produktens prestanda, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd produkten endast för avsett syfte, dvs. filéa fisk.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera alltid att kniven är i gott skick innan användning. Om du upptäcker skador, använd inte produkten.
- Följ alltid tillverkarens instruktioner för användning och underhåll.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven på en stabil och säker yta.
- Håll alltid kniven i ett fast grepp med båda händerna när du använder den.
- Använd skyddshandskar om det behövs för att undvika skador.
- Stäng av kniven när den inte används.
- Använd inte kniven om sladden är skadad eller trasig.
- Håll sladden borta från värme, olja och vassa kanter.
- Använd inte kniven i vatten eller på blöta ytor för att undvika elektriska stötar.

Instruktioner för installation och användning

1. Installation:

- Placera kniven på en torr och stabil yta.
- Anslut sladden till ett 110V uttag som är korrekt installerat och jordad.

2. Användning:

- Välj det blad som passar bäst för den typ av fisk du ska filéa.
- Sätt fast bladet på kniven enligt tillverkarens instruktioner.
- Håll kniven med ett fast grepp och placera spetsen av bladet vid fisken.
- Tryck på avtryckaren för att aktivera kniven och börja filéa försiktigt.
- När du är klar, stäng av kniven och koppla ur den från strömkällan.

Avfallsinstruktioner

- Kassera eventuella trasiga eller oanvändbara delar enligt lokala avfallsbestämmelser.
- Återvinn förpackningsmaterial när det är möjligt.

Kontaktinformation för ytterligare stöd

För frågor eller mer information om säkerhet och användning, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes.

Tack för att du följer dessa säkerhetsinstruktioner. Vi önskar dig en säker och framgångsrik upplevelse med din BUBBA Elektriska Filékniv!