

Electric Fillet Knives - Lithium Ion Cordless Fillet Knife Set, 4 Blades

This Lithium Ion Cordless Electric Fillet Knife is ergonomically designed to fit perfectly in your hand. We've stayed true to our roots by incorporating the iconic non-slip grip handle which allows you to cut through fish like butter. Our lithium ion battery has the longest run time of any electric fillet knife on the market so you can stack fillets until you're out of fish. The engineered ventilation has been designed to maximize motor transmission output giving you an incredible amount of torque. Included are four different blade styles — 7" E-FLEX, 9" E-FLEX, 9" E-STIFF and 12" E-STIFF — that reflect our legendary tapered flex and stiff fillet knives. These blades are constructed out of high carbon stainless-steel and coated with titanium nitride making them extremely corrosion resistant. We've also incorporated a safety lock and trigger guard for ultimate security. The electric fillet knife comes in a premium EVA molded carrying case which allows you to break apart the storage units for easy cleaning. This knife contains a secondary replacement battery, charging cord, and all batteries contain a battery life indicator so you can rest assured that you'll never run out of juice. This electric fillet knife is exactly what you've been looking for and it's ready to fillet any fish any time.

NO IMAGE
AVAILABLE

Attributes

- Name: Lithium Ion Cordless Fillet Knife Set, 4 Blades
- Manufacturer: BUBBA
- Product no.: EU1001357
- Mfr. No.: 1095705
- Color: Red
- Delivery weight: 1.86kg
- Shipping height: 94mm
- Shipping width: 159mm
- Shipping length: 432mm
- UPC: 661120416128

Table of Contents

- [Startpage](#)
- [English: BUBBA Electric Fillet Knife Safety Instructions](#)
- [Svenska: Säkerhetsanvisningar för BUBBA Elektrisk Filékniv](#)

BUBBA Electric Fillet Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA Electric Fillet Knife Set. This product is designed to provide a safe and efficient way to fillet fish. Please read and follow these safety instructions carefully to ensure safe use and avoid potential hazards.

General Safety Guidelines

- Always ensure that the knife is turned off and unplugged when not in use.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose; do not use it for cutting materials other than fish.
- Regularly inspect the knife and blades for any signs of damage or wear.
- In the event of a malfunction or damage, discontinue use immediately and seek professional assistance.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the work area is clean and free from clutter to prevent accidents.
- Always use the knife on a stable surface to avoid slipping.
- Use the safety lock feature when the knife is not in use.
- Wear protective gloves if necessary to avoid cuts while handling the knife or fish.
- Be aware of your surroundings and ensure that no one is within reach of the blade while in use.
- Do not attempt to change blades while the knife is plugged in or turned on.

Instructions for Installation and Usage

1. Charging the Knife:

- Before first use, charge the lithiumion battery using the provided charging cord.
- Ensure the knife is turned off during charging.
- The battery life indicator will show when charging is complete.

2. Changing Blades:

- Ensure the knife is turned off and unplugged before changing blades.
- Press the release button to detach the current blade.
- Select the desired blade and insert it until it clicks into place.

3. Using the Knife:

- Hold the knife with a firm grip on the nonslip handle.
- Position the fish securely on a cutting board.
- Turn on the knife using the ergonomic trigger.
- Use smooth, controlled motions to fillet the fish.
- Turn off the knife immediately after use and unplug it.

4. Cleaning the Knife:

- Allow the knife to cool down before cleaning.
- Detach the blade and wash it separately with warm, soapy water.
- Wipe the handle and body of the knife with a damp cloth.
- Dry all parts thoroughly before reassembling.

Disposal Instructions

- Dispose of the knife and its components according to local regulations.
- Do not dispose of the lithiumion battery in regular waste. Follow local guidelines for battery disposal.
- If the knife is damaged beyond repair, ensure it is safely disposed of to prevent accidents.

Contact Information for Further Support

For any inquiries or concerns regarding the safety and use of the BUBBA Electric Fillet Knife, please refer to the manufacturer's contact details provided in the product packaging.

By following these safety instructions, you can enjoy using your BUBBA Electric Fillet Knife Set with confidence. Thank you for your attention to safety!

Säkerhetsanvisningar för BUBBA Elektrisk Filékniv

Introduktion

Tack för att du valt BUBBA Elektrisk Filékniv. Denna produkt är designad för att ge en säker och effektiv filéupplevelse. För att säkerställa säker användning och långvarig prestanda är det viktigt att följa dessa säkerhetsanvisningar noggrant.

Allmänna säkerhetsriktlinjer

- Läs alltid bruksanvisningen noggrant innan du använder produkten.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Använd endast produkten för dess avsedda syfte.
- Kontrollera att produkten är i gott skick innan användning.
- Rapportera eventuella skador eller defekter till tillverkaren.
- Håll arbetsområdet rent och fritt från hinder för att undvika olyckor.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar knivbladen.
- Se till att kniven är avstängd innan du byter blad.
- Använd inte kniven om den är skadad eller om batteriet är defekt.
- Håll fingrar och andra kroppsdelar borta från bladet under användning.
- Låt aldrig kniven vara utan uppsikt när den är påslagen.
- Använd kniven på en stabil och plan yta.
- Undvik att använda kniven i fuktiga miljöer för att förhindra elektriska stötar.

Instruktioner för installation och användning

1. Installation av blad:

- Stäng av kniven.
- Ta bort det befintliga bladet genom att trycka på frigöringsknappen.
- Välj önskat blad och sätt in det tills du hör ett klick.

2. Laddning av batteri:

- Anslut laddningskabeln till kniven och ett vägguttag.
- Kontrollera att batterilivslängdsindikatorn visar att batteriet laddas.
- Låt batteriet laddas helt innan första användning.

3. Användning av kniven:

- Sätt på kniven genom att trycka på avtryckaren.
- Håll kniven i ett fast grepp och för den mot fisken med en jämn rörelse.
- Stäng av kniven efter användning.

Avfallsanvisningar

- Kasta inte produkten eller dess komponenter i hushållsavfall.
- Följ lokala riktlinjer för avfallshantering och återvinning av elektriska apparater.
- Ta bort batteriet innan du kasserar produkten och återvinn det separat.

Kontaktinformation för ytterligare stöd

För frågor eller support, vänligen kontakta tillverkaren eller återförsäljaren där du köpte produkten. Kontrollera även EU:s Safety Gateplattform för eventuella återkallelser och säkerhetsuppdateringar.

Avslutning

Genom att följa dessa säkerhetsanvisningar kan du säkerställa en säker och effektiv användning av din BUBBA Elektriska Filékniv. Tack för att du väljer vår produkt!