

Electric Fillet Knives - BUBBA Electric Fillet Knife Blade, Thin Profile, 7"

This 7" E-FLEX replacement Blade fits both our 110V Electric Fillet Knife and Cordless Lithium Ion Electric Fillet Knife. It's made of a High Carbon Stainless Steel and chemically bonded with a ti-nitride coating to be extremely corrosion resistant. The 7" blade serrated edge and apposing bidirectional blades make filleting medium to large size fish effortlessly.

NO IMAGE
AVAILABLE

Attributes

- Name: BUBBA Electric Fillet Knife Blade, Thin Profile, 7"
- Manufacturer: BUBBA
- Product no.: EU1001358
- Mfr. No.: 1099591
- Color: Silver
- Delivery weight: 0.113kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 330mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: BUBBA Electric Fillet Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv](#)

BUBBA Electric Fillet Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA Electric Fillet Knife. This guide provides essential safety information and instructions to ensure safe and effective use of your knife. Please read this manual thoroughly before using the product.

General Safety Guidelines

- Always ensure the knife is turned off and unplugged when not in use.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose—filleting fish.
- Inspect the knife for any damage before each use. Do not use if damaged.
- Ensure that your hands and the working area are dry to prevent slips.
- Always cut away from your body and keep your fingers clear of the blade.
- Do not attempt to disassemble or modify the knife.
- Store the knife in a safe location, preferably in its protective case.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - The knife has sharp blades that can cause cuts or injuries.
 - Electrical components pose a risk of electric shock if handled improperly.
- **Avoiding Hazards:**
 - Always use the knife on a stable surface.
 - Do not use the knife while distracted or under the influence of substances that impair judgment.
 - Do not immerse the knife in water or other liquids.
 - Ensure the power cord is not damaged and is kept away from hot surfaces.

Instructions for Installation and Usage

- **Installation:**
 - Ensure the knife is unplugged before installation.
 - Attach the 7" EFLEX replacement blade securely to the knife by following the manufacturer's instructions included in the packaging.
- **Usage:**
 - Plug the knife into a suitable power outlet.
 - Turn on the knife using the designated power switch.
 - Hold the knife firmly with one hand on the handle and the other guiding the fish.
 - Begin filleting by placing the blade at the fish's back and cutting down towards the belly.
 - Use smooth, even strokes to achieve clean cuts.
 - When finished, turn off the knife and unplug it from the outlet.

Disposal Instructions

- Dispose of the knife and any packaging materials in accordance with local regulations.
- Do not dispose of the knife in regular household waste. Check for local electronic waste recycling programs.

Contact Information for Further Support

For any safety inquiries or support regarding the BUBBA Electric Fillet Knife, please refer to the product packaging or your retailer for guidance.

Thank you for following these safety instructions to ensure a safe and enjoyable experience with your BUBBA Electric Fillet Knife.

Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv

Introduktion

Tack för att du valt BUBBA Elektrisk Filékniv. Denna produkt är designad för att underlätta filéering av fisk. För att säkerställa en säker och effektiv användning av produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- **Produktsäkerhet:** Använd alltid produkten enligt tillverkarens anvisningar för att undvika skador.
- **Återkallelser:** Håll dig informerad om eventuella produktåterkallelser via EU:s Safety Gateplattform.
- **Online shopping:** Se till att köpa produkten från auktoriserade återförsäljare för att säkerställa att du får en säker och äkta produkt.
- **Särskilt konsumentskydd:** Var extra försiktig om produkten används av barn eller andra sårbara grupper.
- **EUKontaktpunkt:** För frågor om säkerhet, se till att ha kontaktinformation tillgänglig för den lokala EUkontaktpunkten.
- **Snabba varningar:** Var medveten om att det finns ett system för snabba uppdateringar om osäkra produkter.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar bladet för att undvika skador.
- Håll produkten utom räckhåll för barn och husdjur.
- Undvik att använda filékniven i närheten av vatten för att förhindra elektriska stötar.
- Kontrollera alltid att kniven är avstängd när du inte använder den.
- Använd endast kniven för dess avsedda syfte filéering av fisk.

Instruktioner för installation och användning

• Installation:

1. Kontrollera att alla delar är intakta och inga skador finns.
2. Fäst bladet på handtaget enligt instruktionerna i manualen.
3. Anslut kniven till ett lämpligt eluttag (110V).

• Användning:

1. Slå på kniven med strömbrytaren.
2. Håll kniven stadigt med en hand och fisken med den andra.
3. Filéera fisken med en lång, jämn rörelse, vilket gör att det tandade bladet kan skära effektivt.
4. Stäng av kniven när du är klar och koppla ur den från eluttaget.
5. Rengör kniven noggrant efter användning och förvara den på en säker plats.

Avfallsinstruktioner

- Kassera trasiga eller slitna delar av produkten enligt lokala avfallsföreskrifter.
- Återvinn material när det är möjligt, särskilt metallkomponenter, för att minska miljöpåverkan.

Kontaktinformation för vidare support

För frågor om säkerhet eller produktinformation, vänligen kontakta din lokala återförsäljare eller sök hjälp via de officiella kanalerna i EU.