

Electric Fillet Knives - Electric Fillet Knife Blade, Thin Profile, 9"

This 9" E-FLEX replacement Blade fits both our 110V Electric Fillet Knife and Cordless Lithium Ion Electric Fillet Knife. It's made of a High Carbon Stainless Steel and chemically bonded with a ti-nitride coating to be extremely corrosion resistant. The 9" blade serrated edge and apposing bidirectional blades make filleting medium to large size fish effortlessly.

NO IMAGE
AVAILABLE

Attributes

- Name: Electric Fillet Knife Blade, Thin Profile, 9"
- Manufacturer: BUBBA
- Product no.: EU1001359
- Mfr. No.: 1099592
- Color: Silver
- Delivery weight: 0.113kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 381mm
- UPC: 661120418832

Table of Contents

- [Startpage](#)
- [English: BUBBA Electric Fillet Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv](#)

BUBBA Electric Fillet Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA Electric Fillet Knife with a 9" EFLEX replacement blade. This guide provides essential safety instructions to ensure the safe use and maintenance of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure that the knife is used only for its intended purpose: filleting fish.
- Always keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife for any damage before use. Do not use if damaged.
- Use the knife in a welllit area to avoid accidents.
- Always handle the knife with care, as the blade is sharp and can cause injury.
- Store the knife in a safe place when not in use, preferably in a protective sheath or case.
- Follow all local regulations regarding the use of electric knives.

Specific Safety Precautions for Use

- Before plugging in the knife, ensure that your hands are dry to prevent electric shock.
- Do not immerse the electric knife in water or any other liquids.
- Avoid using the knife near flammable materials or in wet conditions.
- Do not attempt to disassemble or repair the knife yourself. Contact a qualified technician for repairs.
- Always unplug the knife when not in use or before cleaning.
- Use caution when changing blades to avoid cuts or injuries.

Instructions for Installation and Usage

1. Installation:

- Ensure that the knife is unplugged.
- If replacing the blade, press the release button and carefully remove the old blade.
- Align the new blade with the slots and push it into place until it clicks securely.
- Ensure that the blade is firmly attached before plugging in the knife.

2. Usage:

- Plug the knife into a compatible electrical outlet.
- Hold the knife firmly by the handle, ensuring a secure grip.
- Position the blade at the desired angle to the fish and apply gentle pressure to begin filleting.
- Use smooth, consistent motions to achieve even cuts.
- If the knife becomes difficult to operate, unplug it immediately and check for any obstructions or damage.

3. Cleaning:

- After use, unplug the knife and allow it to cool.
- Clean the blade with warm, soapy water and a soft cloth. Do not immerse the knife in water.
- Dry the blade thoroughly before storing.
- Avoid using abrasive cleaners or scrubbers that may damage the blade.

Disposal Instructions

- Dispose of the knife responsibly in accordance with local regulations.
- If the knife is no longer usable, ensure that the blade is securely covered to prevent accidental injury during disposal.
- Consider recycling options for the materials if available in your area.

Contact Information for Further Support

For any safety inquiries or further assistance regarding your BUBBA Electric Fillet Knife, please reach out to the designated EUbased contact point provided with your product packaging.

Thank you for your attention to these safety instructions. Enjoy using your BUBBA Electric Fillet Knife responsibly and safely!

Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv

Introduktion

Tack för att du valt BUBBA Elektrisk Filékniv. Denna guide innehåller viktiga säkerhetsinstruktioner och riktlinjer för att säkerställa en säker och effektiv användning av produkten. Vänligen läs igenom dessa instruktioner noggrant innan du använder kniven.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna för att minimera risker.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera alltid att kniven är i gott skick innan användning. Om du upptäcker några skador, använd inte produkten.
- Använd inte kniven i närheten av vatten eller andra vätskor för att undvika elektriska stötar.
- Se till att kniven är avstängd och urkopplad när den inte används, samt vid byte av blad.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar det vassa bladet för att undvika skador.
- Håll fingrarna borta från bladets kant under användning.
- Använd kniven på en stabil yta för att förhindra att den glider eller faller.
- Filéera endast medelstora till stora fiskar som produkten är avsedd för.
- Följ alltid tillverkarens instruktioner för hur du byter blad på kniven.

Instruktioner för installation och användning

1. Installera bladet:

- Se till att kniven är avstängd och urkopplad.
- Ta bort det gamla bladet genom att trycka på frigöringsknappen.
- Sätt in det nya bladet tills det klickar på plats.

2. Användning av kniven:

- Anslut kniven till eluttaget.
- Slå på kniven med strömbrytaren.
- Håll kniven i en vinkel mot fisken och börja filéera med en jämn rörelse.
- Stäng av kniven och koppla ur den efter användning.

Avfallshanteringsinstruktioner

- Kassera slitna eller skadade blad på ett säkert sätt för att undvika skador på andra.
- Återvinn kniven och dess komponenter i enlighet med lokala avfallsbestämmelser.
- Kontrollera alltid lokala riktlinjer för korrekt avfallshantering.

Kontaktinformation för vidare support

För eventuella frågor eller säkerhetsrelaterade ärenden, vänligen kontakta tillverkaren eller din lokala återförsäljare. Se till att ha produktens modellnummer och inköpsinformation tillgänglig.

Rapportera osäkra produkter

Om du upptäcker att produkten är osäker eller har orsakat en olycka, rapportera detta omedelbart till de lokala myndigheterna. Kontrollera även EU:s Safety Gateplattform för uppdateringar om eventuella återkallelser.

Tack för att du valt BUBBA Elektrisk Filékniv. Vi önskar dig en säker och njutbar upplevelse!