

## Electric Fillet Knives - Electric Fillet Knife Blade, 12"

This 12" E-STIFF replacement Blade fits both our 110V Electric Fillet Knife and Cordless Lithium Ion Electric Fillet Knife. It's made of a High Carbon Stainless Steel and chemically bonded with a ti-nitride coating to be extremely corrosion resistant. The 12" blade serrated edge and apposing bidirectional blades make filleting medium to large size fish effortlessly.

NO IMAGE  
AVAILABLE

### Attributes

- Name: Electric Fillet Knife Blade, 12"
- Manufacturer: BUBBA
- Product no.: EU1001361
- Mfr. No.: 1099594
- Color: Silver
- Delivery weight: 0.113kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 457mm
- UPC: 661120418856

# Table of Contents

- [Startpage](#)
- [English: BUBBA Electric Fillet Knife Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv](#)

# BUBBA Electric Fillet Knife Safety Instruction Guide

## Introduction

Thank you for choosing the BUBBA Electric Fillet Knife. This guide provides important safety instructions to ensure the safe use of your 12" ESTIFF replacement blade. Please read this guide carefully to avoid any potential hazards and to ensure a safe and enjoyable experience while using the product.

## General Safety Guidelines

- Always ensure that the knife is unplugged when not in use or when changing blades.
- Keep the knife out of reach of children and vulnerable individuals.
- Avoid using the knife in wet conditions or with wet hands to prevent electric shock.
- Regularly inspect the knife for any signs of damage or wear before use.
- Do not use the knife for any purpose other than filleting fish.
- Follow all local regulations regarding the use of electric knives.

## Specific Safety Precautions for Use

- **Electrical Safety:**
  - Ensure that the knife is connected to a properly grounded outlet.
  - Do not use an extension cord that is damaged or not rated for the power of the knife.
- **Blade Safety:**
  - Always handle the blade with care. The serrated edge is sharp and can cause injury.
  - Use protective gloves when changing or cleaning the blade.
- **Operating Safety:**
  - Always cut away from your body to avoid accidental injury.
  - Do not force the knife through tough materials; let the blade do the work.
- **Maintenance Safety:**
  - Unplug the knife before cleaning or performing maintenance.
  - Store the knife in a safe, dry place when not in use to prevent accidents.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure the knife is unplugged.
- To attach the blade, align the blade with the slot on the knife handle and push until it clicks into place.
- To remove the blade, press the release button and pull the blade out.

### 2. Usage:

- Plug the knife into a suitable outlet.
- Hold the knife firmly with one hand on the handle and the other guiding the fish.

- Start the knife by pressing the power button and begin filleting by moving the blade smoothly along the fish.
- If the knife becomes difficult to operate, unplug it immediately and check for obstructions.

### 3. **PostUsage:**

- After use, unplug the knife and allow it to cool down.
- Clean the blade with warm, soapy water and dry thoroughly.
- Store the knife in a safe location, away from children.

## **Disposal Instructions**

- Dispose of the knife in accordance with local regulations concerning electrical appliances.
- Remove the blade and dispose of it separately, ensuring it is wrapped securely to prevent injury.
- Do not dispose of the knife in regular household waste; check for local ewaste recycling programs.

## **Contact Information for Further Support**

For any safety inquiries or further assistance, please contact the manufacturer directly. Ensure to have your product information ready for a quicker response.

## **Conclusion**

Following these safety instructions will help ensure your safe and effective use of the BUBBA Electric Fillet Knife. Always prioritize safety and handle the knife with care. Enjoy your filleting experience!

# Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv

## Introduktion

Tack för att du valt BUBBA Elektrisk Filékniv. Denna guide innehåller viktiga säkerhetsinstruktioner och riktlinjer för att säkerställa säker och effektiv användning av produkten. Vänligen läs igenom och följ dessa instruktioner noggrant.

## Allmänna säkerhetsriktlinjer

- Använd produkten endast för dess avsedda syfte, vilket är att filéa fisk.
- Håll produkten utom räckhåll för barn och använd den endast av vuxna.
- Kontrollera alltid att kniven är i gott skick innan användning. Byt ut blad som är slitna eller skadade.
- Använd alltid kniven på en stabil och säker yta för att undvika olyckor.
- Var försiktig med knivens egg och sågtandade blad för att förhindra skador.
- Vid eventuella olyckor, rapportera omedelbart till de lokala myndigheterna.

## Specifika säkerhetsåtgärder vid användning

- Använd skyddshandskar för att skydda händerna när du hanterar kniven och bladet.
- Undvik att använda kniven i närheten av vatten eller andra vätskor som kan orsaka halka.
- Stäng av kniven när den inte används och koppla ur den från strömkällan.
- Använd alltid kniven med båda händerna för bättre kontroll och stabilitet.
- Undvik att nå in i knivens arbetsområde medan den är påslagen.

## Instruktioner för installation och användning

### 1. Installation av blad:

- Se till att kniven är avstängd och urkopplad.
- Ta bort det gamla bladet genom att trycka på frigöringsknappen.
- Sätt i det nya 12" ESTIFF ersättningsbladet tills det klickar på plats.

### 2. Användning:

- Koppla in kniven i ett lämpligt eluttag.
- Håll kniven med ena handen och fisken med den andra.
- Starta kniven och börja filéa fisken i en jämn, kontrollerad rörelse.
- Stäng av kniven när du är klar och koppla ur den från strömkällan.

## Avfallshantering

- Avfallshantering av produkten och dess delar ska ske enligt lokala riktlinjer för avfallshantering.
- Släng inte elektriska apparater i hushållssoporna. Kontakta din lokala avfallshanteringsmyndighet för korrekt avfallshantering.

## Kontaktinformation för vidare support

För frågor eller support angående säkerhet och användning av BUBBA Elektrisk Filékniv, vänligen kontakta en auktoriserad återförsäljare eller besök vår officiella webbplats för mer information.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din BUBBA

Elektrisk Filékniv. Tack för att du bidrar till en säker användning av våra produkter!