

MICROSTREAM POCKET LIGHT - MICROSTREAM LED FLASHLIGHT

Powerful & Nearly Indestructible

MICROSTREAM POCKET LIGHT USB Rechargeable, Bright Small LED Flashlight

Ultra-compact, this personal light, which fits in the palm of your hand or comfortably in your pocket, provides unparalleled performance for its size. SPECIFICATIONS: High and low modes (double tap the tail switch to change modes): High: 250 lumens; 68m beam; runs 1.5 hours Low: 50 lumens; 31m beam; runs 3.5 hours Lithium-ion battery charges in-product in 4 hours Multi-function push-button tail switch with charge indicator: Red - charging Green - fully charged Durable, anodized machined aluminum construction; scratch-resistant polycarbonate lens Metal sleeve protects charge port; slide sleeve forward to reveal charge port Removable pocket clip also clips onto brim of hat for hands free use IPX4 water-resistant; 1m impact resistance tested Includes USB cord and high-strength lanyard Ultra-compact design fits in the palm of your hand, comfortably fits in your pocket 3.87 in (9.83 cm); 1.2 oz (34.1 g) Limited lifetime warranty



Attributes

- Name: MICROSTREAM LED FLASHLIGHT
- Manufacturer: Streamlight
- Product no.: 100005923
- Mfr. No.: 66318
- Battery: AAA
- Color: Black
- Lumens: 35
- Style: LED,Handheld
- Delivery weight: 0.023kg
- Shipping height: 20mm
- Shipping width: 109mm
- Shipping length: 173mm
- UPC: 080926663183

Item details

This product contains a battery.

Table of Contents

- [Startpage](#)
- [English: MICROSTREAM POCKET LIGHT Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Streamlight MICROSTREAM LED Ficklampa](#)

MICROSTREAM POCKET LIGHT Safety Instructions

Introduction

Thank you for choosing the MICROSTREAM POCKET LIGHT. This guide provides important safety instructions and information to ensure the safe and effective use of your flashlight. Please read this document carefully before use.

General Safety Guidelines

- Ensure that the flashlight is used only for its intended purpose.
- Keep out of reach of children and vulnerable individuals.
- Inspect the flashlight regularly for any signs of damage or wear.
- Do not use the flashlight if it is damaged or malfunctioning.
- Avoid exposing the flashlight to extreme temperatures, moisture, or hazardous environments.
- Do not attempt to disassemble or modify the flashlight.

Specific Safety Precautions for Use

- **Battery Safety:**
 - Use only the recommended lithiumion battery for charging.
 - Do not expose the battery to fire or high temperatures.
 - Charge the flashlight using the included USB cord only.
- **Charging Instructions:**
 - Charge the flashlight in a wellventilated area.
 - Do not leave the flashlight unattended while charging.
 - Disconnect the charger once the flashlight is fully charged.
- **Water Resistance:**
 - The flashlight is rated IPX4 waterresistant; avoid submerging it in water.
- **Impact Resistance:**
 - The flashlight has been tested for 1m impact resistance; handle with care to avoid drops from greater heights.

Instructions for Installation and Usage

1. Charging the Flashlight:

- Connect the USB cord to the charge port located under the metal sleeve.
- Plug the other end of the USB cord into a power source.
- The charge indicator will show red while charging and green when fully charged.

2. Using the Flashlight:

- To turn on the flashlight, press the pushbutton tail switch.
- For high mode (250 lumens), double tap the tail switch.
- For low mode (50 lumens), double tap the tail switch again.
- To turn off, press the tail switch once.

3. Attaching the Pocket Clip:

- The removable pocket clip can be attached to the flashlight for easy carrying.
- It can also be clipped onto the brim of a hat for handsfree use.

4. Storing the Flashlight:

- Store the flashlight in a cool, dry place when not in use.
- Ensure that the flashlight is turned off to conserve battery life.

Disposal Instructions

- Dispose of the flashlight and its components in accordance with local regulations.
- Do not dispose of the flashlight in regular household waste.
- Recycle the lithiumion battery at designated recycling centers.

Contact Information for Further Support

For any safety inquiries or concerns regarding the MICROSTREAM POCKET LIGHT, please refer to the manufacturer's contact information provided with your product.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of your MICROSTREAM POCKET LIGHT. For further information or updates, please stay informed about product recalls and safety notices through the EU's Safety Gate platform. Thank you for prioritizing safety.

Säkerhetsinstruktioner för Streamlight MICROSTREAM LED Ficklampa

Introduktion

Tack för att du valt Streamlight MICROSTREAM LED Ficklampa. Denna lampa är designad för att ge högkvalitativ belysning i en kompakt och bärbar form. För att säkerställa en säker och effektiv användning av produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd endast produkten enligt tillverkarens anvisningar.
- Kontrollera lampan regelbundet för skador. Använd inte lampan om den är skadad.
- Förvara lampan på en torr och säker plats, utom räckhåll för barn.
- Använd inte lampan under extrema väderförhållanden om den inte är avsedd för sådana förhållanden.
- Rapportera alltid eventuella skador eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd lampan endast för sitt avsedda syfte, som bärbar belysning.
- Undvik att rikta ljuset mot ögonen, då det kan orsaka tillfällig blindhet eller skada.
- Använd lampan med försiktighet i trånga utrymmen för att undvika att den tappas eller skadas.
- Se till att lampan är avstängd när den inte används för att förlänga batteriets livslängd.
- Använd endast rekommenderade batterier (3V CR123A litiumbatterier) för att undvika skador på lampan.

Instruktioner för installation och användning

1. Batteribyte:

- Skruva av lampans bakre del för att komma åt batterifacket.
- Ta bort det gamla batteriet och sätt i ett nytt 3V CR123A litiumbatteri, se till att plus och minuspolerna är korrekt riktade.
- Skruva tillbaka lampans bakre del ordentligt.

2. Användning:

- Tryck på svansknappen för att slå på eller av lampan.
- Välj mellan de tre olika driftslägena (hög/strobe/låg) genom att trycka på knappen flera gånger.
- Hög: 750 lumen för maximal belysning.
- Låg: 35 lumen för längre driftstid.
- Strobe: För att desorientera eller signalera.

3. Underhåll:

- Rengör lampan med en mjuk, torr trasa för att ta bort smuts och skräp.
- Inspektera Oringen och glaslinsen för skador och byt ut dem vid behov.

Avfallshanteringsinstruktioner

- Kasta inte lampan eller dess delar i hushållsavfallet.
- Följ lokala regler och riktlinjer för avfallshantering av elektriska och elektroniska produkter.
- Återvinn batterier enligt lokala bestämmelser för att skydda miljön.

Kontaktinformation för vidare support

För ytterligare information eller support, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes. Se till att ha produktens modellnummer och serienummer tillgängligt för snabbare hjälp.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en säker och effektiv användning av din Streamlight MICROSTREAM LED Ficklampa. Tack för att du bidrar till en säker användning av produkter!