

GAME CAMERA MICRO SD CARDS - DELKIN DEVICES CLASS 10 MICRO SD CARD 32GB

[Optics & Mounting](#) > [Action Cameras](#) > [Accessories](#)

Delkin microSD cards aren't just for tablets and phones anymore; the UHS-I enabled microSD cards are designed specifically for demanding jobs like recording 4K video, continuous shooting and time-lapse photography at short intervals, and quick transfers to your computer. With read speeds surpassing 56MB/s and write speeds up to 40MB/s, you can swap these cards between your action camera, smart phone, and tablet, or slide the card into the included SD adapter and use it as a full sized SD card in your camera or any other SD compatible device. 16 and 32 GB Data Storage Capacity Max. UHS-I Read Speed: 56MB/s Min. UHS-I Write Speed: 40MB/s Max Class 10 Read Speed: 22MB/s Min Class 10 Write Speed: 20MB/s microSD to SD Adapter Included



Attributes

- Name: [DELKIN DEVICES CLASS 10 MICRO SD CARD 32GB](#)
- Manufacturer: [DELKIN DEVICES](#)
- Product no.: 100015392
- Mfr. No.: DDMSD50032GB
- Size: 32 GB
- Delivery weight: 0.045kg
- Shipping height: 8mm
- Shipping width: 79mm
- Shipping length: 155mm
- UPC: 750324102583

Table of Contents

- [Startpage](#)
- [GAME CAMERA MICRO SD CARDS DELKIN DEVICES CLASS 10 MICRO SD CARD 32GB Safety Instruction Guide](#)
- [About Us](#)

GAME CAMERA MICRO SD CARDS DELKIN DEVICES

CLASS 10 MICRO SD CARD 32GB Safety

Instruction Guide

Introduction

Thank you for choosing the Delkin Devices Class 10 Micro SD Card (32GB). This guide provides important safety instructions and guidelines to ensure the safe and effective use of your microSD card. Please read this manual carefully before using the product.

General Safety Guidelines

- Ensure that the microSD card is used in compatible devices only.
- Keep the microSD card away from moisture, extreme temperatures, and direct sunlight.
- Do not expose the microSD card to physical shock or pressure.
- Handle the microSD card with care to avoid damage to the card or your devices.
- Store the microSD card in its protective case when not in use.

Specific Safety Precautions for Use

- Avoid using the microSD card in devices that do not support UHSI technology.
- Do not remove the microSD card from the device while data is being written or read, as this may cause data loss or corruption.
- If you notice any physical damage to the microSD card, discontinue use immediately and replace it.
- Keep the microSD card out of reach of children to prevent accidental swallowing or injury.

Instructions for Installation and Usage

1. Inserting the microSD Card:

- Ensure that your device is powered off before inserting the microSD card.
- Locate the microSD card slot on your device.
- Gently slide the microSD card into the slot until it clicks into place.

2. Using the microSD Card:

- Turn on your device to recognize the microSD card.
- Follow the device instructions to format the card if necessary.
- Use the microSD card for storing photos, videos, and other data as per your device's capabilities.

3. Transferring Data:

- Use a compatible card reader or the SD adapter included to transfer data between your microSD card and computer.
- Ensure that data transfer is complete before removing the card from the device.

4. Removing the microSD Card:

- Always safely eject the microSD card from your device before removal to prevent data loss.
- Turn off the device before physically removing the card for added safety.

Disposal Instructions

- Dispose of the microSD card in accordance with local electronic waste disposal regulations.
- Do not throw the microSD card in regular trash as it may contain materials harmful to the environment.
- Consider recycling options available in your area for electronic devices.

Contact Information for Further Support

For safety inquiries or additional support, please refer to the manufacturer's website or customer service resources.

Thank you for your attention to these safety guidelines. Enjoy using your Delkin Devices Class 10 Micro SD Card!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk