

# FIRING PIN ASSEMBLY KITS - FIRING PIN ASSEMBLY KIT 9MM GLOCK®

[Handgun Parts](#) > [Action Parts](#) > [Firing Pin Parts](#) > [Firing Pins](#)

The Firing Pin Assembly Kits for Glock® feature the components needed to quickly and easily replace your firing pin parts. The kits are available for all models of Glock®, and are available in configurations: 9mm, 357 Sig / 40 S&W / 45 GAP. Firing pin safety and spring is included as well. All parts are genuine Glock® components.



## Attributes

- Name: [FIRING PIN ASSEMBLY KIT 9MM GLOCK®](#)
- Manufacturer: [GLOCK](#)
- Product no.: 100015949
- Mfr. No.:
- Caliber: 9 mm (.355-.356)
- Make: Glock
- Model: 17,19,25,26,28,34
- Delivery weight: 0.027kg

## Item details

US export classification: 0A501.x

# Table of Contents

- [Startpage](#)
- [Firing Pin Assembly Kit Safety Instructions](#)
- [About Us](#)

# Firing Pin Assembly Kit Safety Instructions

## Introduction

Thank you for choosing the Firing Pin Assembly Kit for your Glock® firearm. This guide provides essential safety instructions and information to ensure the safe use and installation of the product. Please read this guide carefully before use.

## General Safety Guidelines

- Ensure that you are familiar with the operation of your Glock® firearm before attempting to replace any parts.
- Always handle firearms with care and treat them as if they are loaded.
- Store all firearm components, including the Firing Pin Assembly Kit, out of reach of children and unauthorized users.
- Only use genuine Glock® components in your firearm to maintain safety and reliability.
- Regularly check for product recalls and safety notices through official channels.

## Specific Safety Precautions for Use

- Always wear safety glasses when working on your firearm to protect your eyes from potential debris.
- Ensure the firearm is unloaded before beginning any maintenance or installation.
- Keep your work area clean and organized to avoid losing small parts.
- Do not attempt to modify any components of the Firing Pin Assembly Kit.
- If you are unsure about any step in the installation process, consult a qualified gunsmith.

## Instructions for Installation and Usage

### 1. Preparation:

- Gather all necessary tools and components from the Firing Pin Assembly Kit.
- Ensure you are working in a welllit and safe environment.

### 2. Disassembling the Firearm:

- Ensure the firearm is pointed in a safe direction.
- Remove the magazine and check the chamber to confirm the firearm is unloaded.
- Follow the manufacturer's instructions to disassemble the slide from the frame.

### 3. Removing the Old Firing Pin:

- Carefully remove the existing firing pin safety and spring.
- Take out the old firing pin and any other components that need to be replaced.

### 4. Installing the New Firing Pin Assembly:

- Insert the new firing pin into the slide.
- Install the firing pin spring and ensure it is seated correctly.
- Place the firing pin safety in its designated position.
- Reassemble any other components that were removed during disassembly.

### 5. Final Checks:

- Ensure all parts are securely in place and functioning correctly.
- Perform a function check to confirm the firing pin operates as intended.

- Reassemble the frame and slide according to the manufacturer's instructions.

## **Disposal Instructions**

- Dispose of any old or unused components in accordance with local regulations.
- Do not throw away components in regular trash; check with local waste management for proper disposal methods.

## **Contact Information for Further Support**

For any questions or concerns regarding the Firing Pin Assembly Kit, please refer to the manufacturer's contact resources.

Thank you for following these safety instructions. Your safety and the safe operation of your firearm are our top priorities.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)