

PROTAC RAIL MOUNT 1 LONG GUN LIGHT BLACK

The ProTac series expands into weapon-mounted lights with this light featuring a dedicated fixed-mount for Picatinny rails. It uses either a remote switch with momentary/constant on operation or a standard push-button tail switch, and can run on either a lithium battery or an easy-to-find alkaline battery. ProTac Rail Mount 1 Specs: Dual fuel - uses one AA alkaline or CR123A lithium battery (both included); also accepts AA lithium CR123A lithium battery output: High: 350 lumens; 12,000 candela; 219m beam; runs 1.75 hours Low 40 lumens; 1,380 candela; 19m beam; runs 14.5 hours AA alkaline/AA lithium battery output: High: 150 lumens; 4,950 candela; 141m beam; runs 1.5 hours (alkaline); runs 4.5 hours (AA lithium) Low: 40 lumens; 1,380 candela; 19m beam; runs 8 hours (alkaline); runs 14 hours (AA lithium) Strobe for signaling or disorienting TEN-TAP® Programming - choice of three operating modes: 1.) high/strobe; 2.) high only; 3.) low/high Remote pressure switch features momentary and "constant on" operation Integrated rail clamp attaches to MIL-STD-1913 rails Easy to attach, secure mounting Includes remote pressure switch, push-button tail switch, remote retaining clips, double-sided tape and zip ties Durable, anodized aluminum construction with impact-resistant tempered glass lens IPX7 rated with the Standard button switch installed; waterproof to 1 meter for 30 minutes. IPX4 rated with the Remote Pressure Switch installed Operating temperature: -40°F to +120°F Limited lifetime warranty RoHS compliant ProTac Rail Mount 2 Specs: TEN-TAP® Programming - choice of three operating modes: 1.) high/strobe; 2.) high only; 3.) low/high High: 625 lumens; 22,000 candela; 297m beam; runs 2 hours Low: 60 lumens; 2,000 candela; 89m beam; runs 21 hours Strobe for signaling or disorienting Remote pressure switch features momentary and "constant on" operation Integrated rail clamp attaches to MIL-STD-1913 rails Easy to attach, secure mounting Includes remote pressure switch, push-button tail switch, remote retaining clips, double-sided tape and zip ties Uses two CR123A lithium batteries (included) Durable, anodized aluminum construction with impact-resistant tempered glass lens IPX7 rated with the Standard button switch installed; waterproof to 1 meter for 30 minutes. IPX4 rated with the Remote Pressure Switch installed Operating temperature: -40°F to +120°F Limited lifetime warranty RoHS compliant Protac Rail Mount HL-X Long Gun Light Specs: The ProTac Rail Mount HL-X is a 1,000 lumen weapon-mounted light featuring a dedicated fixed-mount for Picatinny rails. It uses either a remote switch or a standard push-button tail switch, and can run on multiple battery sources. High for maximum illumination: 1,000 lumens; 332m beam; runs 1.25 hours (CR123A batteries); runs 1.5 hours (18650 battery); 27,600 candela Low for extended run time: 60 lumens; 80m beam; runs 20 hours (CR123A batteries); runs 23 hours (18650 battery); 1,600 candela Strobe for signaling or disorienting: runs 2.5 hours (CR123A batteries); runs 3.25 hours (18650 battery) Dual fuel - uses two CR123A lithium batteries (included); also accepts one Streamlight rechargeable 18650 lithium ion battery Easy to use pressure switch comes with a button for on/off and a pressure switch for momentary activation. Integrated rail clamp attaches to MIL-STD-1913 rails Durable, anodized aluminum construction with impact-resistant tempered glass lens IPX7 rated with the Standard button switch installed; waterproof to 1 meter for 30 minutes. IPX4 rated with the Remote Pressure Switch installed Operating temperature: -40°F to +120°F Anti-roll head Includes two CR123A lithium batteries, remote pressure switch, push-button tail switch, remote retaining clips, double-sided tape and zip ties Solid State power regulation provides maximum light output throughout battery life RoHS compliant



Attributes

- Name: PROTAC RAIL MOUNT 1 LONG GUN LIGHT BLACK
- Manufacturer: Streamlight
- Product no.: 100018987
- Mfr. No.: 88058
- Battery: CR-123A,AA
- Candela: 12000
- Lumens: 350
- Style: Rail Mounted
- Delivery weight: 0.272kg
- Shipping height: 165mm
- Shipping width: 64mm
- Shipping length: 165mm
- UPC: 080926880580

Item details

Made in USA

This product contains a battery.

Table of Contents

- [Startpage](#)
- [English: ProTac Rail Mount Long Gun Light Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för PROTAC RAIL MOUNT 1 LONG GUN LIGHT](#)

ProTac Rail Mount Long Gun Light Safety Instructions

Introduction

Thank you for choosing the ProTac Rail Mount Long Gun Light. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure the light is suitable for your weapon and intended use.
- Always handle the light with care to avoid accidents.
- Keep the light out of reach of children and unauthorized users.
- Regularly inspect the light for damage or wear before use.
- Do not modify the light or use it in ways not intended by the manufacturer.
- If you notice any unusual behavior, such as flickering or failure to turn on, discontinue use immediately and consult the manufacturer.

Specific Safety Precautions for Use

- **Battery Safety:**
 - Use only the batteries specified in this manual (CR123A lithium or AA alkaline/lithium).
 - Do not mix different battery types or brands.
 - Ensure batteries are installed with the correct polarity (+ and).
 - Dispose of used batteries properly according to local regulations.
- **Environmental Considerations:**
 - Avoid exposing the light to extreme temperatures outside the operating range of 40°F to +120°F.
 - Do not use the light in wet conditions if the remote pressure switch is installed, as it has an IPX4 rating. Use caution to maintain the IPX7 rating with the standard button switch.
- **Mounting Safety:**
 - Ensure the light is securely mounted to the weapon before use.
 - Regularly check the attachment points to prevent the light from becoming loose during use.

Instructions for Installation and Usage

Installation

1. **Mounting the Light:**
 - Use the integrated rail clamp to attach the light to MILSTD1913 rails.
 - Ensure the clamp is tightened securely to prevent movement during operation.
2. **Battery Installation:**
 - Open the battery compartment and insert the specified batteries, ensuring correct polarity.
 - Close the compartment securely.
3. **Switch Installation:**
 - Choose between the remote pressure switch or the pushbutton tail switch.
 - Attach the switch securely to the designated area on the weapon.

Usage

1. **Operating Modes:**
 - The ProTac Rail Mount Long Gun Light features multiple operating modes:
 - High/Strobe
 - High Only

- Low/High
 - Use the TENTAP® Programming feature to select your preferred mode.
2. **Using the Pressure Switch:**
 - For momentary activation, press the pressure switch lightly.
 - For constant on, press the switch fully until it clicks.
 3. **Strobe Function:**
 - Activate the strobe mode for signaling or disorienting purposes by selecting the appropriate mode.

Disposal Instructions

- Dispose of the ProTac Rail Mount Long Gun Light and its components in accordance with local environmental regulations.
- Do not dispose of the product in regular household waste.
- For battery disposal, follow local guidelines for hazardous materials.

Contact Information for Further Support

For any safety inquiries, product support, or to report any unsafe conditions, please refer to the manufacturer's contact details provided with the product packaging or on the official website.

Conclusion

Your safety and satisfaction are our top priorities. By following these guidelines, you can ensure the safe use of the ProTac Rail Mount Long Gun Light. If you have any questions or concerns, do not hesitate to reach out for assistance. Thank you for choosing our product.

Säkerhetsinstruktioner för PROTAC RAIL MOUNT 1 LONG GUN LIGHT

Introduktion

Tack för att du har valt PROTAC RAIL MOUNT 1 LONG GUN LIGHT från Streamlight. Denna lampa är designad för att ge säker och effektiv belysning för ditt vapen. För att säkerställa en trygg och korrekt användning av produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens instruktioner.
- Kontrollera produkten regelbundet för skador och slitage.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Rapportera alla farliga produkter eller incidenter till relevanta myndigheter.
- Kontrollera EU:s Safety Gateplattform för eventuella återkallelser av produkten.

Specifika säkerhetsåtgärder för användning

- Undvik att rikta lampan mot ögonen, då detta kan orsaka allvarlig ögonskada.
- Använd bara de rekommenderade batterierna (CR123A eller AA) för att undvika skador på produkten.
- Se till att produkten är korrekt monterad på vapnet innan användning.
- Använd endast den medföljande fjärrtryckknappen eller tryckknappen på svansen för att aktivera lampan.
- Vid användning av strobelaget, var medveten om att detta kan orsaka desorientering för både användaren och omgivningen.

Instruktioner för installation och användning

Installation

1. Fäst lampan på MILSTD1913skenan på ditt vapen.
2. Använd den medföljande skruven för att säkerställa att lampan sitter fast ordentligt.
3. Kontrollera att fjärrtryckknappen är korrekt ansluten om den används.

Användning

- För att aktivera lampan, tryck på knappen på svansen eller använd fjärrtryckknappen.
- Välj driftsläge genom att trycka på TENTAP® programmeringsknappen:
 - Läge 1: Hög/strobe
 - Läge 2: Hög endast
 - Läge 3: Låg/hög
- Observera att lampan har olika ljusstyrkor beroende på valt läge:
 - Hög: 350 lumen (AA alkaliskt) / 625 lumen (CR123A)
 - Låg: 40 lumen
 - Strobe: för signalering eller desorientering

Avfallshantering

- Kassera använda batterier enligt lokala föreskrifter för farligt avfall.
- Återvinn lampan och dess komponenter enligt lokala regler för elektronikavfall.

Kontaktinformation för ytterligare stöd

För frågor eller mer information, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för snabbare hjälp.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din PROTAC RAIL MOUNT 1 LONG GUN LIGHT. Tack för att du bidrar till en säker användning av produkter.