

ENGAGE 1300 RANGEFINDER - ENGAGE 1300 6X24MM RANGEFINDER

[Optics & Mounting](#) > [Rangefinders](#)

The Bushnell Engage Laser Rangefinders are designed to give you the cool confidence to take that long-range shot secure in the knowledge that your first shot will hit where you want it to.



Attributes

- Name: [ENGAGE 1300 6X24MM RANGEFINDER](#)
- Manufacturer: [BUSHNELL](#)
- Product no.: 100046032
- Mfr. No.: LE1300SBL
- Battery: CR2
- Color: Green
- Magnification: 6x
- Objective Size: 24mm
- Delivery weight: 0.345kg
- Shipping height: 76mm
- Shipping width: 140mm
- Shipping length: 140mm
- UPC: 029757005366

Item details

This product contains a battery.

Table of Contents

- [Startpage](#)
- [ENGAGE 1300 RANGEFINDER Safety Instructions](#)
- [About Us](#)

ENGAGE 1300 RANGEFINDER Safety Instructions

Introduction

Thank you for choosing the ENGAGE 1300 Rangefinder by Bushnell. This product is designed to enhance your outdoor experience by providing accurate distance measurements. However, it is essential to follow safety guidelines to ensure safe and effective use. This document provides comprehensive safety instructions in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the rangefinder is used only for its intended purpose.
- Keep the device out of reach of children and vulnerable individuals.
- Regularly check the device for any signs of damage or malfunction.
- Avoid exposing the rangefinder to extreme temperatures, moisture, or direct sunlight for extended periods.
- Use the rangefinder in accordance with local laws and regulations regarding its use.

Specific Safety Precautions for Use

- Do not look directly into the laser beam. This can cause eye damage.
- Do not attempt to disassemble or modify the rangefinder. This may lead to malfunction or injury.
- Ensure that the battery is installed correctly and is not leaking. Dispose of used batteries properly.
- When using the rangefinder, maintain a firm grip and stable stance to avoid falls or accidents.
- Use the rangefinder only in conditions where visibility is adequate to ensure accurate readings.

Instructions for Installation and Usage

1. Battery Installation

- Open the battery compartment by sliding the cover in the direction indicated.
- Insert a CR2 battery, ensuring the positive (+) and negative (-) terminals are correctly aligned.
- Close the battery compartment securely.

2. Using the Rangefinder

- Power on the device by pressing the power button.
- Aim the rangefinder at the target object while keeping the device steady.
- Press the measurement button to obtain the distance reading.
- The display will show the distance in yards or meters, depending on your settings.

3. Maintenance

- Clean the lens with a soft, dry cloth to remove dust and debris.
- Store the rangefinder in a protective case when not in use to prevent damage.

Disposal Instructions

- Dispose of the rangefinder and its components in accordance with local waste disposal regulations.
- Do not dispose of batteries in regular household waste. Instead, take them to designated recycling centers.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please refer to the EUbased contact point provided with your product packaging.

Conclusion

By following these safety instructions, you can enjoy the full benefits of your ENGAGE 1300 Rangefinder while ensuring your safety and the safety of others. Always stay informed about recalls and safety updates through the EU's Safety Gate platform. Thank you for your attention to these important guidelines.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at