

TANGO FRONT MOUNT RIFLE/PISTOL SHOOTING REST - BIRCHWOOD CASEY TANGO FRONT MOUNT RIFLE/PISTOL SHOOTING REST

[Shooting Accessories](#) > [Shooting Rests](#) > [Handgun Rests](#)

KEY FEATURES PADDED FRONT REST NON-MARRING MATERIAL COMFORTABLE
AND DURABLE ADJUSTABLE ELEVATION CAN BE USED WITH MOST HANDGUNS



Attributes

- Name: [BIRCHWOOD CASEY TANGO FRONT MOUNT RIFLE/PISTOL SHOOTING REST](#)
- Manufacturer: [BIRCHWOOD CASEY](#)
- Product no.: 100048022
- Mfr. No.: BC-FMSR
- Material: Plastic
- Style: Pistol Rest
- Delivery weight: 1.411kg
- Shipping height: 127mm
- Shipping width: 267mm
- Shipping length: 324mm
- UPC: 888151031490

Table of Contents

- [Startpage](#)
- [TANGO FRONT MOUNT RIFLE/PISTOL SHOOTING REST SAFETY INSTRUCTIONS](#)
- [About Us](#)

TANGO FRONT MOUNT RIFLE/PISTOL SHOOTING REST SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the TANGO FRONT MOUNT RIFLE/PISTOL SHOOTING REST by Birchwood Casey. This product is designed to enhance your shooting experience by providing a stable and comfortable platform for your handgun. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always treat firearms as if they are loaded.
- Keep the shooting rest and all firearms out of reach of children.
- Use the shooting rest only in a safe and controlled environment.
- Follow all local laws and regulations regarding firearm use.
- Regularly inspect the shooting rest for any signs of wear or damage.
- If you notice any defects, do not use the product and contact the manufacturer.

Specific Safety Precautions for Use

- Ensure that the shooting rest is placed on a stable and level surface before use.
- Always secure your handgun safely in the rest before attempting to load or unload.
- Never place your hands or any part of your body in front of the muzzle of the firearm while it is in the rest.
- Be aware of your surroundings and ensure that there are no people or animals in the line of fire.
- Use appropriate eye and ear protection while shooting.

Instructions for Installation and Usage

1. Setting Up the Shooting Rest

- Place the shooting rest on a flat, stable surface.
- Adjust the elevation to suit your shooting preference by using the adjustable elevation feature.

2. Using the Shooting Rest

- Position your handgun securely in the padded front rest.
- Ensure that the handgun is pointed in a safe direction at all times.
- Load the handgun only when you are ready to shoot, and always follow safe firearm handling practices.

3. PostUse Care

- After use, remove the handgun from the rest and store it safely.
- Clean the shooting rest with a dry cloth to remove any dirt or debris.

Disposal Instructions

- Dispose of the shooting rest in accordance with local regulations.
- If the product is damaged beyond repair, consider recycling materials where possible.
- Do not dispose of the product in regular household waste.

Contact Information for Further Support

For any safety inquiries or concerns regarding the TANGO FRONT MOUNT RIFLE/PISTOL SHOOTING REST, please refer to the contact information provided on the packaging or visit the manufacturer's website.

Thank you for prioritizing safety while using the TANGO FRONT MOUNT RIFLE/PISTOL SHOOTING REST. Enjoy your shooting experience responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk