

# SINGLE STAGE SMALL PRIMER SEATING ASSEMBLY

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

High-quality replacement parts are compatible with the RCBS Rock Chuck, Reloader Special and most C-frame single-stage presses. Small primer plug, sleeve and spring are replacements for the built in primer arms on many RCBS single-stage presses.



## Attributes

- Name: [SINGLE STAGE SMALL PRIMER SEATING ASSEMBLY](#)
- Manufacturer: [RCBS](#)
- Product no.: 100060870
- Mfr. No.: 9553
- Delivery weight: 0.005kg
- Shipping height: 3mm
- Shipping width: 51mm
- Shipping length: 152mm
- UPC: 076683095534

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for SINGLE STAGE SMALL PRIMER SEATING ASSEMBLY
- About Us

# Safety Instruction Guide for SINGLE STAGE SMALL PRIMER SEATING ASSEMBLY

## Introduction

Thank you for choosing the SINGLE STAGE SMALL PRIMER SEATING ASSEMBLY. This product is designed to enhance your reloading experience with highquality replacement parts compatible with RCBS Rock Chucker, Reloader Special, and most Cframe singlestage presses. To ensure safe and effective use, please read and follow these safety instructions carefully.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always operate the reloading press in a wellventilated area.
- Keep the work area clean and free of clutter to prevent accidents.
- Store all reloading components, including this assembly, out of reach of children and pets.
- Regularly inspect the product for wear or damage before use.
- Follow all local laws and regulations regarding ammunition reloading.

## Specific Safety Precautions for Use

- Use protective eyewear to shield your eyes from debris during operation.
- Avoid wearing loose clothing or jewelry that could get caught in machinery.
- Do not exceed the manufacturer's recommended load limits when using the assembly.
- Always ensure that the reloading press is securely mounted before use.
- In case of any malfunction or unusual noise, stop using the product immediately and inspect for issues.
- Do not attempt to modify or alter the assembly in any way.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure the reloading press is unplugged or disconnected from power.
- Remove any existing primer seating components from the press.
- Insert the small primer plug into the primer arm of the press.
- Attach the sleeve and spring as per the manufacturer's guidelines.
- Ensure all components are securely fastened before proceeding.

### 2. Usage:

- Prepare your reloading materials and ensure you have a clean workspace.
- Load the primer into the assembly according to the press's operating instructions.
- Operate the press smoothly and steadily, applying even pressure.
- After seating the primer, inspect each round for proper seating depth.
- Store the assembly and all reloading components in a safe location after use.

## Disposal Instructions

- Dispose of any damaged or worn components in accordance with local waste disposal regulations.
- Recycle packaging materials where possible.
- Do not dispose of any components in a manner that could harm the environment or pose a risk to public safety.

## **Contact Information for Further Support**

For any inquiries regarding safety or product performance, please refer to the manufacturer's contact information provided with your product packaging or visit the manufacturer's official website.

By adhering to these safety guidelines and instructions, you can ensure a safe and enjoyable reloading experience with your SINGLE STAGE SMALL PRIMER SEATING ASSEMBLY. Thank you for your attention to safety.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)