

DEBRIS SHIELD FOR PROCHRONO MODELS - COMPETITION ELECTRONICS DEBRIS SHIELD FOR PROCHRONO MODELS

[Shooting Accessories](#) > [Range Gear](#) > [Chronographs](#)

Lexan Debris Shield to be used with ProChrono Models Clear lexan cover protects the display from debris. Covers the entire front and top of unit. Held in place with the guide wires Control buttons remain accessible Not intended to protect chronograph from projectiles

Lexan Debris Shield to be used with ProChrono Models Clear lexan cover protects the display from debris. Covers the entire front and top of unit. Held in place with the guide wires Control buttons remain accessible Not intended to protect chronograph from projectiles



Attributes

- Name: [COMPETITION ELECTRONICS DEBRIS SHIELD FOR PROCHRONO MODELS](#)
- Manufacturer: [COMPETITION ELECTRONICS](#)
- Product no.: 225000010
- Mfr. No.: CEI-2519
- Colour: Clear
- Style: Chronograph Accessory
- Delivery weight: 2.268kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 432mm
- UPC: 787735025194

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [DEBRIS SHIELD FOR PROCHRONO MODELS Safety Instruction Guide](#)
- [About Us](#)

DEBRIS SHIELD FOR PROCHRONO MODELS Safety Instruction Guide

Introduction

Thank you for choosing the Debris Shield for ProChrono Models by Competition Electronics. This guide provides essential safety instructions, usage guidelines, and installation procedures to ensure the safe and effective use of this product. Please read this document carefully before use.

General Safety Guidelines

- Ensure the Debris Shield is used only with ProChrono Models.
- Do not attempt to modify or alter the Debris Shield in any way.
- Keep the Debris Shield out of reach of children and vulnerable individuals.
- Regularly inspect the Debris Shield for any signs of damage or wear.
- If the Debris Shield shows signs of damage, discontinue use immediately and replace it.
- Be aware that the Debris Shield is not designed to protect the chronograph from projectiles.

Specific Safety Precautions for Use

- Always ensure that the Debris Shield is securely attached before operating the chronograph.
- Do not place any objects on top of the Debris Shield that may obstruct the display or control buttons.
- Ensure that the control buttons remain accessible at all times for safe operation.
- Avoid using the Debris Shield in extreme weather conditions that may affect its integrity.
- If using the chronograph outdoors, ensure that the area is free from debris that could interfere with its operation.

Instructions for Installation and Usage

1. Installation of the Debris Shield:

- Remove the Debris Shield from its packaging.
- Align the Debris Shield with the front and top of the ProChrono Model.
- Secure the Debris Shield in place using the guide wires provided.
- Ensure that the shield covers the entire front and top of the unit.

2. Usage of the Debris Shield:

- Once the Debris Shield is installed, check that all control buttons are easily accessible.
- Power on the chronograph and ensure that the display is visible through the lexan cover.
- Conduct your chronograph operations as per the manufacturer's instructions while ensuring the Debris Shield remains in place.

3. PostUse Care:

- After use, inspect the Debris Shield for any damage.
- Clean the Debris Shield with a soft, damp cloth to remove any debris or marks.
- Store the Debris Shield in a safe, dry place when not in use.

Disposal Instructions

- Dispose of the Debris Shield in accordance with local waste management regulations.
- If the Debris Shield is damaged beyond repair, ensure it is disposed of in an environmentally friendly

manner.

- Do not incinerate the Debris Shield as it may release harmful substances.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Debris Shield for ProChrono Models, please reach out to the appropriate EU-based contact point as specified by the manufacturer.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of the Debris Shield for ProChrono Models. Always prioritize safety and report any unsafe conditions or incidents to the relevant authorities. Thank you for your attention to these guidelines, and enjoy using your chronograph safely.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk