

2 PIECE SHOOTING BAGS - SHOOTING MADE EASY 2 PIECE SHOOTING BAGS FILLED

SME's Front & Rear Gun Rest bags holds your rifles solidly in place when sighting-in. It is constructed of durable, water resistant 600d polyester with non-marring flannelette surface contact and reinforced stitching. The bags features a quick connect for easy transport and is filled with 100 percent inert polybead filler or fill the bags with your desired media, sand, corn, rice, birdseed, etc. The density of the media will determine the weight of the bags. FEATURES Non-slip bottom Inert poly bead fill Suede leather topper to protect stock Front and rear bag included



SME's Front & Rear Gun Rest bags holds your rifles solidly in place when sighting-in. It is constructed of durable, water resistant 600d polyester with non-marring flannelette surface contact and reinforced stitching. The bags features a quick connect for easy transport and is filled with 100 percent inert polybead filler or fill the bags with your desired media, sand, corn, rice, birdseed, etc. The density of the media will determine the weight of the bags. FEATURES Non-slip bottom Inert poly bead fill Suede leather topper to protect stock Front and rear bag included

Attributes

- Name: SHOOTING MADE EASY 2 PIECE SHOOTING BAGS FILLED
- Manufacturer: SHOOTING MADE EASY
- Product no.: 430100874
- Mfr. No.: SME-GRF
- Colour: Gray
- Material: Polyester
- Delivery weight: 3.629kg
- Shipping height: 222mm
- Shipping width: 178mm
- Shipping length: 235mm
- UPC: 888151017371

Table of Contents

- [Startpage](#)
- [English: 2 Piece Shooting Bags Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för 2 PIECE SHOOTING BAGS](#)

2 Piece Shooting Bags Safety Instructions

Introduction

Thank you for choosing the 2 Piece Shooting Bags by Shooting Made Easy. These bags are designed to provide stable support for your rifles during sighting in. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the shooting bags are used in a safe and controlled environment.
- Always follow local laws and regulations regarding firearm handling and shooting.
- Keep the shooting bags out of reach of children and pets when not in use.
- Regularly inspect the bags for any signs of wear or damage before each use.
- Do not use the shooting bags for any purpose other than supporting firearms.

Specific Safety Precautions for Use

- Always place the shooting bags on a stable and flat surface to avoid tipping.
- Ensure that the bags are filled with the appropriate media (e.g., inert polybead filler, sand, etc.) to achieve the desired weight.
- Avoid overfilling the bags, as this may affect their stability and usability.
- Do not use the bags if they show signs of damage, such as tears or frayed seams.
- When transporting the bags, secure them properly to prevent shifting or falling.

Instructions for Installation and Usage

1. Filling the Bags:

- If you choose to fill the bags with your desired media, ensure that the media is clean and free from contaminants.
- Fill each bag to the desired weight, keeping in mind that the density of the media will affect the overall weight.
- Ensure that the bags are sealed properly to prevent spillage.

2. Setting Up the Bags:

- Place the front bag under the forend of the rifle and the rear bag under the buttstock.
- Adjust the positioning of the bags to achieve a comfortable and stable shooting position.
- Ensure that the rifle is securely resting on the bags before proceeding with shooting.

3. Shooting:

- Always maintain proper firearm safety practices while shooting.
- Keep the muzzle of the firearm pointed in a safe direction at all times.
- Use the bags to support the rifle, allowing for better accuracy and stability.

Disposal Instructions

- When the shooting bags reach the end of their usable life, dispose of them responsibly.
- Check local regulations for proper disposal methods for polyester materials and filler media.
- If the bags are damaged, avoid attempting to repair them; dispose of them to prevent accidents.

Contact Information for Further Support

For any inquiries or concerns regarding the 2 Piece Shooting Bags, please contact the manufacturer directly. Ensure you have your product details handy for a quicker response.

By following these safety instructions, you can ensure a safe and enjoyable experience while using your 2 Piece Shooting Bags. Thank you for your attention to safety!

Säkerhetsinstruktioner för 2 PIECE SHOOTING BAGS

Introduktion

Tack för att du valt 2 PIECE SHOOTING BAGS från SHOOTING MADE EASY. Denna produkt är designad för att hålla dina gevär stadigt på plats under skytte. För att säkerställa en säker användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid skyddsutrustning som hörselskydd och skyddsglasögon när du hanterar vapen.
- Håll alltid vapnet riktat bort från människor och djur.
- Förvara alltid vapnet säkert och utom räckhåll för barn.
- Kontrollera att produkten är i gott skick innan användning. Om du upptäcker skador, avbryt användningen omedelbart.
- Rapportera eventuella osäkra produkter eller olyckor till myndigheterna.

Specifika säkerhetsåtgärder för användning

- Använd endast produkten för det avsedda ändamålet, vilket är att stabilisera gevär under skytte.
- Se till att väskorna är fyllda med 100 procent inert polybeadfillning eller annat säkert material som sand eller majs.
- Kontrollera att väskorna är ordentligt placerade innan du börjar skjuta.
- Undvik att använda produkten i ogynnsamma väderförhållanden, som kraftigt regn eller snö, som kan påverka stabiliteten.

Instruktioner för installation och användning

1. Placera framsäkerhetsväskan framför geväret och baksäkerhetsväskan bakom.
2. Justera väskorna så att de ger optimal stabilitet för ditt gevär.
3. Kontrollera att väskorna är ordentligt kopplade och inte glider.
4. Vid behov, fyll väskorna med ditt valda material för att uppnå önskad vikt och stabilitet.
5. När du är klar med skytte, ta bort väskorna försiktigt och förvara dem på en säker plats.

Avfallsinstruktioner

- När produkten når slutet av sin livslängd, se till att avlägsna den på ett miljövänligt sätt.
- Kontakta lokala myndigheter för information om hur man korrekt återvinner eller bortskaffar polyester och andra material.

Kontaktinformation för ytterligare stöd

För frågor om säkerhet eller produktinformation, vänligen kontakta en EUbaserad kontaktpunkt. Se till att följa alla lokala lagar och riktlinjer för säkerhet och avfallshantering.

Vi tackar för din uppmärksamhet och hoppas att du får en säker och framgångsrik upplevelse med dina 2 PIECE SHOOTING BAGS.