

ARCA SWISS® TRIPOD - ARCA TRIPOD W/ARCA SWISS MOUNT BLACK

[Shooting Accessories](#) > [Shooting Rests](#) > [Shooting Rest Accessories](#)

Featuring the dependability of its predecessor the DeathGrip® (4.8 out of 5 stars average customer rating), and utilizing a universal Arca Swiss® mounting system, BOG®'s latest entry into the tripod market is designed as a robust, versatile platform for mounting compatible shooting, glassing and photography gear.



Attributes

- Name: [ARCA TRIPOD W/ARCA SWISS MOUNT BLACK](#)
- Manufacturer: [BOG GEAR LLC](#)
- Product no.: 430108831
- Mfr. No.: 1209008
- Weight: 6.28 lbs
- Delivery weight: 3.502kg
- Shipping height: 838mm
- Shipping width: 127mm
- Shipping length: 127mm
- UPC: 661120750918

Table of Contents

- [Startpage](#)
- [ARCA SWISS TRIPOD Safety Instruction Guide](#)
- [About Us](#)

ARCA SWISS TRIPOD Safety Instruction Guide

Introduction

Thank you for choosing the ARCA SWISS TRIPOD with ARCA SWISS MOUNT in black. This tripod is designed to provide a stable and reliable platform for your shooting, glassing, and photography needs. To ensure your safety and the longevity of the product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always inspect the tripod before use to ensure all components are in good condition.
- Do not exceed the maximum weight limit of the tripod. The weight limit is 6.28 lbs.
- Use the tripod only for its intended purpose. Misuse may lead to accidents or injuries.
- Keep the tripod away from children and vulnerable individuals to prevent accidents.
- Follow all local regulations regarding outdoor use and photography equipment.

Specific Safety Precautions for Use

- Ensure that the tripod is set up on a stable and level surface to prevent tipping.
- When using the tripod in windy conditions, be cautious of potential instability.
- Always secure your equipment properly to the tripod to avoid falls.
- Do not leave the tripod unattended while it is set up with equipment attached.
- Be aware of your surroundings and avoid using the tripod near edges or unstable ground.

Instructions for Installation and Usage

1. Setting Up the Tripod:

- Unfold the tripod legs completely and ensure they are locked in place.
- Adjust the height of the tripod to your desired level by releasing the leg locks and extending the legs.
- Lock the legs securely after adjusting the height.

2. Attaching Equipment:

- Use the universal Arca Swiss mounting system to attach your compatible shooting, glassing, or photography gear.
- Ensure that the equipment is securely fastened to the tripod mount.

3. Using the Tripod:

- Position the tripod on stable ground and ensure all legs are evenly placed.
- Adjust the angle of the tripod head as needed for your shot.
- After use, remove all equipment from the tripod before collapsing it.

4. Collapsing the Tripod:

- Release the leg locks and gently retract the legs.
- Ensure that the tripod is fully collapsed before storing.

Disposal Instructions

- Dispose of the tripod in accordance with local regulations regarding plastic and metal waste.
- Do not dispose of the tripod in household waste. Check for recycling options in your area.

Contact Information for Further Support

For any inquiries or concerns regarding the safety and use of the ARCA SWISS TRIPOD, please contact your local distributor or retailer.

Reporting Unsafe Products

If you encounter any issues or suspect that the product may pose a safety risk, please report it to the relevant authorities. Stay informed about product recalls and safety updates through the EU's Safety Gate platform.

Thank you for your attention to these safety instructions. Enjoy your photography with the ARCA SWISS TRIPOD!

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se