

EZE-SCORER THERMAL OPTIC SIGHT-INTARGETS - BIRCHWOOD CASEY EZE-SCORER THERMAL OPTIC SIGHT-IN TARGETS

BIRCHWOOD CASEY EZE-SCORER THERMAL OPTIC SIGHT-INTARGETS What's the easiest way to zero in your thermal scope? Using a Thermal Sight-In Target from Birchwood Casey's ever-expanding product lineup makes zeroing simpler and far more efficient. Thanks to Eze-Scorer® thermal targets that detect heat signatures, your view will be of a target with temperature differences your thermal optics can easily home in on. Key Features Quick and simple way to zero in thermal scopes Eze-Scorer® thermal targets detect and show heat signatures, showing you where to focus For use with any paper target Includes: Four 3" thermal signatures Four 12"L x 12"W sight-in targets



Attributes

- Name: BIRCHWOOD CASEY EZE-SCORER THERMAL OPTIC SIGHT-IN TARGETS
- Manufacturer: BIRCHWOOD CASEY
- Product no.: 430114046
- Mfr. No.: BC-37216T
- Style: Papers
- Target Size/Type: Large 12 to 20
- Type: Papers
- Quantity: 5
- Delivery weight: 1.937kg
- Shipping height: 71mm
- Shipping width: 244mm
- Shipping length: 229mm
- UPC: 888151085929

Table of Contents

- [Startpage](#)
- [English: EZESCORER BAD GUY 12 X 18" TARGETS SAFETY INSTRUCTIONS](#)

EZESCORER BAD GUY 12 X 18" TARGETS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the EZESCORER BAD GUY 12 X 18" TARGETS by Birchwood Casey. These targets are designed for handgun shooting practice, suitable for both indoor and outdoor ranges. To ensure a safe and enjoyable experience, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always treat all firearms as if they are loaded.
- Ensure that you are in a safe shooting environment, away from bystanders.
- Use appropriate eye and ear protection when shooting.
- Always be aware of your surroundings and ensure that the range is clear before firing.
- Follow all local laws and regulations regarding the use of firearms.
- Keep the targets at a safe distance to avoid ricochets or stray bullets.
- Store firearms and ammunition securely, out of reach of children and unauthorized users.

Specific Safety Precautions for Use

- Ensure that the targets are securely mounted to prevent them from falling or being blown away.
- Avoid using targets in high winds or adverse weather conditions that may affect shooting accuracy.
- Use targets only with firearms that are appropriate for the caliber indicated.
- Inspect the targets before use. If you notice any damage or wear, do not use them.
- Do not shoot at targets if they are placed in a hazardous area, such as near flammable materials.

Instructions for Installation and Usage

- Select a safe shooting area with adequate backstop and distance from the target.
- Securely mount the target on a stable surface or target stand.
- Ensure the target is at eye level for optimal shooting practice.
- Use the targets for practice at any distance, adjusting based on your shooting skill level.
- After shooting, carefully collect any used targets and dispose of them properly.

Disposal Instructions

- Dispose of used targets in accordance with local waste disposal regulations.
- Do not burn the targets as they may contain materials that are harmful when incinerated.
- If you have any unused targets that are damaged or no longer needed, consider recycling them if possible.

Contact Information for Further Support

For any inquiries regarding safety or product information, please consult the manufacturer's website or contact your local retailer.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience while using the EZESCORER BAD GUY 12 X 18" TARGETS. Remember to always prioritize safety and adhere to local laws and regulations. Happy shooting!