

12 GAUGE TRIGGER PLATE FOR REMINGTON VERSA MAX II - 12GA TRIGGER PLATE FOR REMINGTON VERSA MAX II BURNT BRONZE

REMINGTON 12 GAUGE TRIGGER PLATE FOR REMINGTON VERSA MAX II
Factory-style Trigger Plate designed for the Remington Versa Max II in 12 Gauge. Finished in Burnt Bronze, this trigger plate is ideal for replacing a worn or damaged unit or restoring your shotgun to its original factory appearance. Manufactured to factory dimensions for proper fit and reliable function, this trigger plate provides a precision-machined housing for the fire control components. The Burnt Bronze finish matches factory Versa Max II models produced in this color configuration, making it suitable for repair or cosmetic restoration. **FEATURES** Designed for Remington Versa Max II – 12GA Burnt Bronze factory-style finish Precision-machined for proper fit Durable metal construction Ideal for repair, replacement, or restoration projects **SPECS** Product Type: Trigger Plate Compatible Model: Remington Versa Max II Gauge: 12 Gauge Finish: Burnt Bronze Configuration: Factory pattern Installation: Professional gunsmith installation recommended **NOTE:** These items are a new, authentic products acquired directly from Remington's OEM inventory. This item is guaranteed to be unused and fully functional.

NO IMAGE
AVAILABLE

Attributes

- Name: 12GA TRIGGER PLATE FOR REMINGTON VERSA MAX II BURNT BRONZE
- Manufacturer: REMINGTON
- Product no.: 430116580
- Mfr. No.: F419387
- Model: Versa Max II
- Weapon type: Remington
- Delivery weight: 0.199kg
- Shipping height: 132mm
- Shipping width: 23mm
- Shipping length: 55mm

Item details

Made in USA

US export classification: 0A502

Table of Contents

- [Startpage](#)
- [English: Consumer Safety Instruction Guide for 12 Gauge Trigger Plate for Remington Versa Max II](#)

Consumer Safety Instruction Guide for 12 Gauge Trigger Plate for Remington Versa Max II

Introduction

Thank you for choosing the 12 Gauge Trigger Plate for the Remington Versa Max II. This guide provides important safety information and instructions to ensure the safe and effective use of this product. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure that the product is installed and used according to the manufacturer's instructions.
- Always handle firearms and firearm components with care and respect.
- Store the Trigger Plate in a safe location, away from children and unauthorized users.
- Regularly inspect the Trigger Plate for signs of wear or damage.
- If you notice any defects or irregularities, discontinue use immediately and consult a professional gunsmith.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform to stay informed about product safety.

Specific Safety Precautions for Use

- This product is intended for use with the Remington Versa Max II shotgun in 12 Gauge only.
- Professional gunsmith installation is recommended to ensure proper fit and function.
- Do not attempt to modify or alter the Trigger Plate in any way.
- Always ensure the firearm is unloaded before installation or maintenance.
- Follow all local laws and regulations regarding firearms and their components.
- Use appropriate safety gear, such as eye protection, when handling firearms.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your workspace is clean and free from distractions.
- Gather all necessary tools for installation, including screwdrivers and any other required equipment.

2. Installation:

- Ensure the firearm is completely unloaded.
- Remove the existing Trigger Plate from the Remington Versa Max II by following the manufacturer's disassembly instructions.
- Align the new Trigger Plate with the mounting points on the shotgun.
- Secure the Trigger Plate using the provided screws, ensuring a snug fit without overtightening.
- Reassemble the firearm according to the manufacturer's assembly instructions.

3. PostInstallation Check:

- After installation, conduct a function check to ensure that the Trigger Plate operates correctly.
- Inspect the Trigger Plate for proper alignment and secure attachment.

4. Usage:

- Use the shotgun in accordance with the manufacturer's guidelines and safety practices.
- Regularly maintain and clean the Trigger Plate and surrounding components to ensure optimal performance.

Disposal Instructions

- Dispose of any old or damaged Trigger Plates in accordance with local regulations.
- Do not throw away the Trigger Plate in regular household waste.
- Contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the 12 Gauge Trigger Plate for the Remington Versa Max II, please refer to the manufacturer's contact points for assistance. Ensure that you have the product details ready for a more efficient service.

Thank you for your attention to these safety instructions. Your commitment to safe firearm handling is essential for ensuring a secure and enjoyable experience with your Remington Versa Max II.