

NX8 1-8X24MM FFP RIFLE SCOPE - NX8 1-8X24MM FFP ILLUMINATED FC-MIL RETICLE BLACK

Offers Owners a Leading Rifle Optic

The NX8 1-8X24 F1 is a class leading, compact and lightweight riflescope optimized for short to mid-range shooting. At only 8.75" in length and 17 ounces, this riflescope adds minimal size and weight but delivers superior optics and trusted Nightforce performance to any rifle. With the daylight visible center red dot users can engage targets with speed like a red-dot sight, but as targets increase in distance the intelligent first focal plane reticle provides precise hold points. For those preferring to dial for long shots, the ZeroStop elevation adjustment allows for a rapid and positive return to zero. To aid in fast magnification adjustments, a built-in Power Throw Lever (PTL) is included. First Focal Plane Reticle Weighs 17 ounces Built on a 30mm tube 0.2 MRAD or 0.50 MOA adjustments 100 MOA/30 MRAD of total internal adjustment



Attributes

- Name: NX8 1-8X24MM FFP ILLUMINATED FC-MIL RETICLE BLACK
- Manufacturer: NIGHTFORCE
- Product no.: 524000391
- Mfr. No.: C598
- Battery: CR-2032
- Click Value: 0.2 MRAD
- Click Value: 0.2 MRAD
- Eye Relief: 3.75"
- Finish: Matte Black
- Focal Plane: First
- Illumination: Yes
- Length: 8.75"
- Max Magnification: 8x
- Min. Magnification: 1x
- Model Number: NX8
- Objective Size: 24mm
- Reticle: FC-MIL
- Tube Size: 30mm
- Weight: 17.0 oz
- Delivery weight: 1.031kg
- Shipping height: 147mm
- Shipping width: 137mm
- Shipping length: 432mm
- UPC: 847362015514

Item details

This product contains a battery.
US export classification: 0A504.a

Table of Contents

- [Startpage](#)
- [English: NX8 18X24MM FFP RIFLE SCOPE SAFETY INSTRUCTIONS](#)
- [Norsk: Bruksanvisning for NX8 18X24MM FFP Rifle Scope](#)
- [Svenska: Säkerhetsinstruktioner för NX8 18X24MM FFP RIFLE SCOPE](#)

NX8 18X24MM FFP RIFLE SCOPE SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the NX8 18X24MM FFP Rifle Scope. This guide provides important safety instructions and guidelines to ensure the safe and effective use of your riflescope. Please read this manual thoroughly before use to understand the necessary precautions and recommendations.

General Safety Guidelines

- Ensure the riflescope is used in accordance with local laws and regulations regarding firearms and optics.
- Always treat the riflescope as if it is loaded and handle it with care.
- Keep the riflescope out of reach of children and unauthorized users.
- Regularly inspect the riflescope for any signs of damage or wear before use.
- Store the riflescope in a cool, dry place when not in use.
- Do not expose the riflescope to extreme temperatures or moisture to avoid damage.
- If you experience any malfunction or irregularity, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Use the riflescope only for its intended purpose: short to midrange shooting.
- Always ensure the riflescope is securely mounted to your firearm before use.
- When adjusting the magnification or reticle settings, do so only when the firearm is pointed in a safe direction.
- Avoid looking directly at the sun through the riflescope, as this can cause permanent damage to your eyesight.
- Be aware of your surroundings and ensure a clear line of sight before taking any shots.
- Use protective eyewear when shooting to safeguard against debris and potential injury.
- If using the illumination feature, ensure the battery is installed correctly and is functioning.

Instructions for Installation and Usage

1. Mounting the Riflescope

- Choose a suitable mounting base compatible with the 30mm tube of the NX8 riflescope.
- Securely attach the mounting rings to your firearm, ensuring they are tightened to the manufacturer's specifications.
- Place the riflescope in the rings and adjust its position for optimal eye relief (3.75 inches).
- Tighten the rings securely to prevent movement during use.

2. Adjusting the Reticle

- To adjust the reticle for windage and elevation, use the provided dials.
- Each click corresponds to 0.2 MRAD or 0.50 MOA adjustments. Make adjustments as necessary based on your shooting distance.
- Use the ZeroStop feature to return to your zero setting quickly after adjustments.

3. Using the Illumination Feature

- Insert a CR2032 battery into the illumination compartment, ensuring correct polarity.
- Turn on the illumination by adjusting the control knob to the desired brightness level.
- Always turn off the illumination feature when not in use to conserve battery life.

4. Magnification Adjustments

- Use the builtin Power Throw Lever (PTL) to quickly adjust magnification from 1x to 8x as needed.
- Make adjustments while keeping the firearm pointed in a safe direction.

Disposal Instructions

- Dispose of the riflescope in accordance with local regulations regarding electronic waste and firearms accessories.
- Remove the battery before disposal and recycle it according to local battery disposal guidelines.
- If the riflescope is damaged beyond repair, consult local waste management services for safe disposal options.

Contact Information for Further Support

For safety inquiries, product support, or to report unsafe products, please contact the appropriate local authorities or your retailer. Ensure to keep the product's model number (NX8) and any relevant purchase information handy for reference.

By following these safety instructions, you can ensure a safe and enjoyable experience with your NX8 18X24MM FFP Rifle Scope. Thank you for your attention to safety.

Bruksanvisning for NX8 18X24MM FFP Rifle Scope

Introduksjon

Takk for at du valgte NX8 18X24MM FFP Rifle Scope fra Nightforce. Denne kikkerten er designet for å gi overlegen optisk ytelse og pålitelighet. Det er viktig å følge sikkerhetsinstruksjonene i denne veiledningen for å sikre trygg bruk av produktet.

Generelle sikkerhetsretningslinjer

- Bruk alltid kikkerten i henhold til produsentens instruksjoner.
- Hold kikkerten utilgjengelig for barn og sårbare grupper.
- Unngå å bruke kikkerten under ugunstige værforhold, som kraftig regn eller snø.
- Kontroller alltid at kikkerten er sikkert festet til riflen før bruk.
- Vær oppmerksom på omgivelsene dine og målområdet for å unngå ulykker.
- Rapportere eventuelle usikre produkter eller ulykker til myndighetene.

Spesifikke sikkerhetstiltak for bruk

- Unngå å se direkte inn i solen eller sterke lys, da dette kan skade øynene.
- Bruk alltid beskyttelsesbriller hvis du er i et område med høy risiko for støv eller partikler.
- Sørg for at kikkerten er godt rengjort før bruk for å unngå forvrengning av synet.
- Juster øyeavstanden før bruk for å sikre komfort og sikkerhet.
- For lange skudd, bruk ZeroStop høydejusteringen for å sikre presisjon.

Instruksjoner for installasjon og bruk

1. Installasjon:

- Fjern kikkerten fra emballasjen og kontroller at alle deler er inkludert.
- Monter kikkerten på riflen ved hjelp av et passende monteringsystem.
- Stram festene forsiktig, men unngå å overstramme.

2. Bruk:

- Juster forstørrelsen ved å bruke Power Throw Lever (PTL) for rask tilpassing.
- For å bruke det røde punktet, sørg for at batteriet (CR2032) er installert og fungerer.
- Juster retiklet ved hjelp av 0,2 MRAD eller 0,50 MOA justeringene for presise skudd.
- Når du er klar til å skyte, mål og juster retiklet for å sikre nøyaktighet.

Avfallsinstruksjoner

- Kikkerten og dens komponenter må ikke kastes sammen med vanlig husholdningsavfall.
- Følg lokale retningslinjer for avhending av elektroniske produkter og batterier.
- Sørg for at kikkerten er tom for batterier og eventuelle farlige materialer før avhending.

Kontaktinformasjon for videre støtte

- For spørsmål eller bekymringer angående sikkerhet og bruk av NX8 18X24MM FFP Rifle Scope, vennligst kontakt produsenten eller forhandleren der du kjøpte produktet.

Vi håper at du får glede av din NX8 18X24MM FFP Rifle Scope. Følg alltid sikkerhetsretningslinjene for å sikre en trygg og effektiv opplevelse.

Säkerhetsinstruktioner för NX8 18X24MM FFP RIFLE SCOPE

Introduktion

Tack för att du valt NX8 18X24MM FFP Rifle Scope från Nightforce. Denna kikarsikte är designad för att ge överlägsen optik och prestanda. För att säkerställa säker och effektiv användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Produkten är avsedd för användning av vuxna och bör inte användas av barn utan övervakning.
- Kontrollera alltid att kikarsiktet är korrekt installerat och säkert fäst på vapnet innan användning.
- Använd kikarsiktet endast för avsett ändamål och i enlighet med tillverkarens instruktioner.
- Om produkten skadas eller visar tecken på slitage, avbryt användningen omedelbart och kontakta en professionell för inspektion.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddsglasögon när du skjuter för att skydda ögonen mot eventuella skador.
- Kontrollera alltid att vapnet är oladdat innan du monterar eller justerar kikarsiktet.
- Sikta aldrig på något du inte avser att skjuta på.
- Var medveten om omgivningen och se till att det inte finns några personer eller djur i skottlinjen.
- Justera alltid kikarsiktet i en säker miljö och undvik att göra det under pågående skytte.

Instruktioner för installation och användning

1. Installation av kikarsiktet:

- Fäst kikarsiktet på vapnets monteringsystem enligt tillverkarens instruktioner.
- Se till att kikarsiktet är ordentligt fastsatt för att förhindra rörelse under användning.
- Justera ögonreliefen så att den ger en bekväm siktlinje.

2. Användning av kikarsiktet:

- För att justera förstoringen, vrid på Power Throw Lever (PTL) för att enkelt växla mellan olika förstoringar.
- Använd den centrala röda punkten för att sikta på mål. Justera för avstånd med hjälp av den första fokalplanet retikeln.
- Vid justering av höjd, använd ZeroStopfunktionen för att snabbt återgå till noll.

Avfallshantering

- När kikarsiktet har nått slutet av sin livslängd, vänligen följ lokala riktlinjer för avfallshantering.
- Kasta inte produkten i hushållsavfall. Kontakta lokala myndigheter för korrekt avfallshantering av elektroniska produkter.

Kontaktinformation för ytterligare support

För frågor eller mer information om säkerhet och användning, vänligen kontakta tillverkaren eller din återförsäljare. Se till att ha produktens modellnummer (NX8) tillgängligt för snabbare hjälp.

Rapportering av osäkra produkter

- Om du upptäcker en potentiellt farlig produkt, rapportera detta omedelbart till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser genom att besöka EU:s Safety Gateplattform.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av ditt NX8 18X24MM FFP Rifle Scope. Tack för att du bidrar till en säkrare skyttekultur.