

TURBO CASE CLEANING MEDIA - 4.5 LBS TREATED CORNCOB MEDIA

[Reloading](#) > [Case Cleaning](#) > [Tumbling Media & Additives](#)

Lyman Case Cleaning Media is the most effective choice for cleaning dirty and tarnished cases. A few hours in a Lyman Turbo Tumbler and cases are clean, polished, and ready for reloading.



Attributes

- Name: [4.5 LBS TREATED CORNCOB MEDIA](#)
- Manufacturer: [LYMAN](#)
- Product no.: 749010266
- Mfr. No.: 7631394
- Style: Treated Corncob
- Weight: 4.5 lbs
- Delivery weight: 3.039kg
- Shipping height: 284mm
- Shipping width: 130mm
- Shipping length: 196mm
- UPC: 011516813947

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for TURBO CASE CLEANING MEDIA 4.5 LBS TREATED CORNCOB MEDIA](#)
- [About Us](#)

Safety Instruction Guide for TURBO CASE CLEANING MEDIA 4.5 LBS TREATED CORNCOB MEDIA

Introduction

Thank you for choosing Lyman Case Cleaning Media. This guide provides essential safety instructions and information about the safe use, handling, and disposal of the TURBO CASE CLEANING MEDIA. Please read this guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always keep the product out of reach of children and pets.
- Ensure proper ventilation when using the product to avoid inhalation of dust.
- Do not ingest the product. It is not a food item.
- Store the product in a cool, dry place away from direct sunlight.
- Regularly check for any recalls or safety alerts related to the product on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Wear protective gloves and eyewear when handling the cleaning media to avoid skin and eye irritation.
- Avoid using the media in a confined space without adequate airflow.
- Do not mix with other cleaning agents or chemicals unless specified by the manufacturer.
- Use only as intended, following the instructions provided in this guide.

Instructions for Installation and Usage

1. Preparation

- Ensure that your Lyman Turbo Tumbler is clean and free from any previous media.
- Gather your dirty and tarnished cases that need cleaning.

2. Loading the Tumbler

- Pour the TURBO CASE CLEANING MEDIA into the tumbler until it reaches the recommended fill level.
- Add the cases to be cleaned into the tumbler, ensuring not to overload it.

3. Operating the Tumbler

- Close the tumbler lid securely.
- Plug in the tumbler and turn it on.
- Set the timer according to the level of tarnish on the cases (typically a few hours).
- Monitor the tumbler during operation to ensure it is functioning correctly.

4. PostCleaning

- Once the cleaning cycle is complete, turn off the tumbler and unplug it.
- Carefully open the lid and allow the cases to cool before handling.
- Remove the cleaned cases and dispose of the used cleaning media responsibly.

Disposal Instructions

- Dispose of the used TURBO CASE CLEANING MEDIA in accordance with local regulations.
- Do not dispose of the media in water bodies or open environments.
- If uncertain about disposal methods, contact your local waste management authority for guidance.

Contact Information for Further Support

For any inquiries regarding the product, safety concerns, or additional support, please refer to the contact information provided on the product packaging or the manufacturer's website.

Thank you for your attention to these safety guidelines. Safe cleaning!

About Us

Brownells Switzerland

Brownells Switzerland

www.brownells.ch