

TURBO CASE CLEANING MEDIA - 6 LBS UNTREATED CORNCOB MEDIA

Lyman Case Cleaning Media is the most effective choice for cleaning dirty and tarnished cases. A few hours in a Lyman Turbo Tumbler and cases are clean, polished, and ready for reloading.



Attributes

- Name: 6 LBS UNTREATED CORNCOB MEDIA
- Manufacturer: LYMAN
- Product no.: 749010275
- Mfr. No.: 7631392
- Style: -
- Weight: -
- Delivery weight: 1.588kg
- Shipping height: 284mm
- Shipping width: 132mm
- Shipping length: 196mm
- UPC: 011516813923

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for TURBO CASE CLEANING MEDIA](#)

Safety Instruction Guide for TURBO CASE CLEANING MEDIA

Introduction

Thank you for choosing Lyman Case Cleaning Media. This product is designed to effectively clean and polish dirty and tarnished cases, making them ready for reloading. To ensure your safety and the proper use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always use cleaning media in wellventilated areas to avoid inhalation of dust.
- Keep the product out of reach of children and pets.
- Avoid contact with eyes and skin. If contact occurs, rinse with plenty of water.
- Do not ingest the cleaning media. If swallowed, seek medical attention immediately.
- Store the product in a cool, dry place, away from direct sunlight and heat sources.
- Regularly check for any product recalls or safety updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Wear protective gloves and eyewear when handling the cleaning media to prevent skin and eye irritation.
- Do not mix the cleaning media with other substances or chemicals unless specified by the manufacturer.
- Ensure that the tumbler is properly closed during operation to prevent media spillage.
- Do not operate the tumbler without supervision, especially around children or pets.
- Follow the manufacturer's instructions regarding the amount of media to use in the tumbler.

Instructions for Installation and Usage

1. Setup:

- Place the Lyman Turbo Tumbler on a stable and flat surface.
- Ensure that the tumbler is plugged into a properly grounded outlet.

2. Loading the Tumbler:

- Open the tumbler lid and add the appropriate amount of TURBO CASE CLEANING MEDIA.
- Add the cases you wish to clean, ensuring not to overload the tumbler.

3. Operating the Tumbler:

- Close the tumbler lid securely.
- Plug in the tumbler and turn it on.
- Allow the tumbler to run for the recommended time, usually a few hours, depending on the level of tarnish.

4. After Use:

- Once the cleaning cycle is complete, turn off the tumbler and unplug it.
- Carefully open the lid, avoiding dust exposure.
- Remove the cleaned cases and dispose of used media according to the disposal instructions below.

Disposal Instructions

- Dispose of used TURBO CASE CLEANING MEDIA in accordance with local regulations for nonhazardous waste.
- Do not dispose of the media in waterways or public areas.
- If large quantities are involved, contact local waste management authorities for guidance.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the TURBO CASE CLEANING MEDIA, please refer to the manufacturer's website or customer service resources.

By following these safety instructions, you can ensure the effective and safe use of Lyman Case Cleaning Media. Thank you for your attention to safety.