

RUGER® 42665 GRIP CAP - GRIP CAP 42665 FOR RUGER10/22 & RUGER 77/22 SYNTHETIC BLACK

FITS: 10/22® RBI Blue & SS, .22; 77/22® R, RS, .22 LR; 77/22® RH, RSH, .22 Hornet; 77/22® RM, RSM, .22 Mag



Attributes

- Name: GRIP CAP 42665 FOR RUGER10/22 & RUGER 77/22 SYNTHETIC BLACK
- Manufacturer: RUGER
- Product no.: 780000195
- Mfr. No.:
- Finish: Black
- Make: Ruger
- Material: SYNTHETIC
- Model: 10/22,77/22
- Delivery weight: 0.009kg
- Shipping height: 10mm
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for RUGER® 42665 Grip Cap](#)
- [Svenska: Säkerhetsinstruktioner för RUGER® 42665 Grip Cap](#)

Safety Instruction Guide for RUGER® 42665 Grip Cap

Introduction

Thank you for choosing the RUGER® 42665 Grip Cap. This product is designed to enhance the performance and usability of your RUGER 10/22 and RUGER 77/22 firearms. It is essential to read and understand these safety instructions to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always handle firearms with care and respect.
- Ensure that the grip cap is compatible with your firearm model.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the grip cap for any signs of wear or damage.
- Use the product only as intended and according to the instructions provided.

Specific Safety Precautions for Use

- Do not use the grip cap if it shows signs of damage or if it does not fit securely.
- Avoid exposing the grip cap to extreme temperatures or harsh chemicals.
- Ensure that the grip cap is installed correctly before using the firearm.
- If you experience any issues with the grip cap during use, stop using it immediately and consult a professional.

Instructions for Installation and Usage

1. Installation:

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Remove the existing grip cap, if applicable, by following the manufacturer's guidelines.
- Align the new RUGER® 42665 Grip Cap with the grip of your firearm.
- Press the grip cap firmly into place until it fits snugly and securely.
- Doublecheck the installation to ensure it is properly fitted.

2. Usage:

- Once installed, familiarize yourself with the grip cap and how it affects the handling of your firearm.
- Practice safe handling techniques and always follow the manufacturer's guidelines for your firearm.
- Regularly check the grip cap for any signs of looseness or wear during use.

Disposal Instructions

- Dispose of the grip cap in accordance with local regulations.
- Do not dispose of the grip cap in regular household waste if it is damaged or broken.
- Consider recycling options if available in your area.

Contact Information for Further Support

For any inquiries regarding the RUGER® 42665 Grip Cap, including safety concerns or product support, please refer to the manufacturer's contact information provided in the product packaging or on the official website.

Conclusion

Your safety is our priority. By following these guidelines and instructions, you can ensure the safe use of the RUGER® 42665 Grip Cap. Always stay informed about product recalls and safety updates through the EU's Safety Gate platform. Thank you for your attention to safety.

Säkerhetsinstruktioner för RUGER® 42665 Grip Cap

Introduktion

Tack för att du valt RUGER® 42665 Grip Cap. Denna produkt är designad för att förbättra greppet på din RUGER 10/22 och RUGER 77/22. För att säkerställa säker användning och optimal prestanda, vänligen läs noggrant igenom dessa säkerhetsinstruktioner.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Förvara produkten utom räckhåll för barn och sårbara grupper.
- Rapportera alla skador eller incidenter som involverar produkten till lämpliga myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd produkten endast med de angivna modellerna: RUGER 10/22 och RUGER 77/22.
- Se till att produkten är korrekt installerad innan användning.
- Undvik att använda produkten om den är skadad eller defekt.
- Använd inte produkten i kombination med andra tillbehör som inte är godkända av tillverkaren.
- Var försiktig när du hanterar vapen och följ alltid säkerhetsprotokoll för vapenhantering.

Instruktioner för installation och användning

1. Installation av Grip Cap:

- Se till att vapnet är avstängt och säkert.
- Rengör ytan där Grip Cap ska installeras för att säkerställa en bra kontakt.
- Följ instruktionerna i produktens manual för att installera Grip Cap korrekt.
- Kontrollera att Grip Cap sitter fast ordentligt innan användning.

2. Användning av Grip Cap:

- Håll vapnet med ett fast grepp.
- Kontrollera att Grip Cap inte hindrar någon funktion av vapnet.
- Använd alltid skyddsglasögon och hörselskydd vid avfyrning.

Borttagningsinstruktioner

- När Grip Cap inte längre behövs, ta bort den enligt tillverkarens instruktioner.
- Bortskapa Grip Cap på ett miljövänligt sätt. Kontrollera lokala riktlinjer för avfallshantering.

Kontaktinformation för ytterligare stöd

För frågor eller mer information om produkten, vänligen kontakta tillverkaren eller besök deras officiella webbplats. Se till att du har produktens modellnummer och inköpsinformation tillgänglig.

Avslutande anmärkningar

Genom att följa dessa säkerhetsinstruktioner bidrar du till att säkerställa en trygg och säker användning av RUGER® 42665 Grip Cap. Tack för att du prioriterar säkerhet och ansvar vid användning av våra produkter.