

MAGAZINE LATCH, BLUE

[Rifle Parts](#) > [Receiver Parts](#) > [Magazine Parts](#) > [Magazine Releases](#)

FITS: 77/22® R, RS, .22 LR; 77/22® RH, RSH, .22 Hornet; 77/22® RM, RSM, .22 Mag



Attributes

- Name: [MAGAZINE LATCH, BLUE](#)
- Manufacturer: [RUGER](#)
- Product no.: 780000289
- Mfr. No.: J03400
- Make: Ruger
- Model: 77/22
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [MAGAZINE LATCH, BLUE Safety Instruction Guide](#)
- [About Us](#)

MAGAZINE LATCH, BLUE Safety Instruction Guide

Introduction

Thank you for purchasing the MAGAZINE LATCH, BLUE. This guide provides essential safety instructions and information to ensure the safe use of your product. Please read this guide carefully before installation and use.

General Safety Guidelines

- Ensure the MAGAZINE LATCH is compatible with your firearm model: Ruger 77/22® R, RS, .22 LR; 77/22® RH, RSH, .22 Hornet; 77/22® RM, RSM, .22 Mag.
- Always follow the manufacturer's instructions for your firearm when using the MAGAZINE LATCH.
- Keep the MAGAZINE LATCH out of reach of children and unauthorized users.
- Regularly inspect the MAGAZINE LATCH for any signs of wear or damage before use.
- If you notice any defects or malfunctions, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Always ensure the firearm is unloaded before installing or adjusting the MAGAZINE LATCH.
- Do not attempt to modify or alter the MAGAZINE LATCH. Unauthorized modifications may compromise safety.
- Use the MAGAZINE LATCH only for its intended purpose and with compatible firearms.
- Avoid exposing the MAGAZINE LATCH to extreme temperatures or harsh chemicals, as this may affect its performance.
- If using the MAGAZINE LATCH in adverse weather conditions, ensure it is properly maintained to prevent malfunctions.

Instructions for Installation and Usage

1. Installation

- Ensure the firearm is pointed in a safe direction and is unloaded.
- Remove any existing magazine latch if necessary.
- Align the MAGAZINE LATCH with the designated area on your Ruger firearm.
- Securely fasten the MAGAZINE LATCH according to the manufacturer's instructions.
- Confirm that the MAGAZINE LATCH is installed correctly and is functioning as intended.

2. Usage

- To release the magazine, press the MAGAZINE LATCH as instructed in your firearm's manual.
- Always check the firearm's chamber to ensure it is clear before proceeding with any operation.
- Store the firearm in a secure location when not in use, ensuring the MAGAZINE LATCH is in place.

Disposal Instructions

- Dispose of the MAGAZINE LATCH in accordance with local regulations regarding plastic and metal waste.
- Do not incinerate the MAGAZINE LATCH, as it may release harmful substances when burned.
- If you no longer need the MAGAZINE LATCH, consider returning it to the retailer or manufacturer for proper disposal.

Contact Information for Further Support

For any questions or concerns regarding the MAGAZINE LATCH, please refer to the manufacturer's website or

customer service for assistance. Always ensure you are following the latest safety guidelines and product updates.

Conclusion

The MAGAZINE LATCH, BLUE is designed to provide reliable performance when used correctly. By following the safety instructions outlined in this guide, you can ensure a safe and enjoyable experience with your product. Always prioritize safety and stay informed about best practices for firearm use.

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se