

77/22® BEAD FRONT SIGHT - BEAD FRONT SIGHT .464" FOR RUGER 77/22 BRASS

FITS: 77/22 R, RS, .22 LR; K77/22 RP, RSP, .22 LR; 77/44 RS, .44 Mag; M-96, .22 Mag



Attributes

- Name: BEAD FRONT SIGHT .464" FOR RUGER 77/22 BRASS
- Manufacturer: RUGER
- Product no.: 780000312
- Mfr. No.:
- Color: Gold
- Height: .464
- Make: Ruger
- Material: Brass
- Model: 77/22,77/44,M-96
- Style: Bead
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: RUGER 77/22® Bead Front Sight Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för RUGER 77/22® BEAD FRONT SIGHT](#)

RUGER 77/22® Bead Front Sight Safety Instruction Guide

Introduction

Thank you for choosing the RUGER 77/22® Bead Front Sight. This guide provides essential safety instructions and guidelines to ensure the safe use and installation of your product. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of the reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay updated on product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always handle firearms with care and follow all manufacturer safety guidelines.
- Ensure that the firearm is unloaded before installing or adjusting the front sight.
- Use only compatible models as specified: 77/22 R, RS, .22 LR; K77/22 RP, RSP, .22 LR; 77/44 RS, .44 Mag; M96, .22 Mag.
- Avoid using the product in adverse weather conditions that may affect visibility or handling.
- Do not attempt to modify the product in any way, as this may compromise safety.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the old front sight if necessary, following the manufacturer's instructions.
- Align the RUGER 77/22® Bead Front Sight with the sight base on the firearm.
- Securely fasten the front sight using the appropriate tools, ensuring it is firmly in place.
- Check for proper alignment and stability before proceeding to use the firearm.

2. Usage:

- When aiming, ensure that your eye is aligned with the bead front sight for optimal accuracy.
- Practice safe shooting techniques at all times.
- Regularly clean and maintain the sight to ensure continued performance and safety.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in household waste.
- If the product is damaged or no longer usable, contact local authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries or further assistance regarding the RUGER 77/22® Bead Front Sight, please refer to the manufacturer's contact information available in the product packaging or on the official website.

By following these guidelines, you will help ensure a safe and enjoyable experience with your RUGER 77/22®
Bead Front Sight. Thank you for your attention to safety.

Säkerhetsinstruktioner för RUGER 77/22® BEAD FRONT SIGHT

Introduktion

Tack för att du valt RUGER 77/22® BEAD FRONT SIGHT. Denna produkt är designad för att förbättra din skytteupplevelse. För att säkerställa säker användning och prestanda, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Kontrollera alltid att produkten är i gott skick innan användning.
- Använd produkten endast i enlighet med tillverkarens anvisningar.
- Förvara produkten utom räckhåll för barn och sårbara grupper.
- Rapportera omedelbart eventuella skador eller funktionsfel till en auktoriserad återförsäljare.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd endast RUGER 77/22® BEAD FRONT SIGHT med kompatibla modeller: 77/22 R, RS, .22 LR; K77/22 RP, RSP, .22 LR; 77/44 RS, .44 Mag; M96, .22 Mag.
- Kontrollera att siktet är korrekt installerat innan du använder det.
- Undvik att rikta vapnet mot människor eller djur.
- Använd alltid skyddsglasögon under skytte för att skydda ögonen.

Instruktioner för installation och användning

1. Installation av siktet:

- Ta bort det gamla siktet om det finns något installerat.
- Rengör området där det nya siktet ska monteras.
- Montera RUGER 77/22® BEAD FRONT SIGHT på den angivna platsen och se till att det sitter ordentligt.
- Kontrollera att siktet är i linje med vapnet innan du fäster det helt.

2. Användning av siktet:

- Rikta in siktet med målet noggrant.
- Justera sikteinställningarna vid behov för att säkerställa noggrannhet.
- Efter varje användning, kontrollera siktets integritet och säkerställ att det inte har skadats.

Avfallsinstruktioner

- Kasta inte produkten i vanlig hushållssopor.
- Följ lokala föreskrifter för avfallshantering av metallprodukter.
- Om produkten är defekt eller skadad, kontakta en auktoriserad återförsäljare för korrekt avfallshantering.

Kontaktinformation för vidare support

För frågor eller ytterligare support gällande RUGER 77/22® BEAD FRONT SIGHT, vänligen kontakta en auktoriserad RUGERåterförsäljare eller besök RUGER:s officiella webbplats för mer information.

Dessa säkerhetsinstruktioner är utformade för att säkerställa en säker och effektiv användning av din RUGER

77/22® BEAD FRONT SIGHT. Tack för att du följer dessa riktlinjer.