

RECOIL PLATE, SS

FITS: Bisley™ Large Frame; New Model Blackhawk®; Redhawk® - Common Parts; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®



Attributes

- Name: RECOIL PLATE, SS
- Manufacturer: RUGER
- Product no.: 780000531
- Mfr. No.: KMR02000
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: RECOIL PLATE, SS Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för RECOIL PLATE, SS RUGER RECOIL PLATE, SS](#)

RECOIL PLATE, SS Safety Instruction Guide

Introduction

Thank you for choosing the RECOIL PLATE, SS. This product is designed for specific firearm models and aims to enhance your shooting experience. To ensure safe and effective use, please read this safety instruction guide carefully. It complies with the EU General Product Safety Regulation (GPSR) to provide you with essential safety information.

General Safety Guidelines

- Ensure that the RECOIL PLATE, SS is compatible with your firearm model, including Bisley™ Large Frame, New Model Blackhawk®, Redhawk®, Super Blackhawk®, Super Blackhawk® Hunter, and Vaquero®.
- Always handle firearms responsibly and in accordance with local laws and regulations.
- Store the RECOIL PLATE, SS in a safe place, out of reach of children and unauthorized users.
- Regularly inspect the RECOIL PLATE, SS for signs of wear or damage before each use.
- In case of any malfunction or abnormal behavior, discontinue use immediately and seek professional assistance.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before installing or handling the RECOIL PLATE, SS.
- Use proper tools and follow installation instructions to avoid personal injury or damage to the firearm.
- Do not modify the RECOIL PLATE, SS or the firearm in any way that could compromise safety.
- Always wear appropriate eye and ear protection when using firearms.
- Be aware of your surroundings and ensure a safe shooting environment.

Instructions for Installation and Usage

1. Installation Steps:

- Verify that your firearm is unloaded and pointed in a safe direction.
- Remove the existing recoil plate if applicable, following the manufacturer's instructions.
- Align the RECOIL PLATE, SS with the mounting points on your firearm.
- Secure the RECOIL PLATE, SS using the appropriate screws or fasteners, ensuring they are tightened to the manufacturer's specifications.
- Doublecheck that the RECOIL PLATE, SS is securely attached before use.

2. Usage Guidelines:

- After installation, perform a function check to ensure that the firearm operates correctly.
- Regularly inspect the RECOIL PLATE, SS during use for any signs of looseness or damage.
- Clean the RECOIL PLATE, SS and surrounding areas according to the manufacturer's recommendations to maintain optimal performance.

Disposal Instructions

- Dispose of the RECOIL PLATE, SS in accordance with local regulations regarding electronic and firearm-related waste.
- Do not dispose of the RECOIL PLATE, SS in regular household waste.
- If the product is damaged or no longer in use, consider recycling options or contact local authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please refer to the manufacturer's contact information provided with the product packaging.

By following these guidelines and instructions, you can ensure the safe and effective use of the RECOIL PLATE, SS. Thank you for prioritizing safety in your shooting practices.

Säkerhetsinstruktioner för RECOIL PLATE, SS RUGER RECOIL PLATE, SS

Introduktion

Tack för att du valt RECOIL PLATE, SS RUGER RECOIL PLATE, SS. Denna produkt är avsedd för användning med följande modeller: Bisley™ Large Frame, New Model Blackhawk®, Redhawk®, Super Blackhawk®, Super Blackhawk® Hunter, och Vaquero®. För att säkerställa säker och effektiv användning av denna produkt, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens anvisningar.
- Kontrollera produkten före användning för skador eller defekter.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Rapportera eventuella osäkra produkter eller olyckor till myndigheterna.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd endast produkten med kompatibla vapenmodeller.
- Kontrollera att recoilplattan är korrekt installerad innan användning.
- Var försiktig när du hanterar vapen; alltid behandla dem som om de är laddade.
- Använd skyddsglasögon och hörselskydd vid skjutning.
- Undvik att använda produkten om du är trött eller under påverkan av alkohol eller droger.

Instruktioner för installation och användning

1. Installation:

- Se till att vapnet är avstängt och ur funktion.
- Ta bort den gamla recoilplattan om en sådan finns.
- Rengör området där den nya recoilplattan ska installeras.
- Placera den nya recoilplattan på plats och se till att den sitter ordentligt.
- Kontrollera att alla skruvar eller fästen är åtdragna enligt tillverkarens specifikationer.

2. Användning:

- Följ alltid säkerhetsprotokoll för vapenhantering.
- Kontrollera recoilplattan regelbundet för slitage eller skador.
- Om du upptäcker några problem, avbryt användningen omedelbart och kontakta en kvalificerad tekniker.

Avfallsanvisningar

- Kassera eventuella defekta delar i enlighet med lokala avfallshanteringsföreskrifter.
- Återvinn materialet när det är möjligt, i enlighet med lokala riktlinjer för återvinning.

Kontaktinformation för ytterligare stöd

För frågor eller support, vänligen kontakta din lokala återförsäljare eller tillverkare. Se till att ha produktens modell och serienummer tillgängligt för snabbare assistans.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att göra det bidrar du till en säkrare användning av din RECOIL PLATE, SS RUGER RECOIL PLATE, SS.