

BUFFER CROSS PIN, SS

FITS: Mini-14® Ranch Rifle Serial # Prefix 187-188, .223; Mini-30®, 7.62 x 39



Attributes

- Name: BUFFER CROSS PIN, SS
- Manufacturer: RUGER
- Product no.: 780000573
- Mfr. No.: KMS06610
- Make: Ruger
- Model: Mini-14,Mini-30
- Delivery weight: 0.009kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for BUFFER CROSS PIN, SS](#)
- [Svenska: Säkerhetsinstruktioner för BUFFER CROSS PIN, SS RUGER](#)

Safety Instruction Guide for BUFFER CROSS PIN, SS

Introduction

Thank you for purchasing the BUFFER CROSS PIN, SS. This product is designed to enhance the performance of your Mini14® Ranch Rifle and Mini30® firearm models. Your safety is our priority, and this guide provides essential information to ensure the safe use, installation, and disposal of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the BUFFER CROSS PIN is compatible with your firearm model before installation.
- Always handle firearms with care and follow all safety protocols.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the BUFFER CROSS PIN for any signs of wear or damage.
- In case of any safety concerns or product issues, report them to the relevant authorities.

Specific Safety Precautions for Use

- Only use the BUFFER CROSS PIN with Mini14® Ranch Rifle Serial # Prefix 187188, .223, and Mini30®, 7.62 x 39 models.
- Do not modify the BUFFER CROSS PIN or use it in any manner other than as intended.
- Wear appropriate safety gear, such as eye protection, when handling firearms.
- Ensure that the firearm is unloaded before installing or removing the BUFFER CROSS PIN.
- Follow the manufacturer's guidelines for the safe operation of your firearm.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is completely unloaded and pointed in a safe direction.
- Gather necessary tools for installation, including a punch tool if required.

2. Installation Steps:

- Locate the BUFFER CROSS PIN area on your firearm.
- Align the BUFFER CROSS PIN with the designated slot.
- Gently insert the BUFFER CROSS PIN into place using the punch tool if necessary.
- Ensure that the BUFFER CROSS PIN is securely fitted and does not move.

3. PostInstallation Check:

- Verify that the BUFFER CROSS PIN is properly installed and seated.
- Conduct a function check of the firearm to ensure that it operates correctly with the new part.

4. Usage:

- Regularly check the BUFFER CROSS PIN during routine maintenance of your firearm.
- If you experience any malfunctions or issues, discontinue use immediately and consult a qualified gunsmith.

Disposal Instructions

- Dispose of the BUFFER CROSS PIN in accordance with local regulations.
- Do not dispose of the product in household waste.
- Consider recycling if applicable, or contact local waste management for proper disposal methods.

Contact Information for Further Support

For any inquiries or further support regarding the BUFFER CROSS PIN, please refer to the product packaging or visit the manufacturer's website for additional contact information. Ensure that you have the product details at hand for efficient assistance.

By following these safety instructions, you can help ensure a safe and enjoyable experience with your BUFFER CROSS PIN, SS. Always prioritize safety and adhere to the guidelines provided. Thank you for your commitment to responsible firearm ownership.

Säkerhetsinstruktioner för BUFFER CROSS PIN, SS RUGER

Introduktion

Tack för att du valt BUFFER CROSS PIN, SS RUGER. Denna produkt är designad för användning med Mini14® Ranch Rifle och Mini30® och är avsedd att säkerställa säker och effektiv drift av ditt vapen. För att garantera en säker användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Kontrollera att produkten är i gott skick och fri från skador innan användning.
- Förvara produkten utom räckhåll för barn och andra otillbörliga användare.
- Rapportera osäkra produkter eller olyckor till relevanta myndigheter.
- Kontrollera regelbundet EU:s Safety Gateplattform för uppdateringar om produktåterkallelser.

Specifika säkerhetsåtgärder för användning

- Använd enbart BUFFER CROSS PIN, SS RUGER med Mini14® Ranch Rifle och Mini30®.
- Kontrollera att serienummerprefixet på ditt vapen är 187188, .223 för Mini14® eller 7.62 x 39 för Mini30®.
- Undvik att använda produkten om den är skadad eller sliten.
- Använd skyddsglasögon och hörselskydd vid installation och användning.
- Följ alltid säkerhetsföreskrifterna för vapnet i fråga.

Instruktioner för installation och användning

1. Förberedelse:

- Se till att vapnet är avstängt och att ingen ammunition finns i närheten.
- Använd ett rent arbetsområde för att undvika föroreningar.

2. Installation:

- Placera BUFFER CROSS PIN i det avsedda utrymmet på vapnet.
- Se till att pinnen sitter ordentligt på plats och att inga delar är lösa.

3. Användning:

- Kontrollera att vapnet fungerar korrekt efter installation av BUFFER CROSS PIN.
- Utför regelbundna kontroller av produkten för att säkerställa att den fungerar som avsett.

Avfallshantering

- Kassera produkten enligt lokala bestämmelser för avfallshantering.
- Undvik att slänga produkten i vanligt hushållsavfall om den är skadad eller innehåller farliga material.

Kontaktinformation för vidare support

För ytterligare information eller support, vänligen kontakta den angivna kontaktpunkten i ditt EUland. Se till att ha produktens serienummer och inköpsinformation tillgänglig vid kontakt.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.