

MAINSRING, SS

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainsprings](#)

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®; New Model Single-Six®; Super Blackhawk, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®



Attributes

- Name: [MAINSRING, SS](#)
- Manufacturer: [RUGER](#)
- Product no.: 780000717
- Mfr. No.:
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for MAINSPRING, SS](#)
- [About Us](#)

Safety Instruction Guide for MAINSPRING, SS

Introduction

Thank you for choosing the MAINSPRING, SS. This guide provides essential safety instructions to ensure the safe use and maintenance of your product. Please read this document carefully before using the product to avoid any potential hazards.

General Safety Guidelines

- Always handle the MAINSPRING, SS with care to prevent injury.
- Ensure that your firearm is unloaded before installing or handling the mainspring.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the mainspring for signs of wear or damage.
- In case of any malfunction or abnormal behavior, cease use immediately and consult a qualified gunsmith.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recall updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Only use the MAINSPRING, SS with compatible models:
 - Bisley™ Large Frame
 - Bisley™ Small Frame
 - New Model Blackhawk®
 - New Model SingleSix®
 - Super Blackhawk, .44 Mag
 - Super Blackhawk® Hunter, .44 Mag
 - Vaquero®
- Do not modify the mainspring or any part of your firearm.
- Always wear appropriate eye and ear protection when using firearms.
- Ensure that the firearm is pointed in a safe direction at all times during handling.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools for installation, including a screwdriver and pliers.

2. Installation Steps:

- Remove the grip from the firearm to access the mainspring compartment.
- Remove the old mainspring by unscrewing the retaining screws.
- Carefully place the new MAINSPRING, SS into the compartment, ensuring it is seated properly.
- Reattach the retaining screws securely.
- Replace the grip and ensure it is fitted correctly.

3. Usage Instructions:

- After installation, conduct a function check to ensure the mainspring operates correctly.
- Follow all manufacturer guidelines for the operation of your specific firearm model.
- Regularly clean and maintain the mainspring to ensure optimal performance.

Disposal Instructions

- Dispose of the MAINSPRING, SS in accordance with local regulations for hazardous materials.
- Do not dispose of the mainspring in regular household waste.
- Contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For safety inquiries or additional support, please reach out to your local firearms dealer or manufacturer's representative. Ensure you have your product information ready for assistance.

Thank you for prioritizing safety while using the MAINSPRING, SS. By following these guidelines, you contribute to a safer shooting experience for yourself and those around you.

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se