

GRIP FRAME SCREW FOR RUGER® REVOLVERS - GRIP FRAME SCREW RUGER LARGE FRAME BISLEY, B-BACK, SS

FITS: New Model Blackhawk®; New Model Single-Six®; Old Army™, .45; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®



Attributes

- Name: GRIP FRAME SCREW RUGER LARGE FRAME BISLEY, B-BACK, SS
- Manufacturer: RUGER
- Product no.: 780001221
- Mfr. No.: KBR01801
- Make: Ruger
- Model: Bisley
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: GRIP FRAME SCREW FOR RUGER® REVOLVERS Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för GRIP FRAME SCREW FÖR RUGER® REVOLVERS](#)

GRIP FRAME SCREW FOR RUGER® REVOLVERS

Safety Instruction Guide

Introduction

Thank you for choosing the Grip Frame Screw for Ruger® Revolvers. This guide provides essential safety information and instructions for the proper use and installation of the product. Please read this document carefully to ensure safe handling and operation.

General Safety Guidelines

- Always ensure that the firearm is unloaded before performing any maintenance or installation.
- Keep the product out of reach of children and unauthorized users.
- Inspect the product for any visible damage or defects before use. Do not use if damaged.
- Follow all manufacturer guidelines and safety procedures when handling firearms.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the Grip Frame Screw is compatible with your Ruger® model before installation.
- Use appropriate tools to install the screw to avoid damaging the firearm or the screw itself.
- Do not modify the Grip Frame Screw in any way.
- Avoid using excessive force during installation to prevent stripping the screw threads.
- Always wear safety glasses when performing maintenance on firearms.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather the necessary tools: a screwdriver suitable for the screw head.

2. Installation Steps:

- Locate the grip frame of your Ruger® revolver.
- Align the Grip Frame Screw with the designated hole in the grip frame.
- Carefully insert the screw into the hole.
- Using the screwdriver, tighten the screw gently until secure. Do not overtighten.

3. PostInstallation:

- Inspect the installation to ensure that the screw is secure and the grip is properly attached.
- Perform a function check on the firearm to ensure it operates correctly.

Disposal Instructions

- Dispose of any damaged or unused Grip Frame Screws in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Grip Frame Screw for Ruger® Revolvers, please refer to the manufacturer's customer service resources or your local firearms authority.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of the Grip Frame Screw for Ruger® Revolvers. Always prioritize safety and consult professionals if you have any doubts or concerns about firearm maintenance and operation.

Säkerhetsinstruktioner för GRIP FRAME SCREW FÖR RUGER® REVOLVERS

Introduktion

Tack för att du har valt GRIP FRAME SCREW för Ruger® revolver. Denna produkt är utformad för att ge säker och effektiv användning av din revolver. För att säkerställa en trygg användning, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar för att minimera riskerna.
- Kontrollera produkten regelbundet för slitage eller skador.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Rapportera osäkra produkter och olyckor till myndigheterna.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Kontrollera att skruven är korrekt installerad innan användning av revolvern.
- Använd endast skruven med kompatibla modeller: New Model Blackhawk®, New Model SingleSix®, Old Army™, Super Blackhawk®, Super Blackhawk® Hunter och Vaquero®.
- Undvik att använda produkten om den är skadad eller inte fungerar som avsett.
- Använd skyddsglasögon när du installerar eller justerar skruven för att skydda ögonen från eventuella skröp.
- Följ alla säkerhetsföreskrifter för hantering av vapen.

Instruktioner för installation och användning

1. Förberedelse:

- Se till att revolvern är avsäkrad och att inget ammunition finns i närheten.
- Samla nödvändiga verktyg för installationen, inklusive en skruvmejsel av rätt storlek.

2. Installation:

- Ta bort den gamla skruven om det behövs.
- Placera den nya GRIP FRAME SCREW i rätt position.
- Använd skruvmejseln för att försiktigt dra åt skruven. Var försiktig så att du inte överdrar, vilket kan skada materialet.

3. Kontroll:

- Kontrollera att skruven sitter ordentligt och att inget spel finns.
- Testa revolvern för att säkerställa att allt fungerar korrekt.

Kassationsinstruktioner

- Kassera produkten på ett säkert sätt om den är skadad eller inte längre behövs.
- Följ lokala riktlinjer för avfallshantering av metallprodukter.
- Undvik att kasta produkten i hushållssoporna om det finns särskilda regler för metallavfall i ditt område.

Kontaktinformation för ytterligare stöd

För frågor eller ytterligare information, vänligen kontakta en auktoriserad återförsäljare eller besök tillverkarens officiella webbplats för mer information om produktsäkerhet och support.

Tack för att du prioriterar säkerheten vid användning av GRIP FRAME SCREW för Ruger® revolvers. Genom att följa dessa instruktioner bidrar du till en säker och effektiv användning av din produkt.