

EJECTOR ROD ASSEMBLY FOR RUGER® NEW VAQUERO - EJECTOR ROD ASSEMBLY BLUED

Factory replacement ejector rod assembly for Ruger® New Vaquero revolvers chambered in .357 Magnum; .38 Special; .44-40 Winchester; .44 Magnum; .44 Special and .45 Colt calibers.



Attributes

- Name: EJECTOR ROD ASSEMBLY BLUED
- Manufacturer: RUGER
- Product no.: 780001297
- Mfr. No.:
- Make: Ruger
- Model: New Vaquero
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Ejector Rod Assembly Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för EJECTOR ROD ASSEMBLY för RUGER® NEW VAQUERO](#)

Ejector Rod Assembly Safety Instruction Guide

Introduction

Thank you for choosing the Ejector Rod Assembly for Ruger® New Vaquero. This product is designed to provide reliable performance for your revolver. To ensure your safety and the safety of others, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always treat firearms with respect and handle them as if they are loaded.
- Ensure that the ejector rod assembly is compatible with your specific model of Ruger® New Vaquero.
- Store the ejector rod assembly in a safe place, away from children and unauthorized users.
- Regularly inspect the ejector rod assembly for any signs of damage or wear before use.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Do not use the ejector rod assembly if it shows any signs of damage.
- Avoid using excessive force when installing or using the ejector rod assembly.
- Ensure that the revolver is pointed in a safe direction during installation and usage.
- Always wear appropriate safety gear, including eye protection, when handling firearms.
- If you experience any malfunctions while using the ejector rod assembly, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the revolver is unloaded and pointed in a safe direction.
- Gather necessary tools for installation (if applicable).

2. Installation:

- Remove the existing ejector rod assembly from the revolver by following the manufacturer's instructions.
- Align the new ejector rod assembly with the mounting point on the revolver.
- Secure the assembly in place, ensuring it is firmly attached but not overtightened.

3. Usage:

- Use the ejector rod assembly as intended, ensuring the revolver is in a safe and stable position.
- Regularly check the assembly during use to ensure it remains secure and functional.

Disposal Instructions

- Dispose of any damaged or worn ejector rod assemblies in accordance with local regulations.
- Do not dispose of the ejector rod assembly in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety concerns, product performance, or additional support, please contact the manufacturer or a qualified professional. Always refer to the manufacturer's guidelines for specific assistance.

related to your product.

Thank you for prioritizing safety and compliance with these guidelines. Enjoy your Ruger® New Vaquero safely!

Säkerhetsinstruktioner för EJECTOR ROD ASSEMBLY för RUGER® NEW VAQUERO

Introduktion

Tack för att du har valt EJECTOR ROD ASSEMBLY för RUGER® NEW VAQUERO. Denna produkt är en fabriksersättning för utdragarsystemet i Ruger® New Vaquero revolverar. För att säkerställa säker och korrekt användning av produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens anvisningar.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Förvara produkten på en säker plats, utom räckhåll för barn.
- Rapportera omedelbart eventuella farliga produkter eller olyckor till myndigheterna.
- Håll dig informerad om återkallelser genom EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd endast produkten med Ruger® New Vaquero revolverar som anges i produktbeskrivningen.
- Undvik att använda produkten om den verkar vara skadad eller defekt.
- Följ alltid säkerhetsföreskrifterna för hantering av skjutvapen.
- Använd skyddsglasögon och hörselskydd vid skjutning.
- Säkerställ att vapnet är i ett säkert tillstånd innan du installera eller avlägsnar utdragarsystemet.

Instruktioner för installation och användning

1. Förberedelse:

- Kontrollera att du har rätt verktyg och reservdelar innan installationen.
- Se till att vapnet är avstängt och att inget ammunition finns i närheten.

2. Installation:

- Ta bort det gamla utdragarsystemet genom att följa tillverkarens anvisningar.
- Installera EJECTOR ROD ASSEMBLY genom att fästa den på rätt plats och säkerställa att den är ordentligt på plats.
- Kontrollera att alla skruvar och fästen är åtdragna enligt tillverkarens specifikationer.

3. Användning:

- Använd produkten endast för avsett ändamål.
- Utför regelbundna kontroller för att säkerställa att utdragarsystemet fungerar korrekt.

Avfallshantering

- Kasta inte produkten i hushållsavfall.
- Följ lokala riktlinjer för avfallshantering av vapenrelaterade produkter.
- Kontakta en auktoriserad återvinningsstation för korrekt avfallshantering.

Kontaktinformation för vidare support

För mer information om säkerhetsåtgärder och produktanvändning, vänligen kontakta tillverkaren eller din lokala återförsäljare. Se till att ha produktens modellnummer och serienummer till hands för snabbare hjälp.

Dessa säkerhetsinstruktioner syftar till att skydda användaren och säkerställa korrekt användning av EJECTOR ROD ASSEMBLY för RUGER® NEW VAQUERO. Tack för att du tar ansvar för din säkerhet och andra runt omkring dig.