

EJECTOR ROD ASSEMBLY FOR RUGER® NEW VAQUERO - EJECTOR ROD ASSEMBLY SS

[Handgun Parts](#) > [Action Parts](#) > [Ejector Parts](#) > [Ejector Rod Assemblies](#)

Factory replacement ejector rod assembly for Ruger® New Vaquero revolvers chambered in .357 Magnum; .38 Special; .44-40 Winchester; .44 Magnum; .44 Special and .45 Colt calibers.



Attributes

- Name: [EJECTOR ROD ASSEMBLY SS](#)
- Manufacturer: [RUGER](#)
- Product no.: 780001298
- Mfr. No.: KMVQ10800
- Make: Ruger
- Model: New Vaquero
- Delivery weight: 0.009kg
- Shipping height: 1mm
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [EJECTOR ROD ASSEMBLY FOR RUGER® NEW VAQUERO SAFETY INSTRUCTIONS](#)
- [About Us](#)

EJECTOR ROD ASSEMBLY FOR RUGER® NEW VAQUERO SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the Ejector Rod Assembly for your Ruger® New Vaquero revolver. This guide provides important safety information and instructions to ensure the safe use of your product. Please read this manual carefully before installation and usage.

General Safety Guidelines

- Ensure that the ejector rod assembly is compatible with Ruger® New Vaquero revolvers chambered in .357 Magnum, .38 Special, .4440 Winchester, .44 Magnum, .44 Special, and .45 Colt calibers.
- Always handle firearms with care. Treat every firearm as if it is loaded.
- Keep the ejector rod assembly and all firearm components out of reach of children and unauthorized users.
- Regularly inspect your firearm and its components for wear and damage.
- Follow all local laws and regulations regarding firearm ownership and usage.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls and safety updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not attempt to install the ejector rod assembly if you are not familiar with firearm maintenance and assembly.
- Always ensure the firearm is unloaded before performing any maintenance or installation.
- Wear appropriate personal protective equipment (PPE), such as safety glasses, during installation.
- Avoid using excessive force when installing the ejector rod assembly to prevent damage to the firearm.
- If you experience any difficulties during installation, stop immediately and seek professional assistance.

Instructions for Installation and Usage

1. Preparation:

- Ensure your workspace is clean and welllit.
- Gather all necessary tools for installation, including screwdrivers and any specific tools recommended by the manufacturer.

2. Installation Steps:

- Ensure the firearm is unloaded. Remove any ammunition from the area.
- Remove the existing ejector rod assembly from the revolver according to the manufacturer's instructions.
- Align the new ejector rod assembly with the mounting points on the revolver.
- Carefully secure the assembly in place using the appropriate screws or fasteners.
- Doublecheck that the assembly is firmly attached and that there are no loose parts.

3. PostInstallation:

- Conduct a function check to ensure that the ejector rod operates smoothly.
- Store the firearm in a secure location when not in use.

Disposal Instructions

- Dispose of any old or damaged ejector rod assemblies in accordance with local regulations.
- Do not dispose of firearm components in regular household waste. Contact local authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding the Ejector Rod Assembly or safety concerns, please contact the manufacturer or your local firearms dealer. They will provide you with the necessary assistance and support.

Please remember that safety is paramount when handling firearms. Always prioritize safety and responsible usage to protect yourself and others.

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se