

# MAGAZINE LATCH PIVOT/EJECTOR PIN

[Rifle Parts](#) > [Bolt Parts](#) > [Ejector Parts](#) > [Ejector Pins](#)

FITS: 10/22® - Common Parts, .22; M-96®, .22, .22 Mag, .44 Mag



## Attributes

- Name: [MAGAZINE LATCH PIVOT/EJECTOR PIN](#)
- Manufacturer: [RUGER](#)
- Product no.: 780010022
- Mfr. No.:
- Make: Ruger
- Model: 10/22,M-96
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [MAGAZINE LATCH PIVOT/EJECTOR PIN Safety Instruction Guide](#)
- [About Us](#)

# MAGAZINE LATCH PIVOT/EJECTOR PIN Safety Instruction Guide

## Introduction

Thank you for choosing the MAGAZINE LATCH PIVOT/EJECTOR PIN. This guide provides essential safety instructions to ensure the safe use of this product. It complies with the EU General Product Safety Regulation (GPSR) to protect consumers and enhance safety.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe products or accidents to the relevant authorities.
- Always check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Use the MAGAZINE LATCH PIVOT/EJECTOR PIN only with compatible firearms, specifically:
  - Ruger 10/22
  - Ruger M96
- Always handle firearms safely and responsibly.
- Wear appropriate safety gear when handling firearms.
- Ensure that the firearm is unloaded before installation or maintenance.
- Follow all local laws and regulations regarding firearm use and modifications.

## Instructions for Installation and Usage

### 1. Preparation

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, such as screwdrivers or pliers.

### 2. Installation Steps

- Locate the magazine latch pivot/ejector pin area on your firearm.
- Remove the old magazine latch pivot/ejector pin if applicable.
- Insert the new MAGAZINE LATCH PIVOT/EJECTOR PIN into the designated slot.
- Ensure that the pin is securely in place.

### 3. Usage

- After installation, check the functionality of the magazine latch.
- Test the ejector pin to ensure it operates correctly.
- Regularly maintain the firearm and its components for optimal performance.

## Disposal Instructions

- Dispose of any old or damaged parts in accordance with local regulations.
- Do not dispose of the product in household waste.
- Check for local recycling programs that accept firearm components.

## **Contact Information for Further Support**

For any questions or concerns regarding the MAGAZINE LATCH PIVOT/EJECTOR PIN, please refer to your local authorized dealer or manufacturer for assistance.

By following these guidelines, you ensure not only your safety but also the safety of others while using the MAGAZINE LATCH PIVOT/EJECTOR PIN. Thank you for your attention to these important safety measures.

# About Us

## Brownells Sverige

**Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör**

Brownells Sverige AB  
Box 99  
793 22 Leksand  
Sverige

[www.brownells.se](http://www.brownells.se)