

BOLT LOCK FOR RUGER 10/22 BLACK

FITS: 10/22® DSP, .22 LR; 10/22® R,RB, .22 LR; 10/22® RBI Blue & SS, .22 LR;
10/22® RBM Magnum, .22 LR



Attributes

- Name: BOLT LOCK FOR RUGER 10/22 BLACK
- Manufacturer: RUGER
- Product no.: 780010027
- Mfr. No.: B41B
- Make: Ruger
- Model: 10/22
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for BOLT LOCK FOR RUGER 10/22 BLACK](#)
- [Svenska: Säkerhetsinstruktioner för BOLT LOCK för RUGER 10/22](#)

Safety Instruction Guide for BOLT LOCK FOR RUGER 10/22 BLACK

Introduction

Thank you for choosing the BOLT LOCK FOR RUGER 10/22 BLACK. This product is designed to enhance the safety and functionality of your Ruger 10/22 firearm. Please read this safety instruction guide carefully to ensure proper use and maintenance. Following these guidelines will help you avoid potential hazards and ensure a safe experience.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Ensure that the BOLT LOCK is compatible with your model of Ruger 10/22 before installation.
- Keep the BOLT LOCK out of reach of children and unauthorized users.
- Regularly inspect the BOLT LOCK for any signs of wear or damage.
- Do not use the BOLT LOCK if it is damaged or malfunctioning.
- Always follow the manufacturer's instructions for your Ruger 10/22 firearm.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before installing or removing the BOLT LOCK.
- Do not attempt to modify the BOLT LOCK or use it in any way other than intended.
- Avoid using the BOLT LOCK in wet or humid conditions, as this may affect its performance.
- Store the BOLT LOCK in a dry, cool place when not in use.
- Be aware of your surroundings and ensure that no one is in the line of fire when using your firearm.

Instructions for Installation and Usage

Installation Steps

1. **Ensure Safety:** Confirm that your Ruger 10/22 is completely unloaded.
2. **Remove Existing Bolt:** Follow the manufacturer's instructions to safely remove the bolt from your firearm.
3. **Insert BOLT LOCK:** Place the BOLT LOCK into the bolt assembly area, ensuring it fits securely.
4. **Reattach Bolt:** Carefully reattach the bolt, ensuring that the BOLT LOCK is properly engaged.
5. **Function Check:** Perform a function check to ensure the BOLT LOCK is operating correctly. This includes checking the bolt's movement and functionality.
6. **Final Inspection:** Inspect the installation to ensure everything is secure and correctly positioned.

Usage Guidelines

- Always ensure that the BOLT LOCK is engaged when the firearm is not in use.
- Familiarize yourself with the operation of the BOLT LOCK before using your firearm.
- Regularly check the BOLT LOCK during routine maintenance of your firearm.

Disposal Instructions

- Dispose of the BOLT LOCK in accordance with local regulations.
- Do not dispose of the BOLT LOCK in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety, installation, or product performance, please refer to the manufacturer's website or customer support resources. It is essential to have access to guidance from qualified professionals.

By following these safety instructions, you can ensure the safe and effective use of the BOLT LOCK FOR RUGER 10/22 BLACK. Always prioritize safety and responsible handling of your firearm. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för BOLT LOCK för RUGER 10/22

Introduktion

Tack för att du valt BOLT LOCK för RUGER 10/22. Denna produkt är utformad för att öka säkerheten och funktionaliteten hos din RUGER 10/22. För att säkerställa en säker och korrekt användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar för att undvika skador.
- Kontrollera att produkten är i gott skick innan användning.
- Förvara produkten utom räckhåll för barn och andra känsliga grupper.
- Rapportera eventuella skador eller defekter till tillverkaren omedelbart.
- Håll dig informerad om eventuella återkallelser av produkten via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder vid användning

- Använd BOLT LOCK endast med kompatibla modeller av RUGER 10/22, inklusive:
 - 10/22® DSP, .22 LR
 - 10/22® R,RB, .22 LR
 - 10/22® RBI Blå & SS, .22 LR
 - 10/22® RBM Magnum, .22 LR
- Kontrollera att låset är korrekt installerat innan varje användning.
- Använd aldrig produkten om den är skadad eller om det finns tecken på slitage.
- Undvik att använda produkten i ogynnsamma väderförhållanden som kraftigt regn eller snö.

Instruktioner för installation och användning

1. Installation av BOLT LOCK:

- Se till att vapnet är oladdat och säkert.
- Följ installationsanvisningarna i produktens bruksanvisning noggrant.
- Kontrollera att BOLT LOCK är ordentligt fäst och fungerar som avsett.

2. Användning av BOLT LOCK:

- När vapnet inte används, se till att BOLT LOCK är på plats för att förhindra oavsiktlig avfyrning.
- Kontrollera regelbundet att låset fungerar korrekt och att det inte har några skador.
- Vid avfyrning, ta bort BOLT LOCK enligt anvisningarna innan du använder vapnet.

Avfallsanvisningar

- Kassera produktens förpackning och eventuella oanvända delar på ett miljövänligt sätt.
- Följ lokala föreskrifter för avfallshantering för att säkerställa korrekt bortskaffande av produkten.

Kontaktinformation för vidare support

För frågor eller ytterligare information om produkten, vänligen kontakta tillverkaren eller besök deras officiella hemsida.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av BOLT LOCK

för RUGER 10/22. Tack för att du bidrar till en säkrare användning av ditt vapen.