

# SIGHT CROSS PIN, FRONT, SS

FITS: Bisley™ Large Frame; New Model Blackhawk®; Old Army™, .45



## Attributes

- Name: SIGHT CROSS PIN, FRONT, SS
- Manufacturer: RUGER
- Product no.: 780012009
- Mfr. No.:
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for SIGHT CROSS PIN, FRONT, SS](#)
- [Svenska: Säkerhetsinstruktioner för SIGHT CROSS PIN, FRONT, SS RUGER](#)

# Safety Instruction Guide for SIGHT CROSS PIN, FRONT, SS

## Introduction

Thank you for choosing the SIGHT CROSS PIN, FRONT, SS. This guide provides essential safety instructions, installation procedures, and usage guidelines to ensure safe operation and maintenance of your product. Please read this guide thoroughly before use.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified in this guide.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product regularly for signs of wear or damage.
- Do not use the product if it appears damaged or malfunctioning.
- Follow all local laws and regulations regarding the use of firearm accessories.

## Specific Safety Precautions for Use

- Always handle firearms with care and follow standard firearm safety practices.
- Ensure that the firearm is unloaded before installing or adjusting the sight cross pin.
- Wear appropriate safety gear, such as safety glasses, when working with firearms.
- Do not attempt to modify the sight cross pin or use it in a manner not specified in this guide.
- Be aware of your surroundings and ensure that you are in a safe environment when handling firearms.

## Instructions for Installation and Usage

### 1. Installation Instructions:

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Remove any existing sight pins as per the manufacturer's instructions.
- Align the SIGHT CROSS PIN, FRONT, SS with the sight mounting area of the firearm.
- Securely fasten the sight cross pin using the appropriate tools, ensuring it is properly seated.
- Check that the sight is stable and does not move when pressure is applied.

### 2. Usage Instructions:

- After installation, perform a function check to ensure the sight is properly aligned.
- Familiarize yourself with the sight's adjustments and settings.
- Regularly clean the sight to maintain visibility and performance.
- If you experience any issues with sight alignment or stability, consult a qualified gunsmith.

## Disposal Instructions

- Dispose of the product in accordance with local waste management regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options for metal components if available.

## Contact Information for Further Support

For any inquiries regarding safety or product issues, please reach out to your local authorized dealer or manufacturer. Ensure that you have the product's model and serial number available for reference.

By following these guidelines, you will help ensure your safety and the proper functioning of the SIGHT CROSS PIN, FRONT, SS. Always prioritize safety when handling and using firearms and their accessories. Thank you for your attention to these important safety instructions.

# Säkerhetsinstruktioner för SIGHT CROSS PIN, FRONT, SS RUGER

## Introduktion

Tack för att du valt SIGHT CROSS PIN, FRONT, SS för din Ruger pistol. Denna produkt är utformad för att ge en säker och effektiv användning. För att säkerställa din säkerhet och produktens funktion, vänligen följ dessa säkerhetsinstruktioner noggrant.

## Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Förvara produkten utom räckhåll för barn och andra sårbara grupper.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallelser genom EU:s Safety Gateplattform.

## Specifika säkerhetsåtgärder för användning

- Använd inte produkten om den är skadad eller defekt.
- Se till att produkten är korrekt installerad innan användning.
- Använd skyddsglasögon och handskar vid installation för att skydda dig mot eventuella skador.
- Följ alltid säkerhetsföreskrifterna för din Ruger pistol när du använder denna produkt.

## Instruktioner för installation och användning

### 1. Installation av SIGHT CROSS PIN, FRONT, SS:

- Kontrollera att du har rätt verktyg tillgängliga för installationen.
- Ta bort den gamla sight cross pin om den är installerad.
- Placera den nya sight cross pin i det avsedda utrymmet.
- Se till att den är ordentligt på plats innan du fortsätter.

### 2. Användning av produkten:

- Använd produkten endast med kompatibla Rugermodeller: Bisley™ Large Frame, New Model Blackhawk®, och Old Army™, .45.
- Kontrollera att produkten fungerar korrekt innan varje användning.
- Följ alltid tillverkarens instruktioner för din Ruger pistol.

## Avfallshantering

- Kasta inte produkten i hushållsavfall.
- Följ lokala riktlinjer för avfallshantering och återvinning av metallprodukter.
- Om du är osäker på hur du ska göra, kontakta din lokala avfallshanteringsmyndighet för vägledning.

## Kontaktinformation för vidare support

För frågor eller ytterligare information om säkerhet och användning av SIGHT CROSS PIN, FRONT, SS, vänligen kontakta tillverkaren eller din lokala återförsäljare.

Vi tackar för att du följer dessa säkerhetsinstruktioner och önskar dig en säker och framgångsrik användning av din produkt.