

GRIP PANEL SCREW, SS

[Handgun Parts](#) > [Grip Parts](#) > [Grip Screws](#)

FITS: Bisley™ - Common Parts; New Model Blackhawk®; New Model Single-Six®; Old Army†, .45; Super Blackhawk®, .44 Mag; Super Blackhawk Hunter®, .44 Mag; Vaquero®



Attributes

- Name: [GRIP PANEL SCREW, SS](#)
- Manufacturer: [RUGER](#)
- Product no.: 780012017
- Mfr. No.:
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [GRIP PANEL SCREW, SS Safety Instruction Guide](#)
- [About Us](#)

GRIP PANEL SCREW, SS Safety Instruction Guide

Introduction

Thank you for choosing the GRIP PANEL SCREW, SS. This product is designed for use with various Ruger firearms, including models such as Bisley™, Blackhawk®, SingleSix®, and others. It is essential to follow the safety instructions outlined in this guide to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read and understand the instructions before using the product.
- Ensure the product is suitable for the specific firearm model you own.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for signs of wear or damage.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use only with compatible Ruger firearm models to prevent accidents or malfunctions.
- Avoid using excessive force during installation to prevent damage to the firearm or the screw.
- Ensure that the firearm is unloaded before attempting to install or remove the grip panel screw.
- Wear appropriate safety gear, such as eye protection, when handling firearms.
- Do not modify the product or the firearm in any way that could compromise safety.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is pointed in a safe direction and is unloaded.
- Gather necessary tools, such as a screwdriver suitable for the screw head type.

2. Installation

- Locate the grip panel on your Ruger firearm.
- Align the GRIP PANEL SCREW with the designated hole in the grip panel.
- Using the screwdriver, gently insert the screw and turn clockwise until secure. Do not overtighten.
- Check that the grip panel is firmly attached and does not shift.

3. Usage

- After installation, regularly check the screw to ensure it remains tight and secure.
- If you notice any looseness or damage, remove the screw and inspect it before reinstallation.

4. Removal

- To remove the GRIP PANEL SCREW, use the screwdriver to turn counterclockwise until the screw is free.
- Store the screw in a safe place if not in use.

Disposal Instructions

- Dispose of the GRIP PANEL SCREW in accordance with local regulations.

- Do not dispose of the product in household waste. Instead, use designated recycling facilities if available.

Contact Information for Further Support

- For safety inquiries or further assistance, please refer to the manufacturer's contact resources, which are available on the product packaging or the manufacturer's website.

By following these safety guidelines and instructions, you can ensure the safe use of the GRIP PANEL SCREW, SS with your Ruger firearm. Thank you for prioritizing safety in your firearm practices.

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se