

BASE PIN ASSEMBLY

[Handgun Parts](#) > [Action Parts](#) > [Base Pin Parts](#) > [Base Pin Assemblies](#)

FITS: Bisley™ Large Frame; New Model Blackhawk®; Super Blackhawk®, .44 Mag; Vaquero®



Attributes

- Name: [BASE PIN ASSEMBLY](#)
- Manufacturer: [RUGER](#)
- Product no.: 780012036
- Mfr. No.: MR02905
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.023kg
- Shipping width: 102mm
- Shipping length: 152mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for BASE PIN ASSEMBLY](#)
- [About Us](#)

Safety Instruction Guide for BASE PIN ASSEMBLY

Introduction

Thank you for choosing the BASE PIN ASSEMBLY. This product is designed to fit various Ruger firearms, including the Bisley™ Large Frame, New Model Blackhawk®, Super Blackhawk® in .44 Mag, and Vaquero®. This guide provides essential safety instructions and guidelines to ensure the safe use of this product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the BASE PIN ASSEMBLY is compatible with your firearm model before installation.
- Always handle firearms with care and follow all safety protocols.
- Store the product in a safe place, away from children and unauthorized users.
- Regularly check for any signs of wear or damage to the BASE PIN ASSEMBLY.
- Report any unsafe conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Always wear eye protection when handling or installing the BASE PIN ASSEMBLY.
- Do not attempt to modify the BASE PIN ASSEMBLY or use it with firearms for which it is not designed.
- Ensure that the firearm is unloaded before installing or removing the BASE PIN ASSEMBLY.
- Keep fingers away from the trigger until you are ready to fire.
- Follow the manufacturer's instructions for your specific firearm model regarding the use of base pins.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is pointed in a safe direction and is unloaded.
- Gather all necessary tools for installation.

2. Installation Steps

- Remove the existing base pin from your firearm by following the manufacturer's instructions.
- Take the BASE PIN ASSEMBLY and align it with the base pin opening on your firearm.
- Gently insert the BASE PIN ASSEMBLY into the opening until it is securely in place.
- Verify that the base pin is properly seated and does not move freely.

3. Usage

- Once installed, ensure that the BASE PIN ASSEMBLY is functioning correctly before firing.
- Regularly inspect the assembly during firearm maintenance to ensure continued safety and functionality.

Disposal Instructions

- Dispose of the BASE PIN ASSEMBLY in accordance with local regulations regarding firearm parts.
- Do not dispose of the product in regular household waste.
- If the product is damaged or no longer needed, consider returning it to the manufacturer or a licensed dealer for proper disposal.

Contact Information for Further Support

- For any safety inquiries or concerns regarding the BASE PIN ASSEMBLY, please contact your local authorized dealer or the manufacturer directly. Ensure you have the product details ready for reference.

By following these guidelines, you can help ensure the safe use of the BASE PIN ASSEMBLY and enjoy its benefits while minimizing risks. Always prioritize safety and adhere to local laws and regulations regarding firearms.

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se