

EJECTOR ROD, 4", BLUE

[Handgun Parts](#) > [Action Parts](#) > [Ejector Parts](#) > [Ejector Rods](#)

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®, .357, .41, .44-40, .45; New Model Single-Six®; Old Model Single-Six®, .22; Super Blackhawk®, .44 Mag; Vaquero®



Attributes

- Name: [EJECTOR ROD, 4", BLUE](#)
- Manufacturer: [RUGER](#)
- Product no.: 780012069
- Mfr. No.: XR55
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.014kg
- Shipping height: 1mm
- Shipping width: 102mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Ejector Rod, 4", Blue Consumer Safety Instruction Guide](#)
- [About Us](#)

Ejector Rod, 4", Blue Consumer Safety Instruction Guide

Introduction

Thank you for purchasing the Ejector Rod, 4", Blue. This product is designed to be compatible with various Ruger firearms, including the Bisley™ and Blackhawk® models. It is essential to follow the safety guidelines and instructions provided in this manual to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always handle the Ejector Rod with care to avoid injury.
- Ensure that the firearm is unloaded before installing or using the Ejector Rod.
- Keep the Ejector Rod out of reach of children and vulnerable individuals.
- Regularly inspect the Ejector Rod for any signs of wear or damage.
- In case of any malfunction or damage, discontinue use immediately and seek professional assistance.
- Be aware of your surroundings and ensure a safe environment when using firearms.

Specific Safety Precautions for Use

- Confirm compatibility with your specific firearm model before installation.
- Use only for its intended purpose as described in this manual.
- Avoid using excessive force during installation or removal to prevent damage.
- Wear protective eyewear when using firearms to protect against debris.
- Always follow the manufacturer's instructions for the proper handling and operation of your firearm.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools for installation, if required.

2. Installation:

- Locate the existing ejector rod on your firearm.
- Carefully remove the old ejector rod if applicable, following the manufacturer's instructions.
- Align the new Ejector Rod, ensuring it fits securely into place.
- Tighten any screws or fasteners as required, but do not overtighten.

3. Usage:

- After installation, perform a visual inspection to ensure the Ejector Rod is securely attached.
- Test the functionality of the Ejector Rod by operating the firearm in a safe environment.
- Always follow safe firearm handling practices while using the firearm equipped with the Ejector Rod.

Disposal Instructions

- Dispose of any old or damaged Ejector Rods in accordance with local regulations.
- Do not dispose of the Ejector Rod in household waste. Instead, contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns about the Ejector Rod, please refer to the manufacturer's website or contact their customer service for assistance. It is important to have a reliable source for safety inquiries and product support.

Conclusion

Your safety is our priority. By following the guidelines and instructions provided in this manual, you can ensure the safe use of the Ejector Rod, 4", Blue. If you encounter any issues or have concerns, do not hesitate to seek professional help. Thank you for choosing our product, and we wish you safe and enjoyable use.

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se