

EJECTOR ROD, SS

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®, .357, .41, .44-40, .45; New Model Single-Six®; Super Blackhawk®, .44 Mag; Vaquero®



Attributes

- Name: EJECTOR ROD, SS
- Manufacturer: RUGER
- Product no.: 780012070
- Mfr. No.: KXR55
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.014kg
- Shipping height: 5mm
- Shipping width: 107mm
- Shipping length: 170mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Ejector Rod Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för EJECTOR ROD, SS RUGER EJECTOR ROD, SS](#)

Ejector Rod Safety Instructions

Introduction

Thank you for choosing the Ejector Rod, SS. This product is designed for use with various Ruger firearms, including the Bisley™ Large Frame, Bisley™ Small Frame, New Model Blackhawk®, New Model SingleSix®, Super Blackhawk®, and Vaquero®. To ensure safe usage and compliance with EU regulations, please carefully read and follow the safety guidelines outlined in this document.

General Safety Guidelines

- Always handle firearms with care and ensure they are unloaded when installing or using the ejector rod.
- Keep the ejector rod out of reach of children and unauthorized users.
- Regularly inspect the ejector rod for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm ownership and usage.
- In case of an emergency, seek immediate assistance from qualified personnel.

Specific Safety Precautions for Use

- Ensure that the firearm is pointed in a safe direction at all times when handling the ejector rod.
- Do not attempt to modify or alter the ejector rod in any way.
- Use only compatible Ruger firearms as specified in the product description.
- Avoid using the ejector rod while wearing loose clothing or jewelry that may become entangled.
- If you experience any issues or malfunctions, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is completely unloaded and pointed in a safe direction.
- Remove the existing ejector rod if applicable, following the manufacturer's instructions.
- Align the new ejector rod with the mounting point on the firearm.
- Securely fasten the ejector rod in place, ensuring it is properly aligned and tightened.

2. Usage:

- To use the ejector rod, ensure the firearm is pointed in a safe direction.
- Operate the ejector rod as per the firearm's operational manual.
- Regularly check the ejector rod for proper functioning during use.

Disposal Instructions

- Dispose of the ejector rod in accordance with local regulations regarding hazardous materials.
- Do not dispose of the ejector rod in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any inquiries regarding safety or product support, please refer to the EU-based contact point provided with your product packaging. It is essential to have this information readily available for any safety concerns or product inquiries.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of your Ejector Rod, SS. Always prioritize safety and compliance with local laws to protect yourself and others. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för EJECTOR ROD, SS RUGER EJECTOR ROD, SS

Introduktion

Tack för att du valt EJECTOR ROD, SS RUGER EJECTOR ROD, SS. Denna produkt är designad för att användas med specifika Rugermodeller. För att säkerställa säker och effektiv användning är det viktigt att följa dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Förvara produkten utom räckhåll för barn och sårbara grupper.
- Rapportera eventuella osäkra produkter eller olyckor till myndigheterna.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Kontrollera att EJECTOR ROD är korrekt installerad innan användning.
- Använd skyddsglasögon och handskar vid installation och användning för att skydda mot eventuella skador.
- Undvik att använda produkten om den visar tecken på skador eller defekter.
- Följ alltid säkerhetsanvisningarna för det vapen som EJECTOR ROD används med.

Instruktioner för installation och användning

1. Installation:

- Säkerställ att vapnet är avstängt och ur funktion innan installation.
- Ta bort den gamla EJECTOR ROD om det behövs.
- Installera den nya EJECTOR ROD genom att följa tillverkarens specifikationer.
- Kontrollera att EJECTOR ROD sitter ordentligt på plats innan användning.

2. Användning:

- Använd EJECTOR ROD endast med kompatibla Rugermodeller, inklusive:
 - Bisley™ Större Ram
 - Bisley™ Mindre Ram
 - New Model Blackhawk®, .357, .41, .4440, .45
 - New Model SingleSix®
 - Super Blackhawk®, .44 Mag
 - Vaquero®
- Följ alltid vapnets bruksanvisning vid användning av EJECTOR ROD.

Avfallsinstruktioner

- Kassera produkten på ett miljövänligt sätt i enlighet med lokala avfallsbestämmelser.
- Om produkten är skadad eller defekt, kontakta en auktoriserad återförsäljare för vägledning om hur den ska kasseras.

Kontaktinformation för vidare support

För frågor eller ytterligare support, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modellnummer och inköpsinformation tillgänglig.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av EJECTOR ROD, SS RUGER EJECTOR ROD, SS. Tack för att du prioriterar säkerhet!