

GRIP PANELS, LAMINATED ROSEWOOD

FITS: New Model Blackhawk®; New Model Single-Six®; Old Army™, .45; Vaquero®



Attributes

- Name: GRIP PANELS, LAMINATED ROSEWOOD
- Manufacturer: RUGER
- Product no.: 780012073
- Mfr. No.: 70046
- Color: Rosewood
- Make: Ruger
- Material: Wood
- Model: Blackhawk
- Style: Panels
- Surface: Smooth
- Delivery weight: 0.068kg
- Shipping height: 20mm
- Shipping width: 66mm
- Shipping length: 109mm
- UPC: 736676700462

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- [Startpage](#)
- [English: GRIP PANELS Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för GRIP PANELS, LAMINATED ROSEWOOD](#)

GRIP PANELS Safety Instruction Guide

Introduction

Thank you for choosing the GRIP PANELS, Laminated Rosewood Grip Panels. This product is designed to enhance your shooting experience while ensuring safety and comfort. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Always handle your firearm with care and respect.
- Ensure that the firearm is unloaded before installing or handling the grip panels.
- Keep the grip panels and all firearm accessories out of reach of children and unauthorized users.
- Regularly inspect the grip panels for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm safety and handling.

Specific Safety Precautions for Use

- Use only with compatible firearm models: New Model Blackhawk®, New Model SingleSix®, Old Army™, .45, and Vaquero®.
- Ensure that the grip panels are securely attached to the firearm before each use.
- Avoid exposing the grip panels to extreme temperatures or moisture, as this may affect their integrity.
- If you notice any defects or issues with the grip panels, discontinue use immediately and seek assistance.
- Do not modify the grip panels in any way, as this can compromise safety and performance.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded.
- Gather all necessary tools for installation, typically a screwdriver.

2. Installation Steps

- Remove the existing grip panels from the firearm by unscrewing the screws carefully.
- Align the new laminated rosewood grip panels with the firearm's grip frame.
- Secure the grip panels using the screws provided, ensuring they are tightened but not overtightened to avoid damage.

3. Usage

- Hold the firearm securely by the grip panels.
- Practice safe shooting techniques and maintain control of the firearm at all times.

4. PostInstallation Check

- After installation, doublecheck the screws to ensure they are secure.
- Test the grip panels for stability before using the firearm.

Disposal Instructions

- Dispose of any packaging materials responsibly and in accordance with local regulations.
- If the grip panels become damaged beyond repair, follow local guidelines for disposing of wooden materials.

Contact Information for Further Support

For any safety inquiries or assistance, please reach out to the designated EU contact point. Ensure you have the product details on hand for a quicker response.

By following these guidelines, you can ensure safe and effective use of your GRIP PANELS, Laminated Rosewood Grip Panels. Always prioritize safety and responsible handling of your firearm.

Säkerhetsinstruktioner för GRIP PANELS, LAMINATED ROSEWOOD

Introduktion

Tack för att du valt GRIP PANELS, LAMINATED ROSEWOOD från Ruger. Denna produkt är utformad för att förbättra ditt grepp och ge en bättre upplevelse vid användning av din pistol. För att säkerställa säkerheten och optimal användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens anvisningar.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Förvara produkten på en säker plats, utom räckhåll för barn.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Undvik att använda produkten om den är skadad eller defekt.
- Använd inte produkten i miljöer som är extrema (t.ex. mycket fuktiga eller varma).
- Se till att grepppanelerna är korrekt installerade innan du använder vapnet.
- Använd alltid skyddsglasögon och hörselskydd vid hantering av vapen.
- Håll alltid vapnet riktat på ett säkert sätt och hantera det som om det alltid är laddat.

Instruktioner för installation och användning

1. Installation av grepppaneler:

- Ta bort de gamla grepppanelerna från din Rugerpistol med hjälp av en lämplig skruvmejsel.
- Placera de nya laminatrosenträgrepppanelerna på plats.
- Se till att alla skruvar är åtdragna ordentligt men inte överdrivet hårt för att undvika skador på materialet.

2. Användning av grepppaneler:

- Håll vapnet med ett fast grepp, se till att fingrarna inte är i vägen för avtryckaren.
- Öva på att hantera vapnet i en säker och kontrollerad miljö.
- Var uppmärksam på hur grepppanelerna påverkar din hantering och justera din teknik vid behov.

Avfallshanteringsanvisningar

- När du inte längre behöver grepppanelerna, se till att de kasseras på ett miljövänligt sätt.
- Kontakta din lokala avfallshantering för information om hur du korrekt återvinner eller kasserar träprodukter.

Kontaktinformation för ytterligare stöd

För frågor eller mer information om produkten, vänligen kontakta tillverkaren eller din återförsäljare. Se till att alltid ha produktens serienummer tillgängligt för snabbare assistans.

Tack för att du följer dessa säkerhetsanvisningar och för att du bidrar till en säker användning av dina GRIP PANELS, LAMINATED ROSEWOOD.