

GRIP FRAME SCREW, B-BACK

FITS: New Model Blackhawk®; New Model Single-Six®; Old Army™, .45; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®



Attributes

- Name: GRIP FRAME SCREW, B-BACK
- Manufacturer: RUGER
- Product no.: 780012079
- Mfr. No.: XR01800
- Make: Ruger
- Model: Single Six
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: GRIP FRAME SCREW, BBACK SAFETY INSTRUCTION GUIDE](#)
- [Svenska: Säkerhetsinstruktioner för GRIP FRAME SCREW, BBACK RUGER](#)

GRIP FRAME SCREW, BBACK SAFETY

INSTRUCTION GUIDE

Introduction

Thank you for purchasing the GRIP FRAME SCREW, BBACK. This product is designed for specific Ruger firearm models to ensure proper functionality and safety. Please read this guide carefully to understand how to use and install the product safely.

General Safety Guidelines

- Always ensure that the firearm is unloaded before performing any maintenance or installation.
- Use the product only as intended and in accordance with the manufacturer's specifications.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the product for wear and tear. Replace if damaged.
- Report any unsafe conditions or incidents related to the product to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the GRIP FRAME SCREW is compatible with your firearm model:
 - New Model Blackhawk®
 - New Model SingleSix®
 - Old Army™, .45
 - Super Blackhawk®, .44 Mag
 - Super Blackhawk® Hunter, .44 Mag
 - Vaquero®
- Handle all firearm components with care to avoid accidental discharge.
- Use appropriate tools when installing or removing the GRIP FRAME SCREW to prevent injury.
- Follow all local laws and regulations regarding firearm ownership and maintenance.

Instructions for Installation and Usage

1. Preparation

- Ensure your firearm is unloaded and pointed in a safe direction.
- Gather the necessary tools for installation (e.g., screwdriver).

2. Installation Steps

- Locate the grip frame on your firearm.
- Remove any existing screws carefully to avoid damaging the grip frame.
- Align the GRIP FRAME SCREW with the designated screw hole.
- Tighten the screw gently using the screwdriver until secure, but do not overtighten to avoid stripping the threads.

3. PostInstallation Checks

- After installation, check that the grip is securely attached and does not move.
- Perform a function check of the firearm to ensure it operates correctly.

4. Usage

- Use the firearm in accordance with the manufacturer's instructions and safety guidelines.
- Regularly check the GRIP FRAME SCREW for tightness and integrity during routine maintenance.

Disposal Instructions

- Dispose of any damaged or worn GRIP FRAME SCREWS in accordance with local regulations for hazardous materials.
- Do not dispose of the product in regular household waste. Contact local waste management for guidance on proper disposal.

Contact Information for Further Support

For any questions or concerns regarding the GRIP FRAME SCREW, please consult the manufacturer's website or contact customer support for assistance. Always ensure that you have the product information and your purchase details ready when seeking support.

By following these guidelines, you can ensure safe and effective use of the GRIP FRAME SCREW, BBACK. Your safety is our priority.

Säkerhetsinstruktioner för GRIP FRAME SCREW, BBACK RUGER

Introduktion

Tack för att du valt GRIP FRAME SCREW, BBACK från RUGER. Denna produkt är designad för att användas med specifika Rugermodeller. För att säkerställa säker användning och långvarig prestanda, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Säkerställ att produkten används enligt tillverkarens instruktioner för att undvika skador.
- Kontrollera produkten regelbundet för tecken på slitage eller skada.
- Förvara produkten utom räckhåll för barn och andra sårbara grupper.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser genom EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid produkten i enlighet med de specifika modeller den är avsedd för: New Model Blackhawk®, New Model SingleSix®, Old Army™, .45 Super Blackhawk®, .44 Mag Super Blackhawk® Hunter, .44 Mag Vaquero®
- Använd skyddsglasögon och handskar vid installation och hantering.
- Undvik att använda produkten om den är skadad eller defekt.
- Följ alltid lokala lagar och förordningar gällande användning av vapen och tillbehör.

Instruktioner för installation och användning

• Installation:

1. Se till att vapnet är avstängt och inte laddat innan installation.
2. Ta bort det gamla greppskruven med rätt verktyg.
3. Placera den nya GRIP FRAME SCREW på rätt plats.
4. Använd ett momentverktyg för att åtdra skruven till rekommenderat vridmoment.

• Användning:

1. Kontrollera att skruven är ordentligt åtdragen innan varje användning.
2. Om du upplever några problem med skruven, avbryt användningen omedelbart och kontakta en specialist.

Avfallshanteringsanvisningar

- Kasta inte produkten i hushållsavfallet.
- Följ lokala riktlinjer för avfallshantering av metallprodukter.
- Återvinn så mycket som möjligt av produkten i enlighet med lokala återvinningsprogram.

Kontaktinformation för ytterligare support

För frågor eller ytterligare support, vänligen kontakta din lokala återförsäljare eller tillverkare. Se till att ha produktens modellnummer och inköpsinformation tillgänglig vid kontakt.

Tack för att du väljer RUGER. Din säkerhet är vår prioritet.