

# BASE PIN LATCH, SS

[Handgun Parts](#) > [Action Parts](#) > [Base Pin Parts](#) > [Base Pin Latches](#)

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®; New Model Single-Six®; Super Blackhawk®, .44 Mag; Vaquero®



## Attributes

- Name: [BASE PIN LATCH, SS](#)
- Manufacturer: [RUGER](#)
- Product no.: 780012085
- Mfr. No.:
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- BASE PIN LATCH Safety Instructions
- About Us

# BASE PIN LATCH Safety Instructions

## Introduction

Thank you for choosing the BASE PIN LATCH, SS. This product is designed to enhance the functionality of your firearms, specifically compatible with Bisley™ Large Frame, Bisley™ Small Frame, New Model Blackhawk®, New Model SingleSix®, Super Blackhawk®, .44 Mag, and Vaquero® models. Please read this safety instruction guide carefully to ensure safe and proper use of the product.

## General Safety Guidelines

- Always ensure that the firearm is unloaded before installing or handling the BASE PIN LATCH.
- Follow all local laws and regulations regarding firearm modifications and accessories.
- Use the product only for its intended purpose as specified in the product description.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the BASE PIN LATCH for wear and tear. Replace if damaged.
- Report any unsafe products or accidents to the appropriate authorities.

## Specific Safety Precautions for Use

- Ensure that the BASE PIN LATCH is compatible with your firearm model before installation.
- Do not force the latch into place; it should fit snugly without excessive pressure.
- Avoid using the product if it shows signs of damage or unusual wear.
- Always wear appropriate safety gear when handling firearms, including eye protection.
- Be aware of your surroundings and ensure a safe environment when using your firearm with the BASE PIN LATCH.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools for installation, if required.

### 2. Installation:

- Locate the base pin area on your firearm.
- Remove the existing base pin, if applicable.
- Insert the BASE PIN LATCH into the designated area, ensuring it aligns correctly.
- Secure the latch according to the manufacturer's specifications. Refer to your firearm's manual for specific instructions if needed.

### 3. Usage:

- After installation, test the BASE PIN LATCH to ensure it operates smoothly.
- Regularly check the latch for proper function before use.
- If any issues arise during usage, cease operation immediately and inspect the latch.

### 4. PostUse Care:

- Clean the BASE PIN LATCH regularly to maintain its function.
- Store the firearm in a secure location when not in use.

## Disposal Instructions

- Dispose of the BASE PIN LATCH in accordance with local regulations.
- If the product is damaged beyond repair, consider recycling the materials if possible.
- Ensure that all components are disposed of safely to prevent any potential hazards.

## Contact Information for Further Support

For any inquiries regarding safety, installation, or product performance, please reach out to the designated support channels provided with your purchase.

Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation. Enjoy using your BASE PIN LATCH responsibly!

# About Us

## Brownells Sverige

**Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör**

Brownells Sverige AB  
Box 99  
793 22 Leksand  
Sverige

[www.brownells.se](http://www.brownells.se)