

BASE PIN LATCH NUT, SS

[Handgun Parts](#) > [Action Parts](#) > [Base Pin Parts](#) > [Base Pin Latch Nuts](#)

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®; New Model Single-Six®; Super Blackhawk®, .44 Mag; Vaquero®



Attributes

- Name: [BASE PIN LATCH NUT, SS](#)
- Manufacturer: [RUGER](#)
- Product no.: 780012087
- Mfr. No.:
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- Startpage
- BASE PIN LATCH NUT, SS Safety Instruction Guide
- About Us

BASE PIN LATCH NUT, SS Safety Instruction Guide

Introduction

Thank you for choosing the BASE PIN LATCH NUT, SS. This guide provides essential safety instructions and guidelines to ensure the safe use and proper handling of this product. It is important to follow these instructions to avoid potential hazards and to ensure compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read and understand the instructions before using the product.
- Ensure that the product is suitable for your specific firearm model as listed.
- Regularly inspect the product for wear and tear; do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or incidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure the firearm is unloaded before installing or adjusting the BASE PIN LATCH NUT.
- Use only compatible firearms:
 - Bisley™ Large Frame
 - Bisley™ Small Frame
 - New Model Blackhawk®
 - New Model SingleSix®
 - Super Blackhawk®, .44 Mag
 - Vaquero®
- Do not modify the product in any way; alterations may compromise safety.
- Wear appropriate safety gear, such as eye protection, when handling firearms.
- Follow all manufacturer guidelines for the firearm to ensure safe operation.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is completely unloaded.
- Gather necessary tools for installation, such as a screwdriver.

2. Installation:

- Locate the base pin latch area on your firearm.
- Align the BASE PIN LATCH NUT with the designated area.
- Securely fasten the nut using the appropriate tool until snug, but do not overtighten.

3. Usage:

- After installation, perform a function check of the firearm to ensure proper operation.
- Regularly check the installation of the BASE PIN LATCH NUT to ensure it remains secure.

Disposal Instructions

- Dispose of any unused or damaged products in accordance with local regulations.
- Do not dispose of the product in regular household waste; check for recycling programs in your area.

Contact Information for Further Support

For any inquiries or concerns regarding the BASE PIN LATCH NUT, SS, please refer to the manufacturer's contact information provided on the packaging or product documentation.

By following these safety guidelines and instructions, you can ensure the safe use of the BASE PIN LATCH NUT, SS and contribute to a safer shooting experience. Thank you for your attention to these important safety measures.

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se