

## EJECTOR HOUSING SCREW, SS

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®



### Attributes

- Name: EJECTOR HOUSING SCREW, SS
- Manufacturer: RUGER
- Product no.: 780012089
- Mfr. No.: KXR03301
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

### Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [English: Ejector Housing Screw, SS Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för EJECTOR HOUSING SCREW, SS](#)

# Ejector Housing Screw, SS Safety Instruction Guide

## Introduction

Thank you for choosing the Ejector Housing Screw, SS. This product is designed for use with various Ruger firearms, including the Bisley™ Large Frame, Bisley™ Small Frame, New Model Blackhawk®, Super Blackhawk® (.44 Mag), Super Blackhawk® Hunter (.44 Mag), and Vaquero®. This guide provides essential safety instructions to ensure the safe use and installation of this product in compliance with the EU General Product Safety Regulation (GPSR).

## General Safety Guidelines

- Always handle firearms and their components with care and respect.
- Ensure that the product is compatible with your firearm model before installation.
- Store the product in a safe, dry place away from children and unauthorized users.
- Regularly inspect the product for signs of wear or damage.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Do not attempt to install the Ejector Housing Screw, SS if you are not familiar with firearm maintenance.
- Always ensure the firearm is unloaded before beginning any installation or maintenance work.
- Wear appropriate safety gear, such as eye protection, when working with firearms.
- Keep your work area clean and free from distractions during installation.
- If you experience any difficulties during installation, seek assistance from a qualified gunsmith.

## Instructions for Installation and Usage

### 1. Preparation

- Ensure that the firearm is completely unloaded.
- Gather all necessary tools, including a screwdriver that fits the screw head.

### 2. Installation Steps

- Identify the location of the ejector housing on your firearm.
- Remove the old ejector housing screw if applicable.
- Align the new Ejector Housing Screw, SS with the screw hole.
- Carefully insert and tighten the screw using the appropriate screwdriver. Do not overtighten, as this may damage the housing.
- Once installed, check to ensure that the ejector housing is secure and functions properly.

### 3. PostInstallation Check

- After installation, conduct a thorough inspection of the firearm to ensure all components are installed correctly and securely.
- Test the functionality of the ejector housing by cycling the action of the firearm without ammunition.

## **Disposal Instructions**

- Dispose of any old or unused screws and components in accordance with local regulations.
- Do not dispose of the product in household waste. Check for local recycling programs or hazardous waste disposal sites.

## **Contact Information for Further Support**

For any questions or concerns regarding the Ejector Housing Screw, SS, please reach out to the appropriate authorities or consult with a qualified gunsmith for assistance.

Thank you for prioritizing safety and compliance in your firearm maintenance practices.

# Säkerhetsinstruktioner för EJECTOR HOUSING SCREW, SS

## Introduktion

Tack för att du valt EJECTOR HOUSING SCREW, SS. Denna produkt är utformad för att säkerställa korrekt funktion och säkerhet vid användning av Rugervapen. Vänligen läs och följ dessa säkerhetsinstruktioner noggrant för att minimera risker och säkerställa en trygg användning.

## Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten för skador innan användning. Använd inte om den är skadad.
- Rapportera osäkra produkter och olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

## Specifika säkerhetsåtgärder för användning

- Använd skyddsglasögon och handskar vid installation och hantering av produkten.
- Se till att vapnet är avstängt och inte laddat innan installation av EJECTOR HOUSING SCREW.
- Undvik att använda produkten i ogynnsamma miljöer, såsom fuktiga eller extremt varma platser.
- Följ alltid lokala lagar och förordningar angående vapenhantering och användning.

## Instruktioner för installation och användning

### 1. Förberedelse:

- Kontrollera att du har rätt verktyg för installationen.
- Läs igenom hela installationsanvisningen innan du påbörjar arbetet.

### 2. Installation:

- Ta bort det befintliga ejector housing från vapnet.
- Rengör området där den nya EJECTOR HOUSING SCREW ska installeras.
- Placera den nya skruven på plats och dra åt den med rätt moment för att säkerställa stabilitet.
- Kontrollera att allt är korrekt installerat innan du använder vapnet.

### 3. Användning:

- Efter installation, testa vapnet för att säkerställa att det fungerar som avsett.
- Utför regelbundna kontroller av skruven för att säkerställa att den är åtdragen och i gott skick.

## Avfallshantering

- Avfallshantering av produkten ska ske enligt lokala föreskrifter för avfallshantering.
- Om produkten är skadad eller inte längre behövs, se till att den kasseras på ett säkert sätt för att undvika potentiella risker.

## Kontaktinformation för vidare support

För frågor eller ytterligare information om produkten, vänligen kontakta den lokala återförsäljaren eller tillverkaren för support.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.