

EJECTOR HOUSING SCREW, SS

[Handgun Parts](#) > [Action Parts](#) > [Ejector Parts](#) > [Ejector Screws](#)

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®



Attributes

- Name: [EJECTOR HOUSING SCREW, SS](#)
- Manufacturer: [RUGER](#)
- Product no.: 780012089
- Mfr. No.: KXR03301
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Ejector Housing Screw, SS Safety Instruction Guide](#)
- [About Us](#)

Ejector Housing Screw, SS Safety Instruction Guide

Introduction

Thank you for choosing the Ejector Housing Screw, SS. This product is designed for use with various Ruger firearms, including the Bisley™ Large Frame, Bisley™ Small Frame, New Model Blackhawk®, Super Blackhawk® (.44 Mag), Super Blackhawk® Hunter (.44 Mag), and Vaquero®. This guide provides essential safety instructions to ensure the safe use and installation of this product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always handle firearms and their components with care and respect.
- Ensure that the product is compatible with your firearm model before installation.
- Store the product in a safe, dry place away from children and unauthorized users.
- Regularly inspect the product for signs of wear or damage.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not attempt to install the Ejector Housing Screw, SS if you are not familiar with firearm maintenance.
- Always ensure the firearm is unloaded before beginning any installation or maintenance work.
- Wear appropriate safety gear, such as eye protection, when working with firearms.
- Keep your work area clean and free from distractions during installation.
- If you experience any difficulties during installation, seek assistance from a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is completely unloaded.
- Gather all necessary tools, including a screwdriver that fits the screw head.

2. Installation Steps

- Identify the location of the ejector housing on your firearm.
- Remove the old ejector housing screw if applicable.
- Align the new Ejector Housing Screw, SS with the screw hole.
- Carefully insert and tighten the screw using the appropriate screwdriver. Do not overtighten, as this may damage the housing.
- Once installed, check to ensure that the ejector housing is secure and functions properly.

3. PostInstallation Check

- After installation, conduct a thorough inspection of the firearm to ensure all components are installed correctly and securely.
- Test the functionality of the ejector housing by cycling the action of the firearm without ammunition.

Disposal Instructions

- Dispose of any old or unused screws and components in accordance with local regulations.
- Do not dispose of the product in household waste. Check for local recycling programs or hazardous waste disposal sites.

Contact Information for Further Support

For any questions or concerns regarding the Ejector Housing Screw, SS, please reach out to the appropriate authorities or consult with a qualified gunsmith for assistance.

Thank you for prioritizing safety and compliance in your firearm maintenance practices.

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se